HIGH-RISK ACTIVITY | SERNEM PRO SERIES | VERIFIED 2026

SERNEM

HEALTH AND SAFETY RESOURCES

WORKING AT HEIGHT CRITICAL SAFETY RULES

PLAN • PRIORITIZE COLLECTIVE PROTECTION • PREVENT FALLS

OSHA 29 CFR 1926 | EN 361 • EN 365 • EN 795 | ISO 45001 FRAMEWORK

DOCUMENT
SRN-WAH-001
Revision 2.0
EN

SCAN
Open the digital poster library

SERNEM PRE-JOB CONTROL — CHECK BEFORE STARTING

30 SEC CHECK

- ☐ WORK PERMIT
- ☐ RISK ASSESSMENT
- ☐ TOOLBOX TALK
- ☐ RESCUE PLAN
- ☐ WEATHER
- ☐ PPE CHECK
- ☐ AREA ISOLATION

01 — MANDATORY



PRE-WORK PLANNING

- Verify the risk assessment and work permit.
- Define the safe access and work method.
- Barricade the area below and prevent unauthorized access.

02 — MANDATORY



USE COLLECTIVE PROTECTION

- Use guardrails, platforms or suitable scaffolds first.
- Protect openings with secure covers or barriers.
- Do not start if collective protection is incomplete.

03 — MANDATORY



FULL BODY HARNESS

- Inspect webbing, stitching and labels before every use.
- Wear, fasten and adjust the harness correctly.
- Remove damaged or fall-arrested equipment from service.

04 — MANDATORY



APPROVED ANCHORAGE

- Connect only to a designated and approved anchorage.
- Verify a capacity of 22.2 kN per attached worker.
- Select an anchorage above head level whenever possible.

05 — WARNING



FALL CLEARANCE

- Calculate free-fall and total clearance distance.
- Prevent contact with lower levels or obstructions.
- Minimize the risk of a swing fall.

06 — MANDATORY



SAFE ACCESS

- Use inspected access equipment suitable for the task.
- Maintain three-point contact on ladders.
- Keep access routes clear, stable and unobstructed.

07 — WARNING



PREVENT DROPPED OBJECTS

- Secure tools using a suitable tethering system.
- Store materials safely away from edges.
- Isolate the area below and control access.

08 — INFORMATION



RESCUE READINESS

- Prepare a workable rescue plan before starting.
- Ensure rescue equipment and trained personnel are available.
- Verify emergency communication and response arrangements.

CRITICAL STOP CRITERIA — STOP WORK NOW

STOP

- THERE IS NO APPROVED ANCHORAGE OR FALL PROTECTION
- THE HARNESS, LANYARD OR CONNECTOR IS DAMAGED
- AN UNPROTECTED EDGE OR OPEN HOLE IS PRESENT
- NO RESCUE PLAN OR RESPONSE CAPABILITY IS AVAILABLE
- WIND, ICE OR VISIBILITY CONDITIONS ARE UNSAFE

TECHNICAL CONTROL — CRITICAL VALUES

1,8 m — OSHA CONSTRUCTION THRESHOLD	**22,2 kN** — ANCHORAGE VALUE / WORKER
100% — CONTINUOUS TIE-OFF	**3-POINT** — LADDER CONTACT

REFERENCE
OSHA 29 CFR 1926.501 / 1926.502
EN 361 • EN 365 • EN 795

PERSONAL PROTECTIVE EQUIPMENT — REQUIRED PPE

- CHIN-STRAP HELMET — EN 397
- SAFETY GLASSES — EN 166
- WORK GLOVES — EN 388
- SLIP-RESISTANT FOOTWEAR — ISO 20345
- FULL BODY HARNESS — EN 361

ENGINEERING CONTROLS FIRST, PERSONAL PROTECTION SECOND.

SERNEM
Better Safety, Better Tomorrow.

STOP WORK IF IT IS UNSAFE!

VERIFIED • PRO SERIES • 2026
www.sernem.com