HSE FIELD GUIDE | SERNEM PRO SERIES | SITE VALIDATION REQUIRED

**SERNEM**

HEALTH AND SAFETY RESOURCES

# WORKING AT HEIGHT CRITICAL SAFETY RULES

PLAN • PRIORITIZE COLLECTIVE PROTECTION • PREVENT FALLS

OSHA 1926.501(B)(1) / .502(D)(15) | OSHA - US SCOPE | VERIFY LOCAL REQUIREMENTS SEPARATELY

DOCUMENT
SRN-WAH-001
Revision 2.0
EN

SCAN
Open the digital poster library

## SERNEM PRE-JOB CONTROL
## CHECK BEFORE STARTING

PRE-JOB CHECK

- ☐ WORK PERMIT
- ☐ RISK ASSESSMENT
- ☐ COLLECTIVE PROTECTION
- ☐ APPROVED ANCHORAGE
- ☐ FALL CLEARANCE
- ☐ RESCUE PLAN
- ☐ WEATHER AND DROP ZONE

## 01 — MANDATORY
### PRE-WORK PLANNING

- Verify the risk assessment and work permit.
- Define the safe access and work method.
- Barricade the area below and prevent unauthorized access.

## 02 — MANDATORY
### USE COLLECTIVE PROTECTION

- Prioritize collective protection using guardrails, platforms or suitable scaffolds; protect openings.
- OSHA construction: unprotected edges at ≥6 ft (1.8 m) require guardrails, safety nets or personal fall arrest.
- This threshold is not universal: scaffolds and ladders have separate rules. Lower heights are not automatically safe.

## 03 — MANDATORY
### FULL BODY HARNESS

- Inspect webbing, stitching and labels before every use.
- Wear, fasten and adjust the harness correctly.
- Remove damaged or fall-arrested equipment from service.

## 04 — MANDATORY
### APPROVED ANCHORAGE

- Personal fall-arrest anchorages must be independent of anchorages supporting or suspending platforms.
- OSHA: at least 5,000 lb (22.2 kN) per attached employee; OR the alternative design below.
- Alternative: a complete system with a safety factor of at least 2, designed, installed and used under a qualified person's supervision.

## 05 — WARNING
### FALL CLEARANCE

- Calculate free-fall and total clearance distance.
- Prevent contact with lower levels or obstructions.
- Minimize the risk of a swing fall.

## 06 — MANDATORY
### SAFE ACCESS

- Use inspected access equipment suitable for the task.
- Maintain three-point contact on ladders.
- Keep access routes clear, stable and unobstructed.

## 07 — WARNING
### PREVENT DROPPED OBJECTS

- Secure tools using a suitable tethering system.
- Store materials safely away from edges.
- Isolate the area below and control access.

## 08 — INFORMATION
### RESCUE READINESS

- Prepare a workable rescue plan before starting.
- Ensure rescue equipment and trained personnel are available.
- Verify emergency communication and response arrangements.

## CRITICAL STOP CRITERIA
## STOP WORK NOW

STOP

- THERE IS NO APPROVED ANCHORAGE OR FALL PROTECTION
- THE HARNESS, LANYARD OR CONNECTOR IS DAMAGED
- AN UNPROTECTED EDGE OR OPEN HOLE IS PRESENT
- NO RESCUE PLAN OR RESPONSE CAPABILITY IS AVAILABLE
- WIND, ICE OR VISIBILITY CONDITIONS ARE UNSAFE

## TECHNICAL CONTROL
## CRITICAL CONTROLS

**COLLECTIVE**
GUARDRAILS AND PLATFORMS FIRST

**5,000 lb**
22.2 KN PER EMPLOYEE OR COMPLETE SYSTEM WITH FACTOR ≥2 UNDER QUALIFIED SUPERVISION

**CLEARANCE**
PREVENT LOWER-LEVEL CONTACT

**RESCUE**
PREPARE BEFORE WORK

TECHNICAL REFERENCE · VALIDATION REQUIRED
OSHA 1926.501(b)(1) / .502(d)(15)
Verify source scope and local requirements

## PERSONAL PROTECTIVE EQUIPMENT
## RISK-BASED PPE SELECTION

- **CHIN-STRAP HELMET** — HEAD AND CHIN-STRAP FIT
- **SAFETY GLASSES** — EYE PARTICLE HAZARD
- **WORK GLOVES** — GRIP AND MECHANICAL RISK
- **SLIP-RESISTANT FOOTWEAR** — SLIP-RESISTANT SOLE
- **FULL BODY HARNESS** — COMPATIBLE FALL SYSTEM

SELECT PPE BY RISK, MANUFACTURER AND SITE PROCEDURE; THIS LIST IS NOT MANDATORY FOR EVERY TASK.

**SERNEM**
Better Safety, Better Tomorrow.

**STOP WORK IF IT IS UNSAFE!**

VERIFY SITE PROCEDURE
www.sernem.com