

HSE TOOLBOX TALK

BARRICADING AND EXCLUSION ZONES TOOLBOX TALK

PURPOSE AND SCOPE

Prevent personnel from entering hazardous areas during lifting, excavation, pressure testing, hot work, falling-object exposure and mobile-equipment operations.

KEY HAZARDS

1  Uncontrolled entry into equipment or	2  Falling or projected objects travelling	3  Unauthorised approach to excavations, openings	4  Whipping hoses or failed fittings during pressure
5  Interaction between pedestrian and vehicle	6  Poor barricade visibility during night or low-light	7  Damaged or missing barricades allowing	8  Missing or unclear warning information at

CRITICAL POINTS TO VERIFY IN THE FIELD

01

Uncontrolled entry into equipment or suspended-load

02

Falling or projected objects travelling beyond an inadequate

03

Unauthorised approach to excavations, openings or level



REMEMBER — SERNEM

S

Stop and think

E

Evaluate the risk

R

Remove or reduce

N

Never assume

E

Ensure protection

M

Monitor and communicate

HSE TOOLBOX TALK

BARRICADING AND EXCLUSION ZONES TOOLBOX TALK

FIELD REQUIREMENTS AND VERIFICATION

Prevent personnel from entering hazardous areas during lifting, excavation, pressure testing, hot work, falling-object exposure and mobile-equipment operations.

SERNEM FIELD 01

FIELD VERIFICATION 1

Hazard area identified

SERNEM FIELD 02

FIELD VERIFICATION 2

Barricade distance suitable

SERNEM FIELD 03

FIELD VERIFICATION 3

Entry points controlled

SERNEM FIELD 04

FIELD VERIFICATION 4

Warnings displayed

VERIFICATION BEFORE START

- | | |
|--|--|
| ☐ Hazard area identified | ☐ Barricade distance suitable |
| ☐ Entry points controlled | ☐ Warnings displayed |
| ☐ Barricade intact | ☐ Pedestrian route safe |

SUPERVISOR DISCUSSION POINTS

- What hazard requires an exclusion zone today?
- How was the barricade distance determined?
- How will unauthorised entry be prevented?

FIELD APPLICATION



Barricades must keep people outside the true reach of the hazard.

HSE TOOLBOX TALK

BARRICADING AND EXCLUSION ZONES TOOLBOX TALK

CRITICAL CONTROL MEASURES

1. ELIMINATE / REDUCE THE RISK

Identify the maximum hazard reach and place barricades beyond that boundary. • Confirm pedestrian routes do not pass through the restricted area. • Remove barricades only after the area has been confirmed safe.

2. ENGINEERING & PHYSICAL CONTROLS

Use the correct barricade type and colour coding required by site rules. • Use reflective barricades or additional lighting for night work. • Reassess the exclusion zone whenever the task or site conditions change.

3. WORK METHOD & FIELD CONTROLS

Clearly display the hazard and access restriction. • Define pressure-test and lifting exclusion distances through risk assessment.

4. PPE, VERIFICATION & SUPERVISION

Establish controlled entry points and attendants where required. • Inspect barricade integrity throughout the shift.

CRITICAL WARNING



Team, simply standing outside a tape line does not guarantee safety. Today we will position barricades according to the real hazard radius, control access and maintain the exclusion zone throughout the job.

SITE CHECKLIST — BEFORE STARTING WORK

- | | |
|--|---|
| ☐ Hazard area identified | ☐ Barricade distance suitable |
| ☐ Entry points controlled | ☐ Warnings displayed |
| ☐ Barricade intact | ☐ Pedestrian route safe |
| ☐ Lighting adequate | ☐ Attendant requirement assessed |
| ☐ Crew briefed | ☐ Removal criteria defined |

HSE TOOLBOX TALK

BARRICADING AND EXCLUSION ZONES TOOLBOX TALK

ATTENDANCE AND APPROVAL

Project / Site:

Date:

Presented by:

Work area:

No	Full Name	Company / Role	Signature
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			