

PERMIT TO WORK SYSTEM

Jointly verify scope, location, simultaneous activities, isolations and critical controls before authorizing hazardous work, and safely manage the permit through shift and job-status changes.

PURPOSE AND SCOPE

Jointly verify scope, location, simultaneous activities, isolations and critical controls before authorizing hazardous work, and safely manage the permit through shift and job-status changes.

KEY HAZARDS

1  WRONG SCOPE	2  WRONG LOCATION	3  INCOMPLETE ISOLATION	4  SIMULTANEOUS WORK
5  EXPIRED PERMIT	6  SHIFT HANDOVER	7  CHANGED CONDITION	8  EARLY START

CRITICAL VALUES TO VERIFY IN THE FIELD

100% Joint field verification before work	Every change Suspend and reassess the permit	Job complete Site check and formal close-out
--	---	---



REMEMBER - SERNEM

S

Stop and think

E

Evaluate the risk

R

Remove or reduce

N

Never assume

E

Ensure protection

M

Monitor and communicate

PERMIT TO WORK SYSTEM

Jointly verify scope, location, simultaneous activities, isolations and critical controls before authorizing hazardous work, and safe

STANDARDS AND FIELD REQUIREMENTS

OSHA 1910.119(f)(4), 1910.119(k), 1910.147 and the site PTW procedure integrate safe work practices, hot-work authorization and energy control.

OSHA 1910.119(f)(4)

SAFE WORK PRACTICES

Use written practices for high-risk work including LOTO, confined space, process opening and access control.

OSHA 1910.119(k)

HOT-WORK PERMIT

Document that fire-prevention requirements are implemented before hot work in a covered process area.

OSHA 1910.147

ENERGY CONTROL

A permit does not replace energy isolation; authorized employees separately isolate and verify zero energy.

SAHA PTW PROSEDÜRÜ

AUTHORIZATION, HANDOVER AND CLOSE-OUT

Issuer and performing authority jointly inspect the site and record extension, suspension, shift handover and close-out.

MINIMUM EVIDENCE BEFORE START

- | | |
|---|---|
| ☐ Approved work permit | ☐ JSA / risk assessment |
| ☐ Isolation / LOTO record | ☐ Gas-test records |
| ☐ SIMOPS coordination record | ☐ Suspension / handover / close-out record |

SUPERVISOR DISCUSSION POINTS

- Does the permit scope exactly match field work?
- Which change will make us stop work?
- Who will close the permit, and how?

JOINT FIELD VERIFICATION AND AUTHORIZATION



Scope - Isolation - Gas test - SIMOPS - Briefing - Close-out

PERMIT TO WORK SYSTEM

Jointly verify scope, location, simultaneous activities, isolations and critical controls before authorizing hazardous work, and safe

CRITICAL CONTROL MEASURES (HIERARCHY OF CONTROLS)

1. ELIMINATE HAZARDOUS WORK

First consider de-energized, closed-system or lower-risk methods.

2. ISOLATE AND SEGREGATE

Isolate every energy source and physically segregate the work from other activities and traffic.

3. VERIFY THE PERMIT IN THE FIELD

Jointly verify scope, crew, equipment, gas test, weather, rescue and critical controls at the job site.

4. MANAGE CHANGE AND CLOSE-OUT

Stop when conditions change; formalize handover, suspension and end-of-job site return.

CRITICAL WARNING



A signed permit alone does not make the site safe. If scope, location or conditions differ, do not start; suspend and reauthorize.

SITE CHECKLIST (BEFORE STARTING WORK)

- | | |
|---|---|
| ☐ Scope clear | ☐ Site jointly inspected |
| ☐ Isolations verified | ☐ Gas test valid |
| ☐ SIMOPS checked | ☐ Rescue ready |
| ☐ Time / shift valid | ☐ Crew briefed |
| ☐ Close-out understood | |



PERMIT TO WORK SYSTEM

Jointly verify scope, location, simultaneous activities, isolations and critical controls before authorizing hazardous work, and safe

ATTENDANCE AND APPROVAL

Project / Site: _____ Date: _____

Presented by: _____ Work area: _____

No	Full Name	Company / Role	Signature
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			