

SIMULTANEOUS OPERATIONS (SIMOPS)

Identify how maintenance, lifting, hot work, commissioning, vehicle and production activities interact in the same area; segregate

PURPOSE AND SCOPE

Identify how maintenance, lifting, hot work, commissioning, vehicle and production activities interact in the same area; segregate conflicts and establish one coordination system.

KEY HAZARDS

1  CONFLICTING WORK	2  OVERLAPPING WORK	3  IGNITION SOURCE	4  PEOPLE UNDER LOAD
5  VEHICLE TRAFFIC	6  ENERGIZATION	7  LOST COMMUNICATION	8  CHANGED PLAN

CRITICAL VALUES TO VERIFY IN THE FIELD

1 Single SIMOPS coordinator for the area	100% Pre-shift permit/work matrix review	0 Unapproved plan change
--	--	--



REMEMBER - SERNEM

S

Stop and think

E

Evaluate the risk

R

Remove or reduce

N

Never assume

E

Ensure protection

M

Monitor and communicate

SIMULTANEOUS OPERATIONS (SIMOPS)

Identify how maintenance, lifting, hot work, commissioning, vehicle and production activities interact in the same area; segregate

STANDARDS AND FIELD REQUIREMENTS

OSHA 1910.119(f)(4), 1910.119(h) and the site SIMOPS procedure integrate safe work practices, contractor coordination, permit matrices and area control.

OSHA 1910.119(f)(4)

SAFE WORK PRACTICES

Coordinate hot work, entry, line opening and energy control in process areas through written practices.

OSHA 1910.119(h)

CONTRACTOR COORDINATION

Employer and contractors mutually communicate process hazards, emergencies and performance expectations.

OSHA 1926.20(b)

PROGRAM AND INSPECTION

Competent persons regularly inspect the site, materials and equipment and stop until deficiencies are corrected.

SAHA SIMOPS MATRISI

CONFLICT DECISION

Classify work pairs as compatible, conditional or prohibited and build time/space separation into the shift plan.

MINIMUM EVIDENCE BEFORE START

- | | |
|--|---|
| ☐ Daily SIMOPS matrix | ☐ Area layout / barrier plan |
| ☐ Permit register | ☐ Shared-isolation list |
| ☐ Shift coordination record | ☐ Change / stop-work record |

SUPERVISOR DISCUSSION POINTS

- Which two jobs interact most today?
- Who stops when lifting or energization starts?
- Whom do we call when unplanned work appears?

FIELD SIMOPS MATRIX, SEGREGATION AND SINGLE COORDINATION



Permit matrix - Time - Space - Barrier - Radio - Stop-work

SIMULTANEOUS OPERATIONS (SIMOPS)

Identify how maintenance, lifting, hot work, commissioning, vehicle and production activities interact in the same area; segregate

CRITICAL CONTROL MEASURES (HIERARCHY OF CONTROLS)

1. DEFER CONFLICTING WORK

Move work that need not be simultaneous to another shift or day.

2. SEPARATE TIME AND SPACE

Separate lifting, hot work, vehicles, energization and entry by barriers, distance and time windows.

3. USE ONE PERMIT MATRIX

Review every permit in one view and verify shared isolations and interactions with accountable persons.

4. SHARED COMMUNICATION AND STOP-WORK

Use one radio plan, shift meeting and explicit stop-work authority; reapprove changes.

CRITICAL WARNING



A valid permit can be made unsafe by adjacent work. Stop all affected work when a conflict or unplanned activity appears.

SITE CHECKLIST (BEFORE STARTING WORK)

- | | |
|--|---|
| ☐ Daily work list complete | ☐ Permit matrix reviewed |
| ☐ Conflicts classified | ☐ Areas physically separated |
| ☐ Time windows clear | ☐ Shared isolations known |
| ☐ Coordinator assigned | ☐ Communication tested |
| ☐ Change process understood | |



SIMULTANEOUS OPERATIONS (SIMOPS)

Identify how maintenance, lifting, hot work, commissioning, vehicle and production activities interact in the same area; segregate

ATTENDANCE AND APPROVAL

Project / Site: _____ Date: _____

Presented by: _____ Work area: _____

No	Full Name	Company / Role	Signature
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			