HSE FIELD GUIDE | SERNEM PRO SERIES | SITE VALIDATION REQUIRED

SERNEM

HEALTH AND SAFETY RESOURCES

WORKING AT HEIGHT CRITICAL SAFETY RULES

PLAN • PRIORITIZE COLLECTIVE PROTECTION • PREVENT FALLS

OSHA 1926.501 / 1926.502 | OSHA · US SCOPE | VERIFY LOCAL REQUIREMENTS SEPARATELY

DOCUMENT

SRN-WAH-001

Revision 2.0

EN

SCAN

Open the digital poster library

SERNEM PRE-JOB CONTROL
CHECK BEFORE STARTING

PRE-JOB CHECK

- ✓ WORK PERMIT
- ✓ RISK ASSESSMENT
- ✓ COLLECTIVE PROTECTION
- ✓ APPROVED ANCHORAGE
- ✓ FALL CLEARANCE
- ✓ RESCUE PLAN
- ✓ WEATHER AND DROP ZONE

01 — MANDATORY
PRE-WORK PLANNING

- Verify the risk assessment and work permit.
- Define the safe access and work method.
- Barricade the area below and prevent unauthorized access.

02 — MANDATORY
USE COLLECTIVE PROTECTION

- Use guardrails, platforms or suitable scaffolds first.
- Protect openings with secure covers or barriers.
- Do not start if collective protection is incomplete.

03 — MANDATORY
FULL BODY HARNESS

- Inspect webbing, stitching and labels before every use.
- Wear, fasten and adjust the harness correctly.
- Remove damaged or fall-arrested equipment from service.

04 — MANDATORY
APPROVED ANCHORAGE

- Connect only to a designated and approved anchorage.
- Verify anchorage capacity against the qualified design and manufacturer instructions.
- Select an anchorage above head level whenever possible.

05 — WARNING
FALL CLEARANCE

- Calculate free-fall and total clearance distance.
- Prevent contact with lower levels or obstructions.
- Minimize the risk of a swing fall.

06 — MANDATORY
SAFE ACCESS

- Use inspected access equipment suitable for the task.
- Maintain three-point contact on ladders.
- Keep access routes clear, stable and unobstructed.

07 — WARNING
PREVENT DROPPED OBJECTS

- Secure tools using a suitable tethering system.
- Store materials safely away from edges.
- Isolate the area below and control access.

08 — INFORMATION
RESCUE READINESS

- Prepare a workable rescue plan before starting.
- Ensure rescue equipment and trained personnel are available.
- Verify emergency communication and response arrangements.

CRITICAL STOP CRITERIA
STOP WORK NOW

STOP

- ✖ THERE IS NO APPROVED ANCHORAGE OR FALL PROTECTION
- ✖ THE HARNESS, LANYARD OR CONNECTOR IS DAMAGED
- ✖ AN UNPROTECTED EDGE OR OPEN HOLE IS PRESENT
- ✖ NO RESCUE PLAN OR RESPONSE CAPABILITY IS AVAILABLE
- ✖ WIND, ICE OR VISIBILITY CONDITIONS ARE UNSAFE

TECHNICAL CONTROL
CRITICAL CONTROLS

COLLECTIVE — GUARDRAILS AND PLATFORMS FIRST

ANCHOR — COMPETENT DESIGN AND COMPATIBILITY

CLEARANCE — PREVENT LOWER-LEVEL CONTACT

RESCUE — PREPARE BEFORE WORK

TECHNICAL REFERENCE · VALIDATION REQUIRED

OSHA 1926.501 / 1926.502

Verify source scope and local requirements

PERSONAL PROTECTIVE EQUIPMENT
RISK-BASED PPE SELECTION

- CHIN-STRAP HELMET — HEAD AND CHIN-STRAP FIT
- SAFETY GLASSES — EYE PARTICLE HAZARD
- WORK GLOVES — GRIP AND MECHANICAL RISK
- SLIP-RESISTANT FOOTWEAR — SLIP-RESISTANT SOLE
- FULL BODY HARNESS — COMPATIBLE FALL SYSTEM

SELECT PPE BY RISK, MANUFACTURER AND SITE PROCEDURE; THIS LIST IS NOT MANDATORY FOR EVERY TASK.

SERNEM

Better Safety, Better Tomorrow.

STOP WORK IF IT IS UNSAFE!

VERIFY SITE PROCEDURE

www.sernem.com