information. Accept & Close Read More

Using hardware and software to make new stuff

Search

type, hit enter

Categories

- 3D Printing (1)
- Affinity Photo (1)
- Aide-memoir (1)
- <u>Analog</u> (1)
- Ansible (3)
- Dates to Remember (3)
- <u>Docker</u> (1)
- Electronics (144)
- <u>ESP8266</u> (12)
- <u>FPGA</u> (4)
- o Garden (1)
- o General (8)
- Home Built CPU (6)
- <u>Informatica</u> (1)
- Internet of Things (8)
- <u>iOS</u> (2)
- <u>KiCad</u> (4)
- o MSP430 (2)
- <u>Netduino</u> (49)
- <u>NuttX</u> (9)
- Photography (3)
- <u>Pico</u> (10)
- Raspberry Pi (17)
- Silverlight (6)
- Software Development (88)
- <u>STM32</u> (5)
- o <u>STM8</u> (54)
- <u>Tips</u> (5)

Archives

- o July 2024
- o June 2024
- May 2024
- o April 2024
- o March 2024
- February 2024
- January 2024
- o December 2023
- November 2023
- o October 2023

information. Accept & Close Read More

- ~ <u>лүш 2023</u>
- February 2020
- January 2020
- o <u>July 2019</u>
- o February 2018
- July 2017
- June 2017
- April 2017
- March 2017
- February 2017
- October 2016
- September 2016
- July 2016
- o June 2016
- May 2016
- April 2016
- March 2016
- o January 2016
- o December 2015
- November 2015
- o October 2015
- <u>August 2015</u>
- <u>June 2015</u>
- o May 2015
- o April 2015
- March 2015
- February 2015
- January 2015
- o December 2014
- October 2014
- September 2014
- <u>August 2014</u>
- <u>July 2014</u>
- June 2014
- o <u>May 2014</u>
- March 2014
- February 2014
- o January 2014
- December 2013
- November 2013
- o October 2013
- September 2013
- <u>August 2013</u>
- o <u>July 2013</u>
- o June 2013
- <u>May 2013</u>
- April 2013
- March 2013
- <u>January 2013</u>
- November 2012
- o October 2012
- September 2012
- August 2012
- July 2012
- o June 2012
- o May 2012

information. Accept & Close Read More

```
    September 2011
    July 2011
    June 2011
    May 2011
    April 2011
    March 2011
    February 2011
    January 2011
    December 2010
    April 2010
```

Single Pulse Generation with the STM8S

I have recently been looking at using a sensor which uses a one-wire communication protocol. The protocol uses a single pulse of a defined length to trigger the unit to send the sensor reading back down the same wire. This lead me on to thinking about how I could achieve this, the results of which are documented here.

Whilst the main purpose of the code we will be developing in this post remains the same, i.e. to produce a single pulse of a defined length, I felt it important to show the two fundamental ways in which this can be achieved:

- Interrupts and GPIO
- Timers

Much of the first method, using interrupts and GPIO signals is a relatively straight forward case of modifying one of the previous examples, namely <u>Using Timers on the STM8S</u>.

The second method is more interesting as we look at using Timers to solve this problem. This will start us looking at using Timer 1. This is probably the most flexible and powerful of the Timers on the STM8S. This power and flexibility comes with a price, it is also the most complex of the timers we have at our disposal.

As an aside, we will look at measuring the length of the pulses we can generate with the aim of defining the minimum pulse length we can create using each of the methods.

So let's start with a common problem definition. We will use both methods to generate a single pulse lasting 30 uS.

Method 1 – Interrupts and GPIO

This method requires only slight modifications to the code presented in <u>Using Timers on the STM8S</u>. So let's start by downloading the example and modifying the code.

The first thing we will need to do is to modify the duration of the timer in order to generate and interrupt every 30 uS. In the original program we setup Timer 2 as follows:

```
1
 2
        Setup Timer 2 to generate a 20 Hz interrupt based upon a 16 MHz timer.
 3
     //
 4
     void SetupTimer2()
 5
 6
         TIM2 PSCR = 0x03;
                                       Prescaler = 8.
 7
         TIM2 ARRH = 0xc3;
                                       High byte of 50,000.
                                  //
 8
         TIM2 ARRL = 0x50;
                                       Low byte of 50,000.
                                  //
         TIM2_IER_UIE = 1;
 9
                                  //
                                       Enable the update interrupts.
10
                                       Finally enable the timer.
         TIM2 CR1 CEN = 1;
```

information. Accept & Close Read More

```
(2^{11INI2} - ^{PSCK} * counter) = f_{master} / f_{interrupt}
```

Now we are looking at generating a high frequency (low duration) pulse and so it is not unreasonable to set the prescalar to 1 (i.e. $TIM2_PSCR = 0$). This simplifies the formula to:

```
counter = f_{master} / f_{interrupt}
```

We also know that $f_{interrupt}$ is given by the following formula:

```
f_{interrupt} = 1 / pulse duration
```

Putting the two together gives:

```
counter = f_{master} * pulse duration

counter = 16,000,000 * 30 * 10^{-6}

counter = 480 (0x1e0)
```

So our code becomes:

```
1
 2
         Setup Timer 2 to generate an interrupt every 480 clock ticks (30 uS).
 3
 4
     void SetupTimer2()
 5
 6
         TIM2 PSCR = 0 \times 00;
                                   //
                                        Prescaler = 1.
 7
         TIM2 ARRH = 0 \times 01;
                                        High byte of 480.
                                   //
 8
         TIM2 ARRL = 0xe0;
                                        Low byte of 480.
 9
                                   // Turn on the interrupts.
         TIM2 IER UIE = 1;
                                   // Finally enable the timer.
         TIM2 CR1 CEN = 1;
10
     }
11
```

If you hook up oscilloscope and deploy the code you should find that the STM8S is generating square wave on Post D, Pin 5. The frequency of the signal should be 60 uS (see the previous article for an explanation where this comes from) with a duty cycle of 50%. Each of the components should have a width of 30 uS.

The next thing we need to do is to make the system generate a single pulse instead of a square wave. The solution is shockingly simple; in this case we turn off the timer interrupt after the first pulse has been generated.

The code in the Interrupt Service Routine (ISR) currently looks like this:


```
1
    //
2
        Timer 2 Overflow handler.
    //
3
4
    #pragma vector = TIM2 OVR UIF vector
5
      interrupt void TIM2 UPD OVF IRQHandler(void)
6
        PD_ODR_ODR4 = !PD_ODR_ODR4;
7
                                         // Toggle Port D, pin 4.
8
        TIM2 SR1 UIF = 0;
                                              Reset the interrupt otherwise it will
9
    }
```

information. Accept & Close Read More

```
1
     //
2
         Timer 2 Overflow handler.
 3
     #pragma vector = TIM2_OVR UIF vector
4
5
       _interrupt void TIM2_UPD_OVF_IRQHandler(void)
6
7
         unsigned char data;
8
9
         data = PD ODR ODR4;
                                           // Toggle Port D, pin 5.
10
         PD ODR ODR4 = !data;
         if (data == 1)
11
12
                                               Only allow the pulse to happen once.
13
             TIM2 IER UIE = 0;
14
         TIM2 SR1 UIF = 0;
15
                                               Reset the interrupt otherwise it will
     }
16
```

This method turns off the Timer 2 interrupt and only the Timer 2 interrupt but resetting the interrupt enable flag for Timer 2 (*TIM2_IER_UIE* = 0). We could have called __disable_interrupt() here but this would have turned off all interrupts.

Deploying this code results in the following output on the oscilloscope:



And just to prove that the application generated a single pulse I hooked up the logic analyser and set this up to capture over 10 seconds worth of data. This resulted in the following output:



As you can see, we have what looks like a single pulse (see the logic analyser output). Zooming in on the pulse on the logic analyser output confirmed that there is indeed only a single pulse. A quick check of the oscilloscope output confirmed that the duration of the pulse is 30 uS.

Method 2 – Timers and PWM

In <u>Generating PWM Signals using the STM8S</u> we saw how we can generate a PWM signal without having to use interrupts. Here we will extend the principle to generating a single pulse using the *One Pulse Mode (OPM)* feature of Timer 1 (note that OPM is not available on Timer 2). As with the above, we will do this is two stages, namely to generate a PWM signal and then to restrict the output to a single pulse.

So let's start by looking at Timer 1 and what we will need for this example.

TIM1_ARRH & TIM1_ARRL – Timer 1 Auto Reload Registers

As with Timer 2, these are two 8-bit registers which when combined make up the 16-bit counter value. To reset the 16-bit value we need to write to TIM1 ARRH before writing to TIM ARRL as writing to TIM1 ARRL

information. Accept & Close Read More

This is a 16-bit register and allows tiner control over the prescalar than we had with Timer 2. In this case the value can be any value from 0 to 65535. The frequency of the counter ($f_{counter}$) is given by the following frequency:

$$f_{counter} = f_{master} / (Prescalar + 1)$$

This means that the range of the divisor used is actually 1 to 65536.

As with the auto-reload register, we should load the high bits before the low bits (i.e. TIM1_PSCRH before TIM1_PSCRL).

TIM1_RCR - Timer 1 Repetition Counter

The repetition counter allows for the timer to generate update events only when a number of repetitions of the counter underflow and overflow have occurred. This is a topic which is outside of the scope of this example and so we will set this to 0 for the moment and return to this topic in future examples.

TIM1_CR1 – Timer 1 Control Register 1

We will be ensuring that two bits in this register are set; namely TIM1 CR1 DIR and TIM1 CR1 CMS.

TIM1_CR1_DIR controls the direction of the counter as counter 1 can count from 0 upwards or from TIM_ARR down to 0. Setting this value to 0 means count upwards whilst 1 means count downwards.

TIM1_CR1_CMS determines the counter alignment. For this example we will be using edge aligned counting and will be setting this to 0. Note that this value is a two bit value and the meaning of the remaining values is left for a future discussion.

TIM1 CCRM4 - Timer 1 Capture/Compare Mode Register 4

As with Timer 2, we can control the PWM mode setting this to either mode 1 or mode 2. We will configure this channel to be operating in PWM mode 2. In this mode OC3 will be inactive as long as the counter < TIM1 CCR3.

TIM1_CCR4H & TIM1_CCR4L – Timer 1 Capture Compare Register 4

These registers together form a 16-bit value for use in Capture/Compare/PWM mode. In PWM mode, these values coupled with the TIM1 ARR registers will allow control of the duty cycle of a PWM signal.

TIM1 CCER2 – Timer 1 Capture/Compare Register 2

This register determines the output polarity and availability of Timer 1, channel 4 (amongst other things). The bits we are really interested in are the availability and the polarity of the output.

TIM1 CCER2 CC4E determines if the output is enabled or disabled; 0 is disabled, 1 is enabled.

TIM2_CCER2_CC4P determines the polarity of the active stage of the output. A polarity of 0 means that the active stage gives a high (logic 1) output, whilst a polarity of 1 gives a low (logic 0) output.

Software

So if we put all of this together we get an application which looks something like this:

information. Accept & Close Read More

```
5
     // This software is provided under the CC BY-SA 3.0 licence. A
         copy of this licence can be found at:
6
     //
7
     11
8
     // http://creativecommons.org/licenses/by-sa/3.0/legalcode
9
     //
     #if defined DISCOVERY
10
11
         #include <iostm8S105c6.h>
12
     #elif defined PROTOMODULE
13
         #include <iostm8s103k3.h>
14
     #else
15
         #include <iostm8s103f3.h>
16
     #endif
17
     #include <intrinsics.h>
18
19
     //
     // Setup the system clock to run at 16MHz using the internal oscillator.
20
21
     //
22
     void InitialiseSystemClock()
23
     {
24
         CLK ICKR = 0;
                                              // Reset the Internal Clock Register
                                              // Enable the HSI.
25
         CLK_ICKR_HSIEN = 1;
26
                                              // Disable the external clock.
         CLK ECKR = 0;
         while (CLK ICKR HSIRDY == 0);
                                              // Wait for the HSI to be ready for
27
                                              //
28
         CLK CKDIVR = 0;
                                                  Ensure the clocks are running at
                                              //
29
         CLK_PCKENR1 = 0xff;
                                                  Enable all peripheral clocks.
                                              // Ditto.
30
         CLK \ PCKENR2 = 0xff;
31
         CLK CCOR = 0;
                                              // Turn off CCO.
                                              // Turn off any HSIU trimming.
32
         CLK HSITRIMR = 0;
                                              // Set SWIM to run at clock / 2.
33
         CLK_SWIMCCR = 0;
                                             // Use HSI as the clock source.
34
         CLK SWR = 0xe1;
35
         CLK SWCR = 0;
                                             // Reset the clock switch control re
                                           // Enable switching.
// Pause while the clock switch is t
36
         CLK SWCR SWEN = 1;
37
         while (CLK SWCR SWBSY != 0);
38
     }
39
     //
40
41
     // Set up Timer 1, channel 4 to output a single pulse lasting 30 uS.
42
     //
43
     void SetupTimer1()
44
     {
45
                                 // Reload counter = 960
         TIM1 ARRH = 0 \times 03;
46
         TIM1 ARRL = 0xc0;
         TIM1_PSCRH = 0;
                                 // Prescalar = 0 (i.e. 1)
47
48
         TIM1 PSCRL = 0;
49
         TIM1 CR1 DIR = 0;
                                 //
                                      Up counter.
                                 //
         TIM1 CR1 CMS = 0;
50
                                     Edge aligned counter.
51
         TIM1 RCR = 0;
                                 //
                                      No repetition.
52
         //
53
         //
            Now configure Timer 1, channel 4.
54
         //
55
         TIM1 CCMR4 OC4M = 7;
                                 //
                                     Set up to use PWM mode 2.
56
         TIM1 CCER2 CC4E = 1;
                                 //
                                      Output is enabled.
57
         TIM1 CCER2 CC4P = 0;
                                 //
                                     Active is defined as high.
                                 // 480 = 50% duty cycle (based on TIM1_ARR).
58
         TIM1 CCR4H = 0 \times 01;
59
         TIM1 CCR4L = 0xe0;
60
         TIM1 BKR MOE = 1;
                                 //
                                      Enable the main output.
61
```

information. Accept & Close Read More

```
67
68
     //
69
     //
         Main program loop.
70
     //
71
     void main()
72
     {
73
              Initialise the system.
74
         //
75
76
           disable interrupt();
77
         InitialiseSystemClock();
78
         SetupTimer1();
79
            _enable_interrupt();
80
         while (1)
81
         {
               wait for interrupt();
82
83
          }
84
     }
```

If we run this application and hook up the oscilloscope to Timer 1, channel 4 (Pin 13 on the STM8S103F3 TSSOP20 package) we should find we get a PWM signal with a 60 uS period and a 50% duty cycle.

Timers and One Pulse Mode

Now that we have PWM functioning as expected we really only have to make one minor code modification, namely to set the timer generating a single pulse. For this we only need to add one line of code to the above application, SetupTimer1 becomes:

```
1
     //
2
         Set up Timer 1, channel 4 to output a single pulse lasting 30 uS.
3
4
     void SetupTimer1()
 5
     {
                                       Reload counter = 960
6
         TIM1 ARRH = 0x03;
7
         TIM1 ARRL = 0xc0;
8
         TIM1 PSCRH = 0;
                                       Prescalar = 0 (i.e. 1)
9
         TIM1 PSCRL = 0;
         TIM1 CR1 DIR = 0;
10
                                       Up counter.
11
         TIM1_CR1_CMS = 0;
                                       Edge aligned counter.
12
                                  //
                                       No repetition.
         TIM1 RCR = 0;
13
         //
14
         //
             Now configure Timer 1, channel 4.
15
         //
16
         TIM1 CCMR3 OC3M = 7;
                                  //
                                       Set up to use PWM mode 2.
17
         TIM1_CCER2_CC3E = 1;
                                  //
                                      Output is enabled.
         TIM1_CCER2_CC3P = 1;
                                  //
                                       Active is defined as high.
18
19
         TIM1_CCR3H = 0x01;
                                  //
                                      480 = 50% duty cycle (based on TIM1_ARR).
20
         TIM1 CCR3L = 0xe0;
         TIM1_BKR_MOE = 1;
                                       Enable the main output.
21
                                  //
22
         TIM1_CR1_OPM = 1;
                                       Enable single pulse mode.
                                  //
23
         TIM1 CR1 CEN = 1;
24
     }
```

information. Accept & Close Read More

this is the first or seconded invocation of the ISR. The second is really only restricted by the speed of the system clock. This does not mean we cannot experiment to determine which is faster.

In both cases the programs were modified changing the timer auto-reload registers and the capture compare registers. The auto-reload register was always set to a value twice that of the capture compare register. For the interrupt method the fastest pulse which could be achieved was in the order of 2.5 uS (ARR = 0x0004) whilst the OPM method resulted in a pulse width of 146 nS (TIM1_ARR = 0x0002).

Conclusion

In this article we have looked at two methods which we can use to generate a single pulse. I am not offering advice on which is better, I'll leave this to you as the application developer to decide.

Hopefully you will have gained an appreciation of the power of Timer 1. You should also have realised that using Timer 1 is not as simple as using Timer 2. There are a number of features we have not touched upon including (but not restricted to):

- Capture/Compare
- PWM Modes
- Timer synchronisation

I am sure that we shall return to Timer 1 in future posts.

As always, the source code is available for <u>download</u>.

Source Code Compatibility

System Compatible?

STM8S103F3 (Breadboard)

STM8S Discovery

Tags: Electronics, Software Development, STM8

Monday, September 3rd, 2012 at 7:55 pm • Electronics, Software Development, STM8 • RSS 2.0 feed Both comments and pings are currently closed.

Comments are closed.


Pages

- About
- Making a Netduino GO! Module
- The Way of the Register
- Making an IR Remote Control
- Weather Station Project
- NuttX and Raspberry Pi PicoW

Support This Site



This website uses cookies to improve your experience and to gather page view statistics. This site does not collect user information. Accept & Close Read More



© 2010 - 2024 Mark Stevens