information. Accept & Close Read More

# Using hardware and software to make new stuff

## Search

type, hit enter

# **Categories**

- 3D Printing (1)
- Affinity Photo (1)
- Aide-memoir (1)
- <u>Analog</u> (1)
- Ansible (3)
- <u>Dates to Remember</u> (3)
- <u>Docker</u> (1)
- Electronics (144)
- <u>ESP8266</u> (12)
- <u>FPGA</u> (4)
- o Garden (1)
- o General (8)
- Home Built CPU (6)
- <u>Informatica</u> (1)
- Internet of Things (8)
- <u>iOS</u> (2)
- <u>KiCad</u> (4)
- o MSP430 (2)
- <u>Netduino</u> (49)
- <u>NuttX</u> (9)
- Photography (3)
- <u>Pico</u> (10)
- Raspberry Pi (17)
- Silverlight (6)
- Software Development (88)
- <u>STM32</u> (5)
- o <u>STM8</u> (54)
- <u>Tips</u> (5)

#### **Archives**

- o July 2024
- o June 2024
- May 2024
- o April 2024
- March 2024
- February 2024
- o January 2024
- o December 2023
- November 2023
- o October 2023

information. Accept & Close Read More

- <u>лрш ∠∪∠Ј</u>
- February 2020
- <u>January 2020</u>
- July 2019
- February 2018
- <u>July 2017</u>
- <u>June 2017</u>
- April 2017
- March 2017
- February 2017
- October 2016
- September 2016
- July 2016
- o June 2016
- May 2016
- April 2016
- March 2016
- <u>January 2016</u>
- December 2015
- November 2015
- October 2015
- <u>August 2015</u>
- June 2015
- o May 2015
- o April 2015
- March 2015
- February 2015
- <u>January 2015</u>
- o December 2014
- October 2014
- September 2014
- <u>August 2014</u>
- <u>July 2014</u>
- <u>June 2014</u>
- o <u>May 2014</u>
- March 2014
- February 2014
- o January 2014
- o December 2013
- November 2013
- o October 2013
- September 2013
- <u>August 2013</u>
- o July 2013
- June 2013
- o May 2013
- <u>April 2013</u>
- March 2013
- <u>January 2013</u>
- November 2012
- o October 2012
- September 2012
- <u>August 2012</u>
- o July 2012
- June 2012
- o May 2012

information. Accept & Close Read More

- September 2011
- <u>July 2011</u>
- o June 2011
- May 2011
- April 2011
- o March 2011
- February 2011
- o January 2011
- o December 2010
- April 2010

## STM8S SPI Slave (Part 2)

In the <u>previous post</u> we looked at exchanging single bytes using SPI with a Netduino Plus acting as the SPI master device and the STM8S acting as a slave device. The code presented suffered from a few deficiencies:

- We could only exchange one byte and that was mirrored back to the master device
- The mirroring assumed that a byte received meant the STM8S was ready to send a byte back to the Netduino

In this post we will deal with both of these issues and also look at a new problem which can arise, namely synchronisation.

The aim of the code we will be developing is to receive a buffer of data and at the same time send a different buffer of data back to the master device.

## Hardware

The hardware we will be using is identical to the initial SPI post. We will be using a few more bits from the registers in order to allow the STM8S application to determine the action we should be taking.

### SPR SR OVR - Overflow Indicator

This bit will be set when the chip detects an overflow condition. This can happen if the bus speed is too high and the data is arriving at a rate which is faster than the Interrupt Service Routine (ISR) can process it.

#### SPI\_SR\_RXNE – Receive Buffer Not Empty

This bit indicates that the receive buffer is not empty and that data is ready to be read.

#### SPI SR TXE – Transmit Buffer Empty

This indicates that the SPI transmit buffer is empty and ready to receive another byte of data.

#### Netduino Plus Software

The software running on the Netduino Plus requires a small modification to allow it to send a buffer of data rather than a single byte. We will also take the opportunity to increase the SPI bus speed to 500KHz. The code running on the Netduino Plus becomes:

```
public class Program
```

information. Accept & Close Read More

```
8
         /// <summary>
         /// Configuration of the SPI port.
 9
10
         /// </summary>
         private static SPI.Configuration config = null;
11
12
13
         public static void Main()
14
              config = new SPI.Configuration(SPI_mod: SPI.SPI_module.SPI1,
15
                                               ChipSelect Port: Pins.GPIO PIN D10,
16
                                               ChipSelect_ActiveState: false,
17
18
                                               ChipSelect SetupTime: 0,
19
                                               ChipSelect HoldTime: 0,
20
                                               Clock_IdleState: false,
21
                                               Clock_Edge: true,
22
                                               Clock RateKHz: 500);
23
              spi = new SPI(config);
24
25
              byte[] buffer = new byte[17];
              for (byte index = 0; index < 17; index++)</pre>
26
27
28
                  buffer[index] = index;
29
              }
30
              while (true)
31
                  for (byte counter = 0; counter < 255; counter++)</pre>
32
33
34
                      buffer[0] = counter;
35
                      spi.Write(buffer);
36
                      Thread.Sleep(200);
37
                  }
38
             }
39
         }
40
     }
```

As you can see, much of the code is the same as that presented in the previous nost. This application will now than sinit a 17 byte outlet to the 511 stave device. The first byte in the outlet will be a sequence number which will cycle through the values 0 to 254. The remaining bytes in the buffer will remain unchanged.

#### STM8S SPI Slave

The main changes we will be making are in the application running on the STM8S. In this case we need to deal with the following additional issues:

- Possible overflows due to the increased speed of the SPI bus
- Treating the receive and transmit scenarios as distinct cases
- Buffer overflows

The first thing we are going to need is somewhere to store the data. Looking at the Netduino Code we have defined the buffer size as 17 bytes. The corresponding declaration in the STM8S code look like this:

information. Accept & Close Read More

```
9
         Application global variables.
     //
10
     unsigned char _rxBuffer[BUFFER_SIZE];
                                                  // Buffer holding the received da
11
     unsigned char txBuffer[BUFFER SIZE];
12
                                                  // Buffer holding the data to ser
     unsigned char * rx;
13
                                                  // Place to put the next byte rec
14
     unsigned char * tx;
                                                  // Next byte to send.
15
     int rxCount;
                                                  // Number of characters received.
                                                  // Number of characters sent.
16
     int _txCount;
```

We will also need to provide a mechanism to reset the SPI buffer pointers back to a default state ready to receive data:

```
-----
1
2
    //
3
    //
        Reset the SPI buffers and pointers to their default values.
4
5
    void ResetSPIBuffers()
6
7
        SPI DR = 0xff;
        _rxCount = 0;
8
9
        _txCount = 0;
10
        rx = rxBuffer;
        _tx = _txBuffer;
11
    }
12
```

We also no longer have a single byte of data to output on the diagnostic pins. We therefore need to add a new diagnostic method to output the data we are receiving.

```
1
 2
     //
        Bit bang a buffer of data on the diagnostic pins.
 3
     //
 4
 5
     void BitBangBuffer(unsigned char *buffer, int size)
 6
 7
         for (int index = 0; index < size; index++)</pre>
 8
              BitBang(buffer[index]);
 9
10
     }
11
```

The main method needs to be modified to take into account the changes we have made. The code becomes:

```
int main(void)
1
2
    {
3
        //
4
            Initialise the system.
5
6
          disable interrupt();
7
        InitialiseSystemClock();
8
        InitialiseSPIAsSlave();
9
        ResetSPIBuffers();
```

information. Accept & Close Read More

```
_status = SC_UNKNOWN;
15
16
           enable interrupt();
17
         //
18
         //
             Main program loop.
19
         //
20
         while (1)
21
22
                wait for interrupt();
              if ( status == SC RX BUFFER FULL)
23
24
25
                  BitBangBuffer( rxBuffer, BUFFER SIZE);
26
27
              status = SC UNKNOWN;
28
         }
29
     }
```

So far all of the code changes have been to support the initialisation and configuration of the system. The one area we have not touched upon is processing of the data which is being transmitted / received, namely the SPI ISR.

#### **SPI Interrupt Service Routine**

For the application we have built so far, the ISR must take into account three possible scenarios:

- Buffer Overflow
- Data received
- Data transmission buffer empty

The code will utilise the three status we identified earlier in order to determine which action to take. In each case we will do the following:

- SPI Overflow (SPI\_SR\_OVR is set)
  Use the status codes to indicate an overflow has occurred and exit the ISR
- Data Received (SPI\_SR\_RXNE is set)
  Add the byte received to the buffer and update the buffer pointers. Set the status code to indicate that we have received some data.
- Data transmission buffer empty (SPI\_SR\_TXNE is set)
  Grab the next byte from the transmit buffer and send it. Update the transmit buffer pointers accordingly.

We will be adopting a naïve buffering solution for this application. The buffers will be circular. The ISR can assume that there is space to save the next byte (i.e. we never overflow) as when we reach the end of the buffer we simply set the pointer back to the start again. The code for the ISR becomes:

```
1
     #pragma vector = SPI TXE vector
 2
       interrupt void SPI IRQHandler(void)
 3
 4
         //
 5
             Check for an overflow error.
         //
 6
         //
 7
         if (SPI SR OVR)
 8
 9
              (void) SPI DR;
                                                    // These two reads clear
              (void) SPI SR;
                                                    // error.
10
             _status = SC_OVERFLOW;
11
             OutputStatusCode( status);
```

information. Accept & Close Read More

```
(SPI SR RXNE)
18
19
20
              //
                  We have received some data.
21
              //
22
23
              * rx = SPI DR;
                                                 Read the byte we have receiv
24
              _rx++;
25
               rxCount++;
26
              if ( rxCount == BUFFER_SIZE)
27
28
                   status = SC RX BUFFER FULL;
29
                  OutputStatusCode(_status);
                  _rx = _rxBuffer;
30
31
                  _{rx}Count = 0;
32
33
          }
if (SPI_SR_TXE)
34
35
36
              //
37
              //
                  The master is ready to receive another byte.
38
              //
39
              SPI DR = * tx;
              _tx++;
40
               txCount++;
41
              if (_txCount == BUFFER_SIZE)
42
43
44
                  OutputStatusCode(SC TX BUFFER EMPTY);
                  _tx = _txBuffer;
45
                  txCount = 0;
46
47
              }
48
          }
49
     }
```

If we run these two applications and connect the logic analyser we are likely to see traces similar to the following:



SPI Slave Buffered output on Logica Analyser

This is not what we expected. In fact we expect to see something like the following:



Correctly synchronised SPI buffered output on the Logic Analyser

The reason for this is the simple buffering and we have used and the fact that there we have not implemented a method for synchronising the two systems (Netduino and STM8S). The trace can be understood if we follow the deployment and startup cycles for each application. The sequence of events will proceed something like the following:

information. Accept & Close Read More

THE APPLICATION ON THE STIMOS STATES AND WAITS TOT UATE TO DETECTIVE ON THE STIT OUS.

It is highly possible that when the application on the STM8S starts we will be part way through the transmission of a sequence of bytes by the Netduino. Let us make the assumption that this is the case and the Netduino is transmitting byte 16.

- Byte 16 transmitted by Netduino
  The byte is received by the STM8S and put into the buffer at position 0. The buffer pointers are moved on to point to position 1.
- Byte 17 is transmitted by the Netduino
  The byte is received by the STM8S and put into the buffer at position 1. The buffer pointers are moved on to point to position 2.
- Netduino enters the 200ms pause The STM8S waits for the next byte
- Byte 0 transmitted by Netduino
  The byte is received by the STM8S and put into the buffer at position 2. The buffer pointers are moved on to point to position 3.

This sequence of events continues until the buffer on the STM8S is full. As you can see, the buffers started out unsynchronised and continue in this manner ad infinitum.

Interestingly, if you power down the two boards and then power them up simultaneously (or power up the STM8S and then the Netduino Plus) you will see the synchronised trace. This happens because the STM8S has been allowed to enter the receive mode before the Netduino Plus could start to send data.

# Synchronising the Sender and Receiver

The key to the synchronisation is this case is to consider using an external signal to indicate the start of transmission of the first byte of the buffer. In theory this is what the NSS signal (chip select) is for. The STM8S does not provide a mechanism to detect the state change for the NSS line when operating in hardware mode (which is how the application has been operating so far). In order to resolve this we should consider converting the application to use software chip select mode.

### **Chip Select**

The first thing to be considered is the port we will be using to detect the chip select signal. In this case we will be using Port B, pin 0. This port will need to be configured as an input with the interrupts enabled. The *InitialisePorts* method becomes:

```
1
     void InitialisePorts()
 2
     {
 3
          //
 4
             Initialise Port D for debug output.
 5
 6
          PD ODR = 0;
                                    // All pins are turned off.
                                   // All pins are outputs.
// Push-Pull outputs.
 7
          PD DDR = 0xff;
          PD_CR1 = 0xff;
 8
 9
          PD_CR2 = 0xff;
                                   // Output speeds upto 10 MHz.
10
          //
              Initialise Port B for input.
11
          //
12
          PB ODR = 0;
13
                                    // Turn the outputs off.
         PB DDR = 0;
                                    // All pins are inputs.
14
```

information. Accept & Close Read More

```
20 EXTI_CR1_PBIS = 2; // Port B interrupt on falling 21 }
```

One point to note about the above method is that we initially only detect the falling edge of the chip select signal. My first attempt at this code had both falling and rising edge detection in place. With this method enabled I found it difficult to detect which edge was causing the interrupt to be triggered. I therefore decided to initially detect only the falling edge. I would then add code to change the edge being detected to the ISR controlling the chip select. The code which detects the change of state for the chip select pin is as follows:

```
1
     #pragma vector = 6
 2
       interrupt void EXTI PORTB IRQHandler(void)
 3
 4
          if (EXTI CR1 PBIS == 1)
 5
          {
 6
              //
 7
                  Transition from low to high disables SPI
              //
 8
              //
 9
              SPI_CR1_SPE = 0;
                                                              Disable
10
              SPI CR2 SSI = 1;
11
              EXTI CR1 PBIS = 2;
                                                              Waiting
              OutputStatusCode(SC_CS_RISING_EDGE);
12
13
          }
         else
14
15
          {
16
              //
17
                  Transition from high to low selects this slave
18
              //
19
              EXTI CR1 PBIS = 1;
                                                              Waitin
20
              ResetSPIBuffers();
21
              (void) SPI DR;
22
              (void) SPI SR;
23
              SPI DR = * tx++;
                                                              Load th
24
               txCount++;
25
              SPI CR2 SSI = 0;
26
              SPI_CR1_MSTR = 0;
                                                          // Enable 5
27
              SPI_CR1_SPE = 1;
              OutputStatusCode(SC CS FALLING EDGE);
28
29
          }
     }
30
```

This code performs two tasks:

- Falling Edge Enable SPI Resets the SPI buffers and the SPI registers ready for data transmission> Next, enable SPI. Finally, setup the chip select to detect a rising edge.
- Rising Edge Disable SPI
   Disables SPI and sets the chip select to look for a falling edge.

You will also note a few lines outputting status information. These should be removed in production code but are left in here in order to aid debugging.

information. Accept & Close Read More

```
1
     void InitialiseSPIAsSlave()
 2
     {
 3
         SPI CR1 SPE = 0;
                                                     Disable SPI.
                                                 //
 4
         SPI CR1 CPOL = 0;
                                                     Clock is low wh
                                                 //
 5
         SPI_CR1_CPHA = 0;
                                                     Sample the data
6
         SPI_ICR_TXIE = 1;
                                                 //
                                                     Enable the SPI
 7
                                                     Enable the SPI
         SPI ICR RXIE = 1;
         SPI_CR2_SSI = 0;
 8
                                                     This is SPI sla
                                                 //
                                                     Slave managemer
9
         SPI CR2 SSM = 1;
10
```

### **Conclusion**

This post shows how we can overcome the naïve data transmission method presented by the <u>previous post</u> and add the ability to buffer data and to store a buffered response. Running the final version of the code overcomes the synchronisation problem we encountered at the expense of performing out own chip select handling in software.

As usual, the source code for this application is available for download (<u>STM8S SPI Slave</u> and <u>Netduino SPI Master</u>).

#### **Source Code Compatibility**

```
System Compatible?
STM8S103F3 (Breadboard) X
Variable Lab Protomodule X
STM8S Discovery
```

Tags: Electronics, Software Development, STM8, The Way of the Register

Monday, November 19th, 2012 at 9:36 am • <u>Electronics</u>, <u>Netduino</u>, <u>STM8</u> • <u>RSS 2.0</u> feed Both comments and pings are currently closed.

Comments are closed.


# **Pages**

- About
- Making a Netduino GO! Module
- The Way of the Register
- Making an IR Remote Control
- Weather Station Project
- NuttX and Raspberry Pi PicoW

# **Support This Site**



This website uses cookies to improve your experience and to gather page view statistics. This site does not collect user information. Accept & Close Read More



© 2010 - 2024 Mark Stevens