

L1-21 / L2-21 LINE RELAY - TECHNICAL DATA (EXCERPT)

Current inputs (IA, IB, IC): nominal 5 A; continuous 15 A; 1 s thermal 500 A.

Terminals: IA Z01 (in) / Z02 (out), IB Z03 / Z04, IC Z05 / Z06. Polarity: current entering the "in" terminal is positive.

Burden: 0.04 ohm per phase, resistive ($0.04 \text{ ohm} \times (5 \text{ A})^2 = 1.0 \text{ VA}$ at nominal current).

Measuring range: 0.05 A to 100 A, linear; accuracy $\pm 1 \%$.

Voltage inputs (VA, VB, VC): nominal 67 V phase to neutral (115 V phase to phase); burden $< 0.1 \text{ VA}$.

Sampling: 32 samples per cycle, see the instruction manual for the protection algorithms.

Event storage: 4 oscillography records of 640 samples; the oldest is overwritten first.

Self-supervision: analog input channels are checked continuously for offset and saturation; a failure asserts ALARM.

BF-50 BREAKER FAILURE RELAY (NUMERICAL) - TECHNICAL DATA (EXCERPT)

Current inputs (IA, IB, IC): nominal 5 A; continuous 10 A; 1 s thermal 300 A.

Terminals: IA A1 (in) / A2 (out), IB B1 / B2, IC C1 / C2. Polarity: current entering the "in" terminal is positive.

Burden: 0.06 ohm per phase, resistive (1.5 VA at nominal current).

Function: retrip and backup trip when a phase current above the 50BF pickup persists after a breaker trip command.

Recording: the BF-50 stores operation records only (no oscillography).