


Note

RESET GND

OLED | TRRS VCC
OLED | TRRS GND
RESET

OLED SCL
OLED SDA

Trackball MT required Trackball SS
Trackball MISO
Trackball MOSI
Trackball SCK



COLUMN 0 COLUMN 1 ENCODER COL slave COLUMN 2 COLUMN 3 COLUMN 4 ENCODER COL master HAPTIC ENCODER GND COLUMN 5 ROW 0 ROW 1 ROW 2 ROW 3 ROW 4 ENCODER ROW ROW 5 TRRS Serial AUDIO GND

Trackball 3V
Trackball GND