


The Thermodynamics of Hydrate Formation and Control

Shifting flow assurance from reactive troubleshooting to proactive physical strategy.


Prepared by
Eng. Sajjad k. Hano

Gas hydrates are an architectural anomaly, not just frozen water.



Standard Ice

- **Structure:** Solid lattice with high density.
- **Bonding:** Tightly packed water molecules with minimal void space.




Gas Hydrate

- **Structure:** A crystalline network built entirely around internal void spaces.
- **Bonding:** Water framework held by chemically weak bonds, constructed specifically to trap hydrocarbon molecules.

Insight: Hydrates resemble ice or wet snow in appearance, but their internal physics exhibit properties entirely unique to pressurized chemical networks.

The Host and Guest relationship dictates the molecular trap.



Chemical Roster

Methane hydrates: $\text{CH}_4 \cdot 7\text{H}_2\text{O}$


Ethane hydrates: $\text{C}_2\text{H}_6 \cdot 8\text{H}_2\text{O}$

Propane hydrates: $\text{C}_3\text{H}_8 \cdot 18\text{H}_2\text{O}$


Carbon Dioxide hydrates: $\text{CO}_2 \cdot 7\text{H}_2\text{O}$

Notice the water-to-gas ratio. Propane requires 18 water molecules to form its cage, meaning heavier gases demand significantly more water architecture to trap their energy.

Four fundamental variables construct the physical blockages.



Mapping the thermodynamic battleground of natural gas.



Hydrates will form whenever the temperature and pressure plot falls to the left of the formation line for that specific gas.

The dew point of the gas must remain below the hydrate temperature to ensure safety.

As specific gravity increases, the physical environment required for formation drastically drops.

Lighter Gas (Methane)

2,150 psia

Required pressure to form at 60°F.
Requires extreme pressure to force the light molecules into the water cages.


Heavier Gas (Specific Gravity 1.0)

450 psia

Required pressure to form at 60°F. Heavier hydrocarbon components fall into the structural traps with almost zero resistance.

Key Insight: Heavier gases inherently shrink your safe operating margins. Souring the gas with H₂S and CO₂ further increases the hydrate temperature and reduces the required formation pressure.

The Expansion Envelope: Synthesizing the permissible drop limits.



Operational Example:

1. A 0.7 SG gas at 1,000 psia and 80°F can safely expand down to 620 psia without forming hydrates.
2. However, a 0.90 SG gas under the exact same starting conditions cannot undergo that same expansion without crystallizing.

Conclusion: The thermodynamic penalty of heavier gases restricts how aggressively a system can be choked.

Hydrate formation triggers fall into two distinct mechanical categories.

Hydrate Triggers


Category A: The Ambient Bleed

- **Mechanism:** A gradual decrease in temperature with no sudden pressure drop.
- **Location:** Flow strings, long-distance transmission pipelines.
- **Prediction:** Governed directly by standard Temperature/Pressure charts.


Category B: The Sudden Drop

- **Mechanism:** Sudden expansion causing a rapid, localized temperature plummet (Joule-Thomson effect).
- **Location:** Flow provers, orifices, back-pressure regulators, chokes.
- **Prediction:** Requires complex specific gravity expansion envelopes.

Hydrate control is a sequence of escalating thermodynamic and chemical interventions.



Strategy One: Altering the physical environment via heat and pressure.



Thermal Intervention

Hydrate formation is prevented by actively heating the gas, provided the pressure and water content remain constant. This forces the system back into the Safe Flow Zone.

Pressure Management

Keeping the pipeline pressure strictly below the formation threshold for the specific ambient temperature of the environment.



The Limitation: Maintaining constant heat across miles of exposed or subsea pipeline is often thermodynamically inefficient or physically impossible.

Strategy Two: Starving the system of its architectural foundation.




The Broken Tetrahedron Concept

Dehydration is the ultimate preventative measure.

By removing the water vapor down to the precise dew point specified by process conditions, the host cage can never be constructed, regardless of how extreme the temperature or pressure becomes.


Operational Reality: Complete dehydration requires high capital investment in permanent separation facilities.

Strategy Three: Altering the chemistry when dehydration is unviable.



The Mechanism: Methanol (MeOH), Ethylene Glycol (EG), and Diethylene Glycol (DEG) inhibitors fundamentally shift the vapor/solid equilibrium constants, requiring significantly lower temperatures to form the crystalline framework.

Strategy Four: Mechanical remediation and flow assurance via Pigging.




The Role of the Pig

Originally developed to scrape deposits and named for the characteristic loud squealing noise of its spring-loaded rakes.

Modern Applications:

Removing wax, clearing liquids in gas lines, applying inhibitors to internal walls, and proving meters during daily production operations.

The Hydrate Control Nexus: A strategic decision framework.



Governing principles of pipeline thermodynamics.

Respect the Architecture.

Hydrates are intelligent traps. Their formation relies entirely on an unbroken chain of Water, Temperature, Pressure, and Gas Gravity.

Break one link, and the system is safe.

Heavier Gases Demand Tighter Tighter Margins.

As specific gravity increases, the physical environment required for hydrate formation drastically drops, shrinking your safe expansion envelopes.

Match the Intervention to Economics.

Do not use a capital-intensive dehydration plant for a seasonal problem; deploy methanol.

Do not rely on heat for a sudden choke expansion; alter the chemistry.

**True flow assurance is proactive physics,
not reactive maintenance.**