


The Architecture of YES

A Six-Part Cognitive
Framework for Drilling
Site Selection

Prepared by
Engineer Sajjad k. Hano

Processing Raw Data through Cognitive Lenses

Standard site selection relies on sequential physical checklists. Advanced site selection treats physical criteria as raw inputs processed through six distinct analytical paradigms.



Lens 1: Unconventional Thinking

Reframing the Target Geometry


Traditional View: Finding the Spot



Core Insight

Instead of searching for where to drill, identify **all absolute reasons NOT to drill**.

Inverted View: Defining the Constraints




Map environmental restrictions, protected areas, and water contamination risks first. Prioritize site accessibility and minimal environmental disturbance to dictate the initial geometric viability of the site.

Lens 2: Reading Between the Lines

Interpreting the Hidden Stratigraphy

GEOLOGICAL CONTEXT


Does the location truly match expected geology? Identify known formations that actively disrupt drilling mechanics (e.g., hard rock, expanding clay, unexpected water-bearing zones).



HYDROGEOLOGICAL REALITY

Look beyond the solid state. Is there a possibility of hidden aquifers that will suddenly complicate drilling stability and escalate project costs?

The Resistivity Transition Model



The Shield


A dense rock layer presents as high resistivity, masking the hydrogeology beneath.

The Signal

The **crucial indicator** is the **transition**. A sharp transition beneath a resistive cap often reveals a potential water source.

Lens 3: Extracting Key Variables

Hard Data Isolation Protocol

Target Depth Extraction	Resistivity Extraction
	
Is the target depth strictly within range for existing equipment? Are expected conditions at this exact depth viable?	Are there clear geological or resistivity signals at the precise target depth, or is the data ambiguous? Demand a clear signal before proceeding.

Resistivity Profile Matrix

High Resistivity (Clear Signal)

Often indicates dense rock or dry soil formations.

Transition Zones (The Target)

Significant shifts (from high to low, or vice versa) pinpoint formation boundaries.


Low Resistivity (Clear Signal)

Strongly indicates the presence of water or saturated zones.

Ambiguous Noise

Gradual, unclear shifts requiring further VES logging before validation.


Lens 4: The Expert Triad



The YES exists only where formation stability, hydrogeological safety, and operational accessibility perfectly overlap.

Lens 5: Reverse Thinking

Autopsy of a Past Decision



Root Cause

Re-evaluating existing borehole data and Vertical Electrical Sounding (VES) logs. What resistivity transitions were ignored in the historical data?

Investigation


Has this area been drilled before? Interrogating prior drill logs for encountered hard rock or sudden aquifers.

Outcome

Previous failures or difficulties at nearby points.

Lens 6: Metacognitive Evaluation

Stress-Testing the YES



Bias Check 1: Are we reading a low resistivity signal as water because the data proves it, or because we desperately need a water source here?

Bias Check 2: Are we minimizing environmental restrictions because the target depth is perfectly aligned with our equipment range?

Conclusion: Never let operational convenience override geological reality.

The Cognitive Drill Matrix

Environment	Filtered by Unconventional Geometry.
Geology & Hydrogeology	Filtered by Reading Hidden Transitions.
Resistivity & Depth	Filtered by Strict Variable Extraction.
Previous Data	Filtered by Reverse Engineering History.

Only when all physical criteria survive cognitive stress-testing is the site ready for the drill.