



THE VEINS OF INDUSTRY

Optimizing Oil & Gas Pipeline Sizing Through
Hydraulics, Safety, and Economics




Prepared by Engineer Sajjad k. Hano


A millimeter of steel triggers a multi-million-dollar chain reaction.



Sizing a pipeline is frequently misunderstood as a basic geometry problem. In reality, the decision alters operational efficiency, dictates structural integrity, and defines the lifecycle cost of the asset. The perfect diameter is not found in a single formula; it is negotiated at the intersection of competing engineering and financial disciplines.




Three distinct mandates drive the sizing debate




The Hydraulic Engineer

Increase the diameter. Lower the velocity, reduce the friction, and we eliminate the need for extra pump stations. Flow is king.



The Safety & Materials Expert

Keep it contained. Larger diameters mean greater wall tension and higher risk under peak operating pressures. Safety standards dictate our limits.



The Project Economist

Optimize the steel. Oversizing destroys our initial CAPEX, but undersizing ruins our OPEX. We must find the exact financial sweet spot.

Four baseline variables dictate the physical playing field.

Flow Rate

The primary driver. Higher volumes of oil or gas demand larger diameters to reduce internal velocity, minimizing friction losses and preventing high-speed erosion.

Pipeline Length

The friction multiplier. Over long distances, cumulative pressure drops force a critical choice: increase the pipe diameter or build highly expensive, recurring pump and compressor stations.

Operating Pressure

The outward force. The pipeline must withstand maximum allowable pressure without rupturing or ballooning. Pressure dictates wall thickness requirements more heavily than diameter.

Environmental Conditions

The external threat. Soil chemistry, temperature extremes, and groundwater dictate material grades, protective coatings, and cathodic protection requirements.




Velocity acts as the ultimate economic lever.



Crude Oil: 1–3 m/s



Natural Gas: 10–20 m/s




“Using Darcy-Weisbach and Hazen-Williams equations, we prove that pushing velocities beyond these specific ranges causes exponential friction losses. We lose the pressure we fought to generate.”

– Hydraulic Engineer

“However, if we drop the speed too much by widening the pipe, we purchase thousands of tons of unnecessary steel. We must hug the absolute upper limit of those speed ranges to minimize CAPEX.”

– Project Economist

Containing the force requires a compromise in volume.



Safety Expert:

According to ASME B31.4/B31.8 and API 5L standards, if we expand the diameter, I must radically increase the wall thickness to manage the Hoop Stress safely and prevent rupture.

Hydraulic Engineer (The Diameter Paradox):

Thicker walls on the inside shrink my internal diameter (ID). The external diameter (OD) drives your footprint cost, but the ID drives my flow revenue. Wall thickness is the tax we pay for safety.

Scale completely alters the optimization strategy.

Dimension	Transmission Pipelines	Distribution Pipelines
Primary Goal	Moving massive volumes cross-country	Feeding end-users and local facilities
Diameter Strategy	Maximum viable diameter for scale economies	Minimum viable diameter for extreme flexibility
Key Constraint	Pipeline Length (managing pressure drop over hundreds of miles)	Flow Rate (managing highly variable local consumption)
Dominant Priority	The Economist (Lifecycle OPEX dominates over decades)	The Safety Expert (Urban environments require strict containment)


The exact mathematical point where engineering becomes art.

The debate concludes at the nadir of the Total Lifecycle Cost curve.

The Hydraulic Engineer pushes right (lower OPEX).

The Economist pulls left (lower CAPEX).

The Safety Expert dictates the steepness of the CAPEX curve based on required steel grades.



The perfectly balanced equation.

