
MPPT SOLAR CHARGER CONTROLLER
U2
LT3652HVEMSE#TRPBF
BMS 1S4P
STEP DOWN 3V3
USB FOR PROGRAMMING
ESP32
ESP32-WROOM-32(8MB)
USB FOR NUTRITION SENSOR
KONEKTOR
BH1750 + SHT31
RS485 SUGGESTION