


05 SPEAKER LEFT - WALLS (L1)

Front | right | back | left. Glue the end tab inside the front edge to make a tube,
then glue top L2 and bottom L3 onto the small tabs.
Print at 100 % / 'Actual size' (NOT 'Fit to page'). Best on 200-250 g/m2 card; or glue the print onto thin card (cereal box).


L1 speaker left



05 SPEAKER RIGHT - WALLS (R1)

Front | right | back | left. Glue the end tab inside the front edge to make a tube,
then glue top R2 and bottom R3 onto the small tabs.
Print at 100 % / 'Actual size' (NOT 'Fit to page'). Best on 200-250 g/m2 card; or glue the print onto thin card (cereal box).


R1 speaker right



05 SPEAKER TOPS + BOTTOMS (L2, L3, R2, R3)

6 x 7 cm each. Glue onto the tabs of the speaker tubes L1 / R1.
Print at 100 % / 'Actual size' (NOT 'Fit to page'). Best on 200-250 g/m2 card; or glue the print onto thin card (cereal box).


L2 left top



L3 left bottom



R2 right top



R3 right bottom

