

SCENTED CANDLES

Basic Materials You Need

- Wax (soy, paraffin, or beeswax)
- Candle wicks
- Fragrance oils
- Dye (optional, for color)
- Heat-safe container (glass jar, tin, or mold)
- Double boiler / microwave-safe bowl
- Stirring stick / spoon
- Thermometer (optional but helpful)

Prepare

Fix the wick in the center of the container (use glue or tape).



Melt Wax

- Use a double boiler or microwave to melt wax slowly.
- Stir gently until fully melted.



Add Fragrance & Color

- Remove wax from heat.
- Add fragrance oil and dye (if using).
- Stir well for even distribution.



Pour

Pour the melted wax carefully into the container around the wick.

Set

- Let the candle cool and solidify completely (2–4 hours).
- Trim the wick to ~1 cm.



Decorate (Optional)

Add dried flowers, glitter, or embeds on top for a decorative touch.

KEEP
LEARNING