# **Using an Oscilloscope and Power Electronics**

### 1. Introduction to the Switched Mode Power Supply (SMPS) Prototype

- The goal: Building a functional prototype that converts 230V AC to 5V DC.
- Successful testing: The system outputs approximately 5V without issues.
- Reminder: Working with oscilloscopes requires knowledge of their operation to avoid mistakes that could damage the equipment.

#### 2. Overview of the Oscilloscope

- **Purpose**: Visualizes voltage/current values over time, crucial for observing waveforms in power electronics and data communication.
- **Basic Operation**: The oscilloscope helps diagnose issues in circuits by showing real-time signals, crucial for building and repairing electronics.

### 3. Choosing the Right Oscilloscope

- Channels: More channels allow simultaneous observation of multiple signals. A 4channel scope is ideal for most applications.
- **Bandwidth**: The scope's ability to handle higher frequencies without significant signal degradation. Rule of thumb: Choose a scope with a bandwidth 5 times greater than the signal's frequency.
- **Sampling Rate**: The number of measurements taken per second. 2GSa/s is sufficient for most applications, even with multiple channels active.

#### 4. Probes: Types and Usage

- Passive Probes: Easy to use and come with scaling factors of x1 or x10.
  - o Scaling Factor:
    - x1: No voltage reduction but lower bandwidth due to higher capacitance.

- x10: Reduces the voltage signal by a factor of 10 but maintains higher bandwidth and performance.
- Impedance: Not discussed in-depth, but important for high-quality measurements.

### 5. Triggering the Oscilloscope

- **Triggering**: Essential for stabilizing periodic signals on the oscilloscope display.
  - The trigger ensures that the signal is captured at the same point every time, like at the rising or falling edge.
- **Common Mistake**: Incorrect triggering leads to unstable or non-stationary waveforms.

## 6. Voltage Division

- **Vertical Voltage Division**: Determines the signal amplitude on the oscilloscope screen.
  - Misadjustment can lead to incorrect signal amplitude readings.
  - Example: If your project works with 5V logic, ensure the oscilloscope scaling is set properly to reflect this.

#### 7. Time Division and Frequency

- Horizontal Time Division: Controls the time per division on the oscilloscope.
  - Helps calculate the frequency of signals.
  - $_{\odot}$  Example: With a time division of 10  $\mu s$  per division, the signal frequency is approximately 33 kHz.

#### 8. Advanced Measurement Features

- **Measurement Functions**: Modern digital oscilloscopes come with built-in measurement features to directly measure parameters like frequency, rise time, etc.
- **Cursor Function**: Allows you to manually measure specific characteristics of a waveform, such as rise time by selecting voltage points.

#### 9. AC and DC Coupling

- AC Coupling: Allows only AC signals to pass, removing any DC offset for clearer waveforms.
  - Example: Measuring the ripple on the output of a boost converter without interference from DC offset.

# 10. Single Mode Capturing

- Single Mode: Useful for capturing transient events like capacitor charging.
  - The oscilloscope triggers only once the signal reaches a specific threshold, allowing you to capture a single event.

#### 11. Current Measurement

- Current Measurement Methods:
  - Current Shunt: Measures current by sensing the voltage drop across a known resistance.
  - o **Current Clamp**: Easier to use and set up for non-invasive current measurements.
- **Recommendation**: A current clamp is recommended for simple and effective current measurements.

# 12. Safe Mains Voltage Measurement

- **Warning**: Mains voltage (230V AC) can be hazardous. Always use proper safety precautions when measuring mains voltage with an oscilloscope.
- **Scaling Factor**: A 10:1 scaling factor reduces the 230V AC to a safer 23V, within the oscilloscope's safe input range.
- **Common Mistake**: Incorrectly grounding the oscilloscope by connecting the alligator clip to the PE (Protective Earth) wire can trip circuit breakers or damage the scope.
- **Solution**: Use a differential probe for safe mains voltage measurement.

#### 13. Differential Probe

• **Purpose**: A differential probe isolates the input and output, preventing potential damage when measuring high-voltage signals, such as mains voltage.

#### 14. Advanced Functions: Math & FFT

- **Math Function**: Useful for analyzing complex signals, such as calculating the power in a circuit.
- **FFT (Fast Fourier Transform)**: Converts time-domain signals to the frequency domain, useful for analyzing frequency components in power electronics.

### 15. Conclusion and Final Tips

- Oscilloscopes are powerful tools but require proper understanding and precautions.
- With knowledge of triggering, scaling factors, and measurement techniques, you can safely and effectively use an oscilloscope for various electronic projects.
- Always ensure proper grounding, especially when working with high-voltage signals like mains electricity.

This concludes the basics of using an oscilloscope and the key techniques for safe and effective measurements in power electronics.