

Jetson Expander
JETSON_HEADER
+5V
+3.3V
IMU
IMU_I2C
STM1
STM2
#JUMTC
SDA
SCL
FOR communicating
with STM32
circuiTician
BE CREATIVE
Team Obseract
SDA
SCL
+3.3V
GND