LANDLORDLEDGER · BUILD IT · EP. 3 · FREE CHECKLIST

CONCRETE POUR-DAY CHECKLIST

The first 7 days decide how strong your slab gets.

BEFORE THE POUR

- [ ] Check the forecast: avoid freezing temps; plan around heat and wind
- [ ] Base compacted and forms level; ask about reinforcement
- [ ] Ask the crew where control joints will go

POUR DAY

- [ ] Early-morning pours help on hot days
- [ ] Don't add extra water to make it easier to spread
- [ ] Joints cut or tooled at the planned spacing

CURING (FIRST 7 DAYS)

- [ ] Keep it damp or covered (curing blanket, plastic, or curing compound)
- [ ] Shade/windbreak in heat; blankets in cold
- [ ] Keep heavy traffic off; ask your contractor when cars are okay

WATCH FOR

- [ ] Dusting surface, wide cracks, or puddling: tell the contractor early
- [ ] **BONUS: why pros cut lines in new concrete: revealed in Build It · Ep. 4**

General information only, not legal, tax, financial, or professional advice. Rules vary by state and city.
Free to use and share · Build It · Ep. 3