# Logic, Shift and Rotate Instructions

# Outline

- Logic instructions
- Shift instructions
- Rotate instructions

# Logic Instructions

- We can change individual bits in the computer by using logic operations.
- The binary values of 0 and 1 are treated as false and true respectively.
- When a logic operation is applied to 8 or 16 bit operands, the result is obtained by applying the logic operation at each bit position.
- Logic instructions are: AND, OR, XOR and NOT.

# Mask

- One use of AND, OR and XOR is to selectively modify the bits in the destination.
- To do is we construct a source bit pattern known as mask.
- The mask bits are chosen so that the corresponding destination bits are modified in the desired way.

B AND 1 = B	B OR 0 = B	B XOR 0 = B
B AND 0 = 0	B OR 1 = 1	B XOR 1 = -B

#### Mask

- The AND instruction can be used to clear specific destination bits while preserving the others. A 0 mask bit clears the corresponding destination bit and a 1 mask bit preserves the corresponding destination bit.
- The OR instruction can be used to set specific destination bits while preserving the others. A 1 mask bit sets the corresponding destination bit and a 0 mask bit preserves the corresponding destination bit.
- The XOR instruction can be used to complement specific destination bits while preserving the others. A 1 mask bit complements the corresponding destination bit and a 0 mask bit preserves the corresponding destination bit.

#### The AND Instruction

- Syntax:
  - AND destination, source
- The result of the operation is stored in the destination.
- Destination must be a register or memory location.
- Source may be a constant, register or memory location.
- Memory to memory operations are not allowed.
- Effect on flags:
  - SF, ZF and PF reflect the result.
  - CF, OF = 0.
- Converting an ASCII digit to a number and conversion of lowercase letter to upper case letter.

#### The OR Instruction

- Syntax:
  - OR destination, source
- The result of the operation is stored in the destination.
- Destination must be a register or memory location.
- Source may be a constant, register or memory location.
- Memory to memory operations are not allowed.
- Effect on flags:
  - SF, ZF and PF reflect the result.
  - CF, OF = 0.
- Testing a register for zero and to check the sign of the value.

#### The XOR Instruction

- Syntax:
  - XOR destination, source
- The result of the operation is stored in the destination.
- Destination must be a register or memory location.
- Source may be a constant, register or memory location.
- Memory to memory operations are not allowed.
- Effect on flags:
  - SF, ZF and PF reflect the result.
  - CF, OF = 0.
- Clearing the value of a register.

#### The NOT Instruction

- Syntax:
  - NOT destination
- Perform the one's complement operation on the destination.
- The result of the operation is stored in the destination.
- Destination must be a register or memory location.
- There is no effect on the status flags.
- Complement the bits of a register or memory location.

## The TEST Instruction

- Syntax:
  - TEST destination, source
- The TEST instruction performs an AND operation of the destination with the source but does not change the destination contents.
- The purpose of the TEST instruction is to set the status flags.
- Effect on flags:
  - SF, ZF, PF reflect the result.
  - CF, OF= 0.

# The TEST Instruction

- The TEST instruction can be used to examine individual bits in an operand. The mask should contain 1's in the bit positions to be tested and 0's elsewhere.
- The result of TEST instruction will have 1's in the tested bit positions if and only if the destination has 1's in these positions; it will have 0's elsewhere.
- If destination has 0's in all the tested position, the result will be 0 and so ZF = 1.

#### Shift Instructions

- The shift instructions shift the bits in the destination operand by one or more positions either to the left or right.
- For a shift instruction, the bits shifted out are lost.
- Syntax:
  - opcode destination, 1 ; for a single shift
  - opcode destination, CL; for a shift of N positions where CL contains N.
- In both cases, destination is an 8 or 16-bit register or memory location.
- For intel's more advanced processors, a shift instruction also allows the use of an 8-bit constant.

#### The SHL Instruction

- The SHL(shift left) instruction shifts the bits in the destination to the left.
- Syntax:
  - SHL destination, 1 ; for a single shift
  - SHL destination, CL; for a shift of N positions where CL contains N.
- The value of CL remains the same after the shift operation.
- A 0 is shifted into the rightmost bit position and the MSB is shifted into CF.

# The SHL Instruction

- Effect on flags:
  - SF, PF, ZF reflect the result.
  - CF= last bit shifted out.
  - OF= 1 if result changes sign on last shift.
- The SHL instruction on a binary number doubles the value.

#### The SAL Instruction

- The opcode SAL (shift arithmetic left) is often used in instances where numeric multiplication is intended.
- SAL instructions generate the same machine code as SHL instruction.
- Negative numbers can also be multiply by powers of 2 by left shifts.
- For example, if AX is FFFFh (-1), then shifting three times will yield AX= FFF8h (-8).

#### Overflow

- When we treat left shifts as multiplication, overflow may occur.
- FOr a single left shift, CF and OF accurately indicate unsigned and signed overflow, respectively.
- But the overflow flags are not reliable indicators for a multiple left shift.
- This is because a multiple shift is really a series of single shifts, and CF, OF only reflect the result of the last shift.
- For example, if BL contains 80h, CL contains 2 and we execute SHL BL,CL, then CF = OF = 0 even though both signed and unsigned overflow occur.

# Example

- Write some code to multiply the value of AX by 8. Assume that overflow will not occur.
- Solution: To multiply by 8, we need to do three left shifts.

```
MOV CL, 3 ;number of shifts to do
```

SAL AX,CL ;multiply by 8

## The SHR Instruction

- The instruction SHR (shift right) performs right shifts on the destination operand.
- Syntax:
  - SHR destination, 1 ;for a single shift
  - SHR destination, CL; for a shift of N positions where CL contains N.
- A 0 is shifted into the MSB position, and the rightmost bit is shifted into CF.

#### The SHR Instruction

- Effect on flags:
  - SF, PF, ZF reflect the result.
  - CF= last bit shifted out.
  - OF= 1 if result changes sign on last shift.
- The SHR instruction on a binary number halves the value if it is an even number. For odd numbers, a right shift halves it and rounds down to the nearest integer.

#### The SAR Instruction

- The SAR Instruction (shift arithmetic right) operates like SHR.
- The MSB retains its original value.
- Syntax:
  - SAR destination,1 ;for a single shift
  - SAR destination, CL; for a shift of N positions where CL contains N.
- Effect on flags:
  - SF, PF, ZF reflect the result.
  - CF= last bit shifted out.
  - OF= 1 if result changes sign on last shift.

#### Rotate Instructions

- The rotate instructions rotate the bits in the destination operand by one or more positions either to the left or right.
- For a rotate instruction, bits shifted out from one end of the operand are put back into the other end.
- Syntax:
  - opcode destination, 1 ;for a single rotate
  - opcode destination, CL; for a rotate of N positions where CL contains N.
- In both cases, destination is an 8 or 16-bit register or memory location.
- For intel's more advanced processors, a rotate instruction also allows the use of an 8-bit constant.

# The ROL Instruction

- The instruction ROL (rotate left) shifts bits to the left.
- The MSB is shifted into the rightmost bit.
- The CF also gets the bit shifted out of the MSB.
- Destination bits forming a circle, with the least significant bit following the MSB in the circle.
- Syntax:
  - ROL destination, 1 ;for a single rotate
  - ROL destination, CL; for a rotate of N positions where CL contains N
- In ROL, CF reflects the bit that is rotated out. This can be used to inspect the bits in a byte or word without changing the contents.

#### The ROR Instruction

- The instruction ROR (rotate right) shifts bits to the right.
- The rightmost bit is shifted into the MSB and also into the CF.
- Syntax:
  - ROR destination, 1 ;for a single rotate
  - ROR destination, CL ; for a rotate of N positions where CL contains N
- In ROR, CF reflects the bit that is rotated out. This can be used to inspect the bits in a byte or word without changing the contents.

# Example

- Use ROL to count the number of 1 bits in BX, without changing BX. Put the answer in AX.
- Solution:

```
XOR AX,AX ;AX counts bits
```

MOV CX, 16 ;loop counter

TOP:

ROL BX,1 ;CF=bit rotated out

JNC NEXT ;0 bit

INC AX ;1 bit, increment total

**NEXT:** 

LOOP TOP ;loop until done

#### The RCL Instruction

- The instruction RCL (Rotate through Carry Left) shifts the bits of the destination to the left.
- The MSB is shifted into the CF, and the previous value of CF is shifted into the rightmost bit.
- RCL works like ROL, except that CF is part of the circle of bits being rotated.
- Syntax:
  - RCL destination, 1 ;for a single rotate
  - RCL destination, CL ; for a rotate of N positions where CL contains N
- Effect on the flags:
  - SF, PF, ZF reflect the result.
  - CF = last bit shifted out.
  - OF = 1 if result changes sign in the last rotation.

#### The RCR Instruction

- The instruction RCR (Rotate through Carry Right) shifts the bits of the destination to the right.
- The LSB is shifted into the CF, and the previous value of CF is shifted into the leftmost bit.
- RCR works like ROR, except that CF is part of the circle of bits being rotated.
- Syntax
  - RCR destination, 1 ;for a single rotate
  - RCR destination, CL ;for a rotate of N positions where CL contains N
- Effect on the flags
  - SF, PF, ZF reflect the result
  - CF = last bit shifted out
  - OF = 1 if result changes sign in the last rotation