# Bring the power of Mentimeter to PowerPoint

- Seamlessly embed your favorite Menti slide without changing windows.
- Edit and do a lot more on Mentimeter.com and sync in real-time.





# Log in to use Mentimeter

Work email

Your password



Log in

Forgot password Log in with SSO

or







Don't have an account? Sign up



# ARM Assembly – Arithmetic and Logical Operators

Haris Rotsos

#### Outline



#### Introduction to Assembly

- Instructions and operands
- Registers
- Arithmetic operators

#### Today we will learn

- How to run our first program.
- Learn our first ARM instructions.


### Assembly Instruction



- An instruction is the most basic unit of computer processing
  - Instructions are words in the language of a computer
  - Instruction Set Architecture (ISA) is the vocabulary
- The language of the computer can be written as
  - Machine language: Computer-readable representation (that is, 0's and 1's)
  - Assembly language: Human-readable representation
- We will study ARM (in detail)
- Principles are similar in all ISAs (x86, SPARC, RISC-V, ...)


#### **Instruction Format**





### **CPU Registers**






- Registers are represented with a 4-bit number.
- **R0–R7**: lower registers (bit-4 = 0)
- **R8-R12**: higher registers (bit-4=1)
  - specific instructions store data to them automatically.
- R13 is the Stack Pointer (SP)
- R14 is the Link Register (LR)
- R15 is the program counter (PC)
- Current Program Status Register (CPSR)

# Example repository






https://scc-source.lancs.ac.uk/scc.Y1/scc.131/arm-assembly-examples

#### Move



 Useful to copy data between registers, or set an immediate to a register.



Copy value of r2 in r1

Set rl to the value 77

# Adding



"add" instruction

source registers
destination register

equivalent C
statement
j = j + k;

register mapping

j: r1

k: r2

# Subtracting



```
subtract sub r1, r1, r2 or sub r1, r2 instruction source registers
```

destination register

```
equivalent C
statement
j = j - k;
```

register mapping

j: r1

k: r2

## **Complex Calculations**



```
add r5,r1,r2

add r3,r4

f:

g:

sub r5,r3

    equivalent C
    statement
    f = (g + h) - (i + j);

telepoon and r5,r1,r2

f:

g:

h:

i:

j:

telepoon and r5,r1,r2

f:

g:

h:

telepoon and r5,r1,r2

f:

g:

telepoon and r5,r1,r2

f:

g:

telepoon and r5,r1,r2

f:

g:

h:

telepoon and r5,r1,r2

f:

g:

telepoon and r5,r2

f:

telepoon and r5,r2

f:

telepoon and r5,r2

f:

g:

telepoon and r5,r2

f:

g:

telepoon and r5,r2

f:

telepoon and r5,r2

file

telepoon and r5,r2

file

telepoon and
```

#### register mapping

```
f: r5
g: r1
h: r2
i: r3
j: r4
temp: r5, r3
```

#### Let's test this...




$$R1 = 10$$
,  $r2 = 20$ ,  $r3 = 30$ 

Add r2, r3
Mov r1, r3
Sub r1, r2, r3

Bring the power of Mentimeter to PowerPoint

- Seamlessly embed your favorite Menti slide without changing windows.
- Edit and do a lot more on Mentimeter.com and sync in real-time.



# Number Encoding



- The "add" instruction assumes that its operands are encoded using two's complement
- Since each register holds a 32-bit number:

(2132)

 Different instructions can have different expectations for how numbers are mapped or coded in registers.

# Two's complement



Positive number is directly converted

To obtain negative number flip bits and add
 1

 To obtain the corresponding positive value flip bits again and add 1

## When things go bad



- Sometimes, an arithmetic operation has side-effects.
  - Carry bit.
  - Overflow.
  - Comparison.
- ARM uses a special register (CPSR) to record arithmetic side-effects from instructions.
- We will discuss this a lot when we get to loop and if statements.

#### Current Program Status Register (CPSR)



- CPSR is an ARM register that records the state of the program.
  - Arithmetic instructions will affect its value every time.
- N bit "negative flag": instruction result was negative.
- **Z bit -"zero flag":** instruction result was zero.
- C bit "carry flag": Instruction causes a carry-out or borrow.
- V bit "overflow flag": Instruction produces an overflow in 2's complement numbers.

31	30	29	28	7	6	5	4	0
N	Z	С	V	 I	F	Т	Mode	

# Integer arithmetic operations in ARM



Instruction	Rd	Rn	Rm	imm	Restrictions
ADCS	RO-R7	RO-R7	R0-R7	-	Rd = Rn + Rm + Carry, update CPSR
	R0-R15	R0-R15	R0-R15	-	Rd = Rn + Rm, Rn and Rm must not both specify the PC (R15).
ADD	RO-R7	SP or PC	-	0-1020	Rd = Rn + imm, imm a multiple of four.
	SP	SP	-	0-508	SP = SP + imm, imm a multiple of four.
	R0-R7	RO-R7	-	0-7	Rd = Rn + imm, update CPSP
ADDS	R0-R7	RO-R7	-	0-255	Rd = Rn + imm, Rd,Rn specify the same register, update CPSP.
	R0-R7	RO-R7	RO-R7	-	Rd = Rn + Rm, update CPSP
RSBS	R0-R7	RO-R7	-	-	Rd = Rn * -1, update CPSP
SBCS	R0-R7	R0-R7	RO-R7	-	Rd = Rn – Rm – Carry, Rd, Rn must specify the same register, update CPSP
SUB	SP	SP	-	0-508	Immediate value must be an integer multiple of four.
	RO-R7	R0-R7	-	0-7	Rd = Rn - imm, update CPSP
SUBS	RO-R7	R0-R7	-	0-255	Rd = Rn - imm, Rd,Rn specify the same register, update CPSP.
	RO-R7	RO-R7	RO-R7	-	Rd = Rn - Rm, update CPSP

# Bring the power of Mentimeter to PowerPoint

- Seamlessly embed your favorite Menti slide without changing windows.
- Edit and do a lot more on Mentimeter.com and sync in real-time.





# Log in to use Mentimeter

Work email

Your password



Log in

Forgot password Log in with SSO

or







Don't have an account? Sign up


# Bit Shifting



- Key operation to manage individual bits in a register.
- Can be used for fast multiplication/division with powers of 2.
  - ASR arithmetic-shift-right
  - LSL logical-shift-left
  - LSR logical-shift-right
  - ROR right-rotation
- You can only use R0-R7.
- Non-immediate operations must use the same source and destination register (i.e, 1s1 r0, r0, r1).

# Logical left bit shifting





 $g00001001_{16}(4097_{10})$ 

f 0001 0010<sub>16</sub> (65552<sub>10</sub>)

equivalent C statement f = g << 4;

register mapping


f: r0

g: r1

Note: Example numbers are in hex; 4 bits -> 1 hex digit

# Logical right bit shifting





#### <u>equivalent C</u> <u>statement</u> f = g >> 4;


#### register mapping

f: r0

g: r1


# Arithmetic right bit shifting





# Rotate right bit shifting





### **Logical Operators**



- Using these instructions you can apply all the Boolean operations you learned in the first part of this module.
  - **AND:** Rn = Rd & Rm
  - EOR: Rn = Rd ^ Rm (xor)
  - **ORR**: Rn = Rd | Rm
  - **BIC:** Rn = Rd & ~Rm
- update the N and Z flags according to the result for the CPSR.

# Logical Operators – bit-by-bit AND



and r0, r1, r2

#### result register

registers evaluated

g 0000 1101 0000 0000

h 0011 1100 0000 0000

0000 1100 0000 0000

#### register mapping

equivalent C statement

f = g & h;

f: r0

g: r1

h: r2

AND	g	h
0	0	0
0	0	1
0	1	0
1	1	1

# Logical Operators – ORR



orr r0, r1, r2 result register registers evaluated

OR	<b>8</b> 0	h
0	0	0
1	0	1
1	1	0
1	1	1

# Logical Operators – EOR



eor r0, r1, r2
result register registers evaluated

OR	g	h
0	0	0
1	1	0
1	0	1
0	1	1

# Logical Operators – MVN (MoVe and Not)



mvn r0, r1 result register registers evaluated

r1 0000 1101 0000 0000

r0 1111 0010 1111 1111

NOT	g
1	0
0	1

### Immediate Operands



- Programmers require operations with constants
  - incrementing a number (e.g. counting, array indexes)
  - initialising the value held by a program variable
- Most instructions can replace one of the input register with an immediate, i.e. an integer value.
- Because ARM MIPS aims to optimize the space of a program, immediate size varies.
- You may need to load big values in a register in multiple steps
- ... or use memory to store constants.

## Adding a Constant



add r4, r4, #-1 constant source register destination register

- Constants are prepended with the symbol #.
- They are interpreted as a signed integer.
- Encoded using two's complement.

# Integer arithmetic operations in ARM



Instruction	Rd	Rn	Rm	imm	Restrictions
ADCS	RO-R7	R0-R7	RO-R7	-	Rd = Rn + Rm + Carry, update CPSR
	R0-R15	R0-R15	R0-R15	-	Rd = Rn + Rm, Rn and Rm must not both specify the PC (R15).
ADD	RO-R7	SP or PC	-	0-1020	Rd = Rn + imm, imm a multiple of four.
	SP	SP	-	0-508	SP = SP + imm, imm a multiple of four.
	RO-R7	R0-R7	-	0-7	Rd = Rn + imm, update CPSP
ADDS	RO-R7	R0-R7	-	0-255	Rd = Rn + imm, Rd,Rn specify the same register, update CPSP.
	RO-R7	R0-R7	RO-R7	-	Rd = Rn + Rm, update CPSP
RSBS	RO-R7	RO-R7	-	-	Rd = Rn * -1, update CPSP
SBCS	R0-R7	RO-R7	RO-R7	-	Rd = Rn – Rm – Carry, Rd, Rn must specify the same register, update CPSP
SUB	SP	SP	-	0-508	Immediate value must be an integer multiple of four.
	RO-R7	R0-R7	-	0-7	Rd = Rn - imm, update CPSP
SUBS	RO-R7	R0-R7	-	0-255	Rd = Rn - imm, Rd,Rn specify the same register, update CPSP.
	R0-R7	RO-R7	R0-R7	-	Rd = Rn - Rm, update CPSP

## Loading large immediates




- mov can load values between 0x00000000 to 0x0000FFFF to registers.
  - What about larger integers?
- movt can load 16-bit values into the upper 16 bits of a register (lower 16-bits remain the same).

mov r0, 
$$0x1 @ r0 = 0x10000$$

mov r0, 0xffff @ Loading 0x7fffffff movt r0, 0x7fff





### Recap Questions




How do you load the value 0x11223344 to register r0?

• Assume r0 = 4, r1 = 2. What is the result value of r0, after the execution of the instruction sub r0, r1.


• Implement the following arithmetic operations: r1 = 16\*r0 + r1/8.

### Summary





# Registers and simple arithmetic



# Logical instructions



Next

Memory operands