BASKET FILTER CLEANING SOP

- 1. Do the cleaning of Basket Filter-101A or 101B only when HSD is available in the Station.
- 2. Take cold work permit for cleaning of basket filter.
- 3. Ensure sufficient ullage in the HSD Sump tank for accommodating the drain product from Basket filter.
- 4. For making standby basket filter online open downstream valve- (HOV 64/HOV 65) then open the upstream valve (MOV 1610/1611).
- 5. Ensure physically that both the valves of standby basket filter are open in field then only close the upstream valve (MOV 1610/ MOV 1611) followed by downstream valve (HOV 64/ HOV 65) of the basket filter to be cleaned.
- 6. Alter confirming that the basket filter to be cleaned is Offline, Open the vent valve for passage of Air in Offline Basket filter.
- 7. Then drain the product into the HSD sump tank.
- 8. After complete draining of Basket filter product, door of the Filter with the help of crane.
- 9. Then pull the filter with the help of chain pulley block.
- 10. Arrange to hang the filter vertically for cleaning purpose.
- 11. After collecting the residue, weigh it and note it down in the log-book and place it at the designated place to avoid any contamination.
- 12. After the cleaning of filter element, place the same in the barrel.
- 13. Using the chain pulley block, box-up basket filter and tighten the nut bolts.
- 14. Apply grease over all the nuts and bolts to avoid any corrosion.
- 15. Close the drain and vent valve.
- 16. Now charge the basket filter with product in coordination with control room.