Monitor robot posture demo

async **test.demo_robot_posture.test_ObserveRobotPosture()** [source]

Monitor robot posture demo

Monitor robot posture change events, and the machine reports the current posture RobotPosture (when the posture changes)

When the robot is lying on its side (LYING) or lying down (LYINGDOWN), stop monitoring and announce “I fell”

ObserveFallClimbResponse.status

STAND = 1; //Stand

SPLITS_LEFT = 2; //Left lunge

SPLITS_RIGHT = 3; //Right lunge

SITDOWN = 4; //Sit down

SQUATDOWN = 5; //Squat down

KNEELING = 6; //Kneel down

LYING = 7; //Lying on your side

LYINGDOWN = 8; //Lying down

SPLITS_LEFT_1 = 9; //Left split

SPLITS_RIGHT_2 = 10;//Right split

BEND = 11;//Bent over