Programming control API

class **mini.apis.api_setup.StartRunProgram**(*is_serial: bool = True*) [source]

Bases: `mini.apis.base_api.BaseApi`

Enter programming mode api

Robot enters programming mode

Parameters: **is_serial** (*bool*) – Whether to wait for a reply, the default is True

#GetAppVersionResponse.isSuccess: Is it successful

#GetAppVersionResponse.resultCode: Return code

#GetAppVersionResponse.version

async **execute**() [source]

Execute the instruction to enter the programming mode

Returns: GetAppVersionResponse

class **mini.apis.api_setup.StopRunProgram**(*is_serial: bool = True*) [source]

Bases: `mini.apis.base_api.BaseApi`

Exit programming mode api

Robot exits programming mode

Parameters: **is_serial** (*bool*) – Whether to wait for a reply, the default is True

async **execute**() [source]

Execute exit programming mode instruction

Returns: DisconnectionResponse

class **mini.apis.api_setup.RevertOrigin**(*is_serial: bool = True*) [source]

Bases: `mini.apis.base_api.BaseApi`

Reset api

Robot reset

Parameters: **is_serial** (*bool*) – Whether to wait for a reply, the default is True

#RevertOriginResponse.isSuccess: Is it successful

#RevertOriginResponse.resultCode: Return code

async **execute**() [source]

Execute robot reset instruction

Returns: RevertOriginResponse