

PREFLIGHT - CABIN

Pitot Tube Cover	Remove
POH	Accessible to Pilot
G1000 Ref Guide	Accessible to Pilot
Airplane Weight and Balance	Checked
Control Wheel Lock	Remove
MAGNETOS Switch	OFF
AVIONICS Switch (BUS1 & BUS2)	OFF
MASTER Switch (ALT & BAT)	ON
Primary Flight Display (PFD)	Check
Fuel QTY (L & R)	Check
LOW FUEL Annunciators (NOT shown)	Check
OIL PRESSURE Annunciator	Verify Shown
LOW VACUUM Annunciator	Verify Shown
AVIONICS (BUS1 & BUS2)	Verify Fans
PITOT HEAT Switch	ON/Verify <i>(Check tube is warm within 30 seconds)</i>
Lights	ON/Verify
Flaps	Down
PITOT HEAT Switch	OFF
Lights	OFF
LOW VOLTS Annunciator	Verify Shown
MASTER Switch (ALT & BAT)	OFF
Elevator Trim Control	TAKEOFF
FUEL SELECTOR Valve	BOTH
ALT STATIC AIR Valve	Check
Fire Extinguisher	Check

PREFLIGHT - EMPENNAGE

Baggage Door Compartment	Check
Rudder Gust Lock	Remove
Tail Tiedown	Disconnect
Elevator Trim Tab	Check
Antennas	Check

PREFLIGHT - RIGHT WING

Flap	Check
Aileron	Check
Wing Tiedown	Disconnect
Main Wheel Tire	Check
Fuel Tank Sumps	Check
Fuel Quantity	Check
Fuel Filler Cap	Secure & Vent Clear

PREFLIGHT - NOSE

Fuel Sumps	Check
Oil Level	Check <i>(Do not operate with less than 5 quarts)</i>
Dipstick/Filler Cap	Secure
Engine Cooling Air Inlets	Check
Alternator Belt	Check
Propeller & Spinner	Check
Air Filter	Check
Nosewheel Strut & Tire	Check

PREFLIGHT - LEFT WING

Static Source Opening	Check
Fuel Tank Vent Opening	Check
Stall Warning Opening	Check
Wing Tiedown	Disconnect
Main Wheel Tire	Check
Fuel Tank Sumps	Check
Fuel Quantity	Check
Fuel Filler Cap	Secure & Vent Clear
Flap	Check
Aileron	Check

BEFORE STARTING ENGINE

Preflight Inspection	Complete
Passenger Briefing	Complete
Seats and Seat Belts	Adjust and Lock
Brakes	Test and Set
Circuit Breakers	Check In
Electrical Equipment	OFF
AVIONICS (BUS1 & BUS2)	OFF
FUEL SELECTOR Valve	BOTH
FUEL SHUTOFF Valve	ON

STARTING ENGINE

Throttle Control	Open 1/4 Inch
Mixture Control	Idle Cutoff
STBY BATT Switch	TEST <i>(Hold for 10 seconds, verify green lamp)</i>
STBY BATT Switch	ARM
Engine Indicating System	(No red Xs) Check
BUS E Volts	(Min 24 volts) Check
BUS M Volts	(1.5 volts or less) Check
BATT S Amps	Verify Discharge
STBY BATT Annunciator	Check
MASTER Switch	ON
BEACON Light Switch	ON

Priming Procedure	
Fuel Pump Switch	ON
Mixture Control	Full Rich <i>(Approx. 3-5 seconds until stable flow)</i>
Mixture Control	Idle Cutoff
Fuel Pump Switch	OFF

Brakes	Hold
Propeller Area	Clear
Magnetos Switch	START
Mixture Control	(Advance smoothly) RICH
Oil Pressure	Check
Amps	Positive Charge
LOW VOLTS Annunciator (NOT shown)	Check
NAV Light Switch	(As required) ON
AVIONICS (BUS1 & BUS2)	ON
Mixture Control	(As necessary) Lean

ENGINE OUT - DURING TAKEOFF

Throttle Control	IDLE
Brakes	Apply
Wing Flaps	Retract
Mixture Control	Idle Cutoff
MAGNETOS Switch	OFF
STBY BATT Switch	OFF
MASTER Switch (ALT & BAT)	OFF

ENGINE OUT - AFTER TAKEOFF

Airspeed	70 KIAS - Flaps UP 65 KIAS - Flaps 10° - FULL
Mixture Control	Idle Cutoff
FUEL SHUTOFF Valve	OFF
MAGNETOS Switch	OFF
Wing Flaps	(FULL recommended) As Required
STBY BATT Switch	OFF
MASTER Switch (ALT & BAT)	OFF
Cabin Door	UNLATCH
Land	STRAIGHT AHEAD

ENGINE OUT - DURING FLIGHT

Airspeed	(Best glide speed) 68 KIAS
FUEL SHUTOFF Valve	ON
FUEL SELECTOR Valve	BOTH
FUEL PUMP Switch	ON
Mixture Control	Rich
MAGNETOS Switch	BOTH <i>(If propeller has stopped, turn MAGNETOS switch to START and advance throttle smoothly from idle)</i>
FUEL PUMP Switch	OFF <i>(If indicated fuel flow immediately drops to zero, return FUEL PUMP switch to the ON position)</i>

LANDING - NO POWER

Seat Backs	Most Upright Position
Seats and Seat Belts	Secure
Airspeed	70 KIAS - Flaps UP 65 KIAS - Flaps 10° - FULL
Mixture Control	IDLE CUTOFF
FUEL SHUTOFF Valve	OFF
MAGNETOS Switch	OFF
Wing Flaps	(FULL recommended) As Required
STBY BATT Switch	OFF
MASTER Switch (ALT & BAT)	OFF
Doors	(Prior to touchdown) Unlatch
Touchdown	Slightly Tail Low
Brakes	Apply Heavily

LANDING - WITH POWER

Seat Backs	Most Upright Position
Seats and Seat Belts	Secure
Airspeed	65 KIAS
Wing Flaps	20°
Wing Flaps	(On final) FULL
Airspeed	65 KIAS
STBY BATT Switch	OFF
MASTER Switch (ALT & BAT)	OFF
Doors	(Prior to touchdown) Unlatch
Touchdown	Slightly Tail Low
Mixture Control	IDLE CUTOFF
MAGNETOS Switch	OFF
Brakes	Apply Heavily

LANDING - DITCHING

Radio	(On 121.5 MHz) Transmit Mayday <i>(Give location, intentions, and SQUAWK 7700)</i>
Heavy Objects	Secure or Jettison
Seat Backs	Most Upright Position
Seats and Seat Belts	Secure
Wing Flaps	20° - FULL
Power	300 FT/MIN @ 55 KIAS <i>(If no power is available, approach at 70 KIAS with Flaps UP or at 65 KIAS with Flaps 10°)</i>
Cabin Doors	UNLATCH
Touchdown	SLOW AS POSSIBLE
ELT	ACTIVATE
Airplane	EVACUATE <i>(If necessary, open window and flood cabin to equalize pressure so doors can be opened)</i>

ENGINE FIRE DURING START

MAGNETOS Switch START
(Continue cranking to start the engine)

If Engine Starts

Power 1800 RPM
Engine *(Inspect for damage)* SHUTDOWN

If Engine Fails to Start

Throttle Control FULL
Mixture Control IDLE CUTOFF
MAGNETOS Switch START
FUEL SHUTOFF Valve OFF
FUEL PUMP Switch OFF
MAGNETOS Switch OFF
STBY BATT OFF
MASTER Switch (ALT & BAT) OFF
Engine Secure
Parking Brake Release
Fire Extinguisher Obtain
Airplane Evacuate
Fire Extinguish
Fire Damage Inspect

ENGINE FIRE IN FLIGHT

Mixture Control Idle Cutoff
FUEL SHUTOFF Valve OFF
FUEL PUMP Switch OFF
MASTER Switch (ALT & BAT) OFF
Cabin Vents Open
CABIN HT and CABIN AIR OFF
Airspeed 100 KIAS

*(If not extinguished, increase glide speed within
airspeed limitations to extinguish)*

Forced Landing Execute
(Refer to "LANDING - NO POWER")

ELECTRICAL FIRE IN FLIGHT

STBY BATT Switch OFF
MASTER Switch (ALT & BAT) OFF
Cabin Vents Closed
CABIN HT and CABIN AIR OFF
Fire Extinguisher Activate
AVIONICS (BUS1 & BUS2) OFF
All Other Switches *(Except MAGNETOS)* OFF

IF FIRE HAS BEEN EXTINGUISHED

Cabin Vents Open
CABIN HT and CABIN AIR OFF

IF FIRE HAS BEEN EXTINGUISHED AND ELECTRICAL POWER IS NECESSARY

Circuit Breakers Check
(For OPEN circuit(s), do not reset)
MASTER Switch (ALT & BAT) ON
STBY BATT Switch ARM
AVIONICS Switch (BUS 1) ON
AVIONICS Switch (BUS 2) ON

CABIN FIRE

STBY BATT Switch OFF
MASTER Switch (ALT & BAT) OFF
Cabin Vents *(To avoid drafts)* CLOSED
CABIN HT and CABIN AIR OFF

(Push full in, to avoid drafts)

Fire Extinguisher *(If available)* ACTIVATE
IF FIRE HAS BEEN EXTINGUISHED

Cabin Vents OPEN
CABIN HT and CABIN AIR ON
Land AS SOON AS POSSIBLE

WING FIRE

LAND and TAXI Light Switches OFF
NAV Light Switch OFF
STROBE Light Switch OFF
PITOT HEAT Switch OFF
Land AS SOON AS POSSIBLE

AFTER START

MFD Activate
Flaps Up
ATIS Obtain
Altimeters (PFD & STBY) Set
Fuel Quantity Check
Flight Instruments Check
(ASI/AI/TC/BARO/VSII/DG)

Autopilot Engage
A/P TRIM DISC Button Press
Flight Director OFF
Taxi/IFR Clearance Obtain
TAXI/RECOG Lights ON
Brakes Check

RUN UP

Parking Brake Set
Seat Backs/Seats/Seat Belts Secure
Cabin Doors Closed and Locked
Flight Controls Free and Correct
Elevator Trim Control Set for Takeoff
Flight Instruments *(No red Xs)* Check
ALT SEL Set
Standby Flight Instruments Check
Mixture Control Rich
FUEL SELECTOR Valve BOTH
Throttle Control 1800 RPM

Magnetos Check
*(RPM drop should not exceed 150 RPM on either
magneto or 50 RPM differential between magnetos)*

VAC Check
Engine Indicators Check
Ammeters & Voltmeters Check
Annunciators Verify None
Throttle Control Idle
Throttle Control 1000 RPM
COM/NAV Frequency(s) Set
FMS/GPS Flight Plan As Desired
(Adjust map settings and set heading bug)

XPDR SET
CABIN PWR 12V Switch OFF
Cabin Windows Closed and Locked
Parking Brake Release
Mixture Control *(As necessary)* Lean

BEFORE TAKEOFF

Wing Flaps *(10° preferred)* UP - 10°
Elevator Trim Control Set for Takeoff
Mixture Control RICH
*(Above 3000 feet pressure altitude,
lean for maximum RPM)*
STROBE Light Switch ON
HDG SEL Set

AFTER TAKEOFF

Airspeed 70 KIAS
Wing Flaps Up
Throttle Control FULL
Mixture Control RICH
*(Above 3000 feet pressure altitude,
lean for maximum RPM)*

CRUISE

Power 2100-2700 RPM
(No more than 75% power recommended)
Engine Instruments Check
LAND Light Switch *(If applicable)* OFF
Mixture Control *(As necessary)* Lean

APPROACH

ATIS/AWOS Check
Altimeters Set
Approach Brief Complete
ALT SEL Set
Power As Desired
Mixture Control *(If necessary)* Adjust
FUEL SELECTOR Valve BOTH
LAND Light Switch ON
CDI Softkey Select Nav Source

BEFORE LANDING

Seat Backs Most Upright Position
Seats and Seat Belts Secured and Locked
FUEL SELECTOR Valve BOTH
Mixture Control RICH
LAND and TAXI Light Switches ON
Autopilot OFF
CABIN PWR 12V Switch OFF

AFTER LANDING

Wing Flaps UP
Elevator Trim Control TAKEOFF
STROBE Light Switch OFF
Landing/Taxi Lights As Required
Taxi Clearance Obtain
Mixture Control *(As necessary)* Lean

SHUTDOWN

Throttle Control 1000 RPM
Electrical Equipment OFF
AVIONICS (BUS1 & BUS2) OFF
Mixture Control Idle Cutoff
MAGNETOS Switch OFF
MASTER Switch (ALT & BAT) OFF
STBY BATT Switch OFF
Control Wheel Lock Install
FUEL SELECTOR Valve Left or Right

FIRES
C172S G1000

NORMAL FLIGHT
C172S G1000