TRUST
INTERIOR EMULSION

DIRECTION FOR USE

1. Use Emery paper 180 to remove loose particles.
2. Apply 1 coat of Wall primer. Allow 6-8 hours drying.
3. Fill dents with thin coats of Acrylic Wall putty. Allow drying for 4-6 hours. Sanding with Emery Paper 180 and wipe clean.
4. Apply another coat of Wall Primer. Allow 6-8 hours of drying time. Sand with Emery Paper 320 and wipe clean.
5. Mix 400-500 ml of water with 1 litre of Trust Interior Emulsion. Apply 2-3 coats with 3-4 hours between each coat. For deep shades, apply an additional layer of Trust Interior Emulsion.



AWANTIKA & AARADHYA GROUP

DUCON

MONARCH

TRUST
INTERIOR EMULSION

TRUST
INTERIOR EMULSION

M.R.P. ₹
(Incl. of all Taxes)

Date of Mfg.:

Batch No.:

Shade :

MANUFACTURED BY:

AWANTIKA AND AARADHYA INDUSTRIES PVT. LTD.

18-19, SECTOR-D, INDUSTRIAL AREA, MANDIDEEP, DISTRICT RAISEN 462046

GST : 23ABBCA2181R1ZI