
Практическая №18

Строим сеть.

Настраиваем Ір-адрес и маску подсети.



Далее переходим в терминал Switch и начинаем его конфигурировать.

```
Switch>en
Switch#conf t
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#int vlan 1
Switch(config-if)#ip address 192.168.0.2 255.255.255.0
Switch(config-if)#no sh

Switch(config-if)#line vty 0 5
Switch(config-line)#pass 123
Switch(config-line)#login
Switch(config-line)#enable pass 123
```

Подключаем Telnet и задаём пароль для привилегированного доступа конфигурирования.

```
Cisco Packet Tracer PC Command Line 1.0
C:\>telnet 192.168.0.2
Trying 192.168.0.2 ...Open

User Access Verification

Password:
Switch>en
Password:
Password:
Switch#conf t
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#
```

Подключаем SSH.

```
Switch(config)#hostname swl
swl(config)#ip domain name test
swl(config)#crypto key generate rsa
The name for the keys will be: swl.test
Choose the size of the key modulus in the range of 360 to 4096 for your
 General Purpose Keys. Choosing a key modulus greater than 512 may take
 a few minutes.
How many bits in the modulus [512]: 768
% Generating 768 bit RSA keys, keys will be non-exportable...[OK]
swl(config)#ip ssh version 2
*Mar 1 0:13:35.915: %SSH-5-ENABLED: SSH 1.99 has been enabled
swl(config)#line vty o 15
% Invalid input detected at '^' marker.
swl(config)#line vty 0 15
swl(config-line)#transport input ssh
swl(config-line)#
```

Проверяем Telnet и смотрим, что он у нас теперь заблокирован.

```
C:\>ssh -1 admin 192.168.0.
Invalid Command.
```