

Unit 4

Microprogrammed Control

4.1 Control Memory

4.2 Address Sequencing

4.3 Computer Configuration


4.4 Microinstruction Format

MICROPROGRAMMED CONTROL

Microprogrammed control is a method of designing the **Control Unit (CU)** of a computer using **microinstructions stored in memory**, instead of using hardwired logic.

In this approach, control signals are generated by executing **microinstructions** stored in a special memory called **control memory**.

- Microprogrammed control uses microinstructions stored in control memory.
- Control memory stores microprograms for machine instructions.
- Address sequencing selects the next microinstruction.
- Computer configuration includes control memory, sequencer, registers, and ALU.
- Microinstruction format defines control signals and next-address logic.
- Widely used in complex CPU designs.



In 8085, one machine instruction (like ADD B) is executed using many internal micro-operations, which is the idea of microprogrammed control.

Unit Topic	**Meaning (Easy)**	**8085 Instruction**	**Internal Micro-operations (What happens inside CPU)**
4.1 Control Memory	Stores control steps (microinstructions)	'ADD B'	1. Fetch opcode from memory 2. Decode instruction 3. ALU adds A + B 4. Result stored in A
4.2 Address Sequencing	Decides next control step	'JZ 2050H'	If Zero flag = 1 → PC + 2050H Else → PC + PC + 1
4.3 Computer Configuration	Arrangement of registers, ALU, buses	'MOV A, C'	Data from register C → internal bus → register A
4.4 Microinstruction Format	Fields that control ALU, registers, next step	'INR A'	A + A + 1 Flags updated Next instruction fetched

4.1 Control Memory

Control memory is a special type of memory used to store **microprograms**.

A **microprogram** is a sequence of microinstructions that control the execution of machine instructions.


Each microinstruction generates a set of control signals that:

- Transfer data between registers
- Select ALU operations

- Control memory read/write
- Control input/output

Key Points

- Control memory is usually implemented using **ROM** or **PLA**
- It is faster than main memory
- Each location stores **one microinstruction**



Example

Suppose the machine instruction is: **ADD X**

This single instruction is broken into microinstructions such as:

$\mu_1: AR \leftarrow PC$

$\mu_2: IR \leftarrow M[AR]$

$\mu_3: PC \leftarrow PC + 1$

$\mu_4: AR \leftarrow IR(address)$

$\mu_5: DR \leftarrow M[AR]$

$\mu_6: AC \leftarrow AC + DR$

Control Memory (ADD B)	

What CPU does internally (micro-operations):	
Step	Micro-operation
μ_1	Fetch opcode from memory
μ_2	Decode ADD instruction
μ_3	$A \leftarrow A + B$
μ_4	Update flags
μ_5	Go to next instruction

All these microinstructions are stored in **control memory**.

4.2 Address Sequencing

Address sequencing is the process of **selecting the address of the next microinstruction** to be executed.

This task is handled by a component called the **Microprogram Sequencer**.

Ways to Determine the Next Microinstruction Address

1. Sequential Addressing

Address Sequencing (JUMP Instruction): JMP 3000H	

Internal steps:	
Condition Action	
Always	$PC \leftarrow 3000H$

Address sequencing decides → next microinstruction address = 3000H.	

- Next microinstruction is stored at the next memory location.
- Example: $\mu\text{Address} \leftarrow \mu\text{Address} + 1$

2. Branching

- Microinstruction specifies the address of the next microinstruction.
- Used for conditional execution.
- Example: **If Z = 1 → go to $\mu\text{Address}$ 120**

3. Mapping from Opcode

- Opcode of machine instruction is used to find the starting address of its microprogram.
- Example: **Opcode ADD → microprogram starts at address 40**

4. Conditional Branching

- Next address depends on condition flags (Z, C, etc.).

Example

For instruction JUMP:

If condition true → $\mu\text{Address} = \text{branch address}$

Else → $\mu\text{Address} = \mu\text{Address} + 1$

4.3 Computer Configuration

Computer configuration refers to the **organization and interconnection of registers, ALU, buses, and control memory** required to support microprogrammed control.

Main Components

1. Control Memory
2. Control Address Register (CAR)
3. Microinstruction Register (MIR)
4. Microprogram Sequencer
5. ALU
6. Registers (AC, PC, IR, DR, AR, etc.)

Computer Configuration (MOV Instruction)	
<hr/>	
MOV A, D	
<hr/>	
Inside CPU:	
<hr/>	
Component	Action
<hr/>	<hr/>
Register D	Places data on internal bus
Internal Bus	Transfers data
Register A	Receives data
<hr/>	<hr/>

How It Works

1. CAR holds the address of the current microinstruction
2. Control memory outputs the microinstruction
3. MIR stores the microinstruction
4. Control signals from MIR control registers, ALU, and buses
5. Sequencer decides next microinstruction address

Example

During execution of LOAD X:

- Control memory issues signals to load AR
- Next microinstruction causes memory read
- Another microinstruction loads AC

4.4 Microinstruction Format

What is a Microinstruction?

A microinstruction is a **low-level instruction** that specifies one or more micro-operations to be executed in a single clock cycle.

3	3	3	2	2	7
F1	F2	F3	CD	BR	AD

F1, F2, F3: Microoperation fields
 CD: Condition for branching
 BR: Branch field
 AD: Address field

General Microinstruction Format

A microinstruction typically contains:

1. **Control Field**
2. **Condition Field**
3. **Next Address Field**

Types of Microinstruction Formats

1. Horizontal Microinstruction Format

- Many control bits
- One bit per control signal

Microinstruction Format (INR A)	
<hr/>	
INR A	
<hr/>	
Microinstruction Fields (conceptual):	
<hr/>	
Field	Meaning
<hr/>	
ALU Control	Increment
Register Select	A
Flag Control	Update flags
Next Address	PC + 1
<hr/>	
☞ This shows how a single microinstruction controls multiple actions.	
<hr/>	

- Fast execution
- Requires large control memory


Format Example | **Control Signals** | **Next Address** |

Example $AR \leftarrow PC$, $DR \leftarrow M[AR]$,
ALU = ADD

2. Vertical Microinstruction Format

- Encoded control signals
- Fewer bits
- Slower than horizontal
- Smaller control memory

Format Example | **Opcode** | **Register Select** | **ALU Function** | **Next Address** |



Example of Microinstruction Format

Field	Purpose
F1	ALU operation (ADD, SUB, AND)
F2	Register transfer
F3	Memory operation
CD	Condition select
BR	Branch control
AD	Next microinstruction address

Example Microinstruction

F1 = ADD

F2 = AC \leftarrow AC + DR

F3 = None

CD = Z

BR = Conditional

AD = 120

Meaning:

If Zero flag is set, go to microinstruction at address 120.

Example: Execution of ADD Instruction (Microprogram Level)

μ_1 : AR \leftarrow PC

μ_2 : IR \leftarrow M[AR]

μ_3 : PC \leftarrow PC + 1

μ_4 : AR \leftarrow IR(address)

μ_5 : DR \leftarrow M[AR]

μ_6 : AC \leftarrow AC + DR

Each step corresponds to one microinstruction stored in control memory.

Advantages of Micropogrammed Control

- Easy to design and modify
- Instruction set can be changed by updating microprogram
- Less complex than hardwired control
- Suitable for complex instruction sets (CISC)

Disadvantages

- Slower than hardwired control

- Control memory cost
- Extra memory access time