## UL Product iQ®



## SWIV2.E87929 - Relay Sockets and Assemblies - Component

Note: We are enhancing our systems and you may notice duplicate entries/missing/outdated data. During this interim period, please contact our Customer Service at <a href="https://www.ul.com/about/locations">https://www.ul.com/about/locations</a>.

## **Relay Sockets and Assemblies - Component**

Omron Corp E87929

SAFETY STANDARDS GROUP
IAB GLOBAL QUALITY CENTER
SHIOKOJI HORIKAWA
SHIMOGYO-KU, KYOTO 600-8530 Japan

Marking: Company name or tradename "OMRON", and model designation. Note: For additional marking information, refer to the <u>Guide Information Page</u>.

Model(s): PTFZ-08-E, may be followed by any letter(s) and/or number(s).

Model(s): PTFZ-14-E, may be followed by any letter(s) and/or number(s).

Coil lamp assemblies, Model(s): P70A+, P70D+

**Relay sockets,** Model(s): 8PFA1, 8PFA1-SA, 8PFA1-W, 8PFA1-W-T, 8PFA1-W-TD, P2RFZ-05-E-TJ, P3G-08, P3G-11, P3GA-11, PF113A-E, PL08, PL11, PLE08-0, PLE11-0

Relay sockets, Model(s): 8, 11 or 14, followed by PF, followed by A, may be followed by -SA, -W, -W-T or -W-TD.

Relay sockets, Model(s): P2CF, followed by 08 or 11, may be followed by E, may be followed by 600.

Relay sockets, Model(s): P2R, followed by -05 or -08, followed by A or P, may be followed by additional letters and or numbers.

Relay sockets, Model(s): P2RF, followed by -05 or -08, followed by -PU, may be followed by additional letters and or numbers.

Relay sockets, Model(s): P2RF, followed by -05 or -08, followed by S, may be followed by additional letters and or numbers.

**Relay sockets,** Model(s): P2RF, followed by -05 or -08, may be followed by -E, may be followed by additional letters and or numbers.

Relay sockets, Model(s): P2RFZ, followed by -05 or -08, may be followed by -E, may be followed by any letter(s) and/or number(s)

Relay sockets, Model(s): P6B, followed by -04P, -04PW, -06P or -26P, may be followed by suffix letters and or numbers.

Relay sockets, Model(s): P6C, followed by 06 or 08, followed by C or P, may be followed by additional letters and or numbers.

Relay sockets, Model(s): P6D, followed by -04P, may be followed by additional letters and or numbers.

Relay sockets, Model(s): P6DF, followed by -F4PU, may be followed by any letter(s) and/or number(s).

Relay sockets, Model(s): P7LF, followed by -06, -06D or -D, may be followed by suffix letters and or two numbers.

**Relay sockets,** Model(s): P7M, followed by -06, followed by P, may be followed by additional letters and or numbers for sales purposes.

Foodback

Relay sockets, Model(s): P7MF, followed by -06, may be followed by -D, may be followed by additional letters and or numbers.

**Relay sockets,** Model(s): P7S followed by 14, followed by A, F or P, may be followed by a letters and or numbers, this type of relay socket will be marked with the UL R/C mark.

**Relay sockets,** Model(s): P7SA, followed by 10 or 14, followed by F or P, may be followed ND, may be followed by letters and or numbers.

**Relay sockets,** Model(s): P7SA, followed by -10F or -14F, may be followed by -ND, followed by -PU, may be followed by additional letters and or numbers.

Relay sockets, Model(s): P7TF, followed by -05, may be followed by -TV, may be followed by suffix letters and/or numbers.+

**Relay sockets,** Model(s): PF-083A, PF-113A, may be followed by -SA, -W, -W-T or -W-TD, may be followed by -E, may be followed by additional letters and or numbers.

**Relay sockets,** Model(s): PTF, followed by -08 or -14, followed by -PU, may be followed by -L, may be followed by any letter(s) and/or number(s).

**Relay sockets,** Model(s): PY may be followed by 08, 11 or 14, may be followed by blank, -0 or -02, may be followed by blank or -Y1, may be followed by additional letters or numbers.

**Relay sockets,** Model(s): PYF, followed by -08 or -14, followed by -PU, may be followed by -L, may be followed by additional letter(s) and/or number(s)

**Relay sockets,** Model(s): PYF may be followed by 08, 11 or 14, may be followed by A, followed by a blank, may be followed by a blank, -W, may be followed by blank, -E, -TU, may be followed by -N, may be followed by additional letters and or numbers.

Relay sockets, Model(s): PYF, followed by 08 or 14, followed by B, may be followed by additional letters and or numbers.

Relay sockets, Model(s): PYF, followed by 08 or 14, followed by S, may be followed by additional letters and or two numbers.

**Relay Sockets,** Model(s): P7S, followed by 14, followed by F or P, followed by E, may be followed by ND, may be followed by a letters and or numbers.

**Relay Sockets,** Model(s): PYFZ-08, may be followed by -E, may by followed by -W, -TU or -W-TU, may be followed by -K3FM, may be followed by additional letter(s) and/or number(s).

**Relay Sockets,** Model(s): PYFZ-14, may be followed by -E, may by followed by -W, -TU or -W-TU, may be followed by additional letter(s) and/or number(s)

Relay Sockets, Model(s): Type P7S followed by 14, followed by F, A, or P, may be followed by a letter(s) and/or number(s).

**Relay Sockets,** Model(s): Type PT, followed by 08, 11 or 14, may be followed by -0, may be followed by additional letter(s) and/or number(s).

**Relay Sockets,** Model(s): Type PTF, followed by 08, 11 or 14, followed by A, may be followed by -W, may be followed by -E or -TU, may be followed by additional letter(s) and/or number(s).

Relay sockets and motor controller combinations, Model(s): G6B

**Relay sockets and motor controller combinations,** Model(s): G3DZ or G6D, followed by F4B, may be followed by additional letters and or numbers.

**Relay Sockets and Motor Controller Combinations,** Model(s): Type G6B, followed by -4 or 47, may be followed by F, followed by B, B1 or P, may be followed by N, may be followed by D, may be followed by -01, may be followed by additional letters or numbers.

**Relay sockets and relay combinations,** Model(s): G6C, followed by -2 or -4, followed by B, may be followed by N, may be followed by additional letters and or numbers.

**Sockets,** Model(s): Type PY, may be followed by 08, 11 or 14, may be followed by blank, -0 or -02, may be followed by blank or -Y1, may be followed by additional letter(s) or number(s).

Feedback

**Sockets,** Model(s): Type PYF, may be followed by 08 or 14, may be followed by A, followed by -V, followed by 100 or 200, may be followed by additional letters and or numbers.

**Sockets,** Model(s): Type PYF, may be followed by 08, 11 or 14, may be followed by A, followed by a blank, may be followed by a blank, -W, may be followed by blank, -E, -TU, may be followed by -N, may be followed by additional letter(s) and/or number(s).

+ - Products are to be provided with the Recognized Mark and if not provided with the Recognized Mark, the product is not UL recognized.

Last Updated on 2023-04-12

4

**•** 

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL Solutions' Follow - Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL Solutions' Follow - Up Service. Always look for the Mark on the product.

UL Solutions permits the reproduction of the material contained in Product iQ subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from Product iQ with permission from UL Solutions" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "©2023 UL LLC."