








### Filter Design, Tower and Drive Train Damper



#### Motivation:

Wind Turbines are very flexible structures...

- Modes from tower, blades, shaft...
- Coupling with each other and rotation.
- Not considered in baseline controller design.
- $\rightarrow$  Might result in unwanted resonance!

### **Objectives**

- ▶ How can we avoid resonance with important modes by filtering?
- ▶ How can we damp tower and drive train torsional vibrations?

### **Schedule**

- 02.09. 1 Controller Design Objectives and Modeling
  03.09. 2 Baseline Generator Torque Controller
  04.09. 3 Collective Pitch Controller
  05.09. 4 Filter Design
  06.09. 5 Tower Damper
- 09.09. 6 Advanced Torque Controller10.09. 7 Wind Field Generation
- 11.09. 8 Steady State Calculations
- 12.09. 9 Individual Pitch Control
- 13.09. 10 Lidar-Assisted Control I
- 16.09. 11 Lidar-Assisted Control II
- 17.09. 12 Wind Farm Effects
- 18.09. 13 Wind Farm Control
- 19.09. 14 Floating Wind Control I
- 20.09. 15 Floating Wind Control II



### **Contents**


1. Update of Reduced Controller Design Model

2. Filter Design for Wind Turbine Control


3. Conclusion and Learning Objectives



## Reduced model for controller design



# Low pass filter design



#### el filtro de primer orden decae con pendiente 10 db por salto de frecuencia

en f=1 rad/s en 3db la amplitud cae al 70% y se retrasa 45° es aprox 0.8 seg en f=10 rad/s en 20db la amplitud cae al 10% y se retrasa 85° casi un cuarto en f=100 rad/s en 40db la amplitud cae al 1% y se retrasa 90° un cuarto de periodo

Ojo con el delay de tiempo 
$$\text{With } \omega_{\text{cut-off}} = 1 \, \text{rad/s} :$$


1st order: 
$$\frac{\omega_{\mathrm{cut-off}}}{s+\omega_{\mathrm{cut-off}}}$$

2nd order Butterworth:

$$\frac{\omega_{\mathsf{cut-off}}^2}{2\omega_{\mathsf{cut-off}}s+\omega_{\mathsf{cut-off}}^2}$$

- Used to filter out noise above highest eigenfrequency.
- ▶ Usually first or second order Butterworth filter is used.
- ▶ Main problem: phase and thus time delay!
- ightarrow Use with care! Better place it at a higher frequency and use a notch filter.

### Notch filter design




With  $\omega_1=0.1\,\mathrm{rad/s}$  and  $\omega_2{=}10\,\mathrm{rad/s}$  or  $\omega_{\mathrm{notch}}=\sqrt{\omega_2\omega_1}=1\,\mathrm{rad/s}$ , bandwidth  $b=\omega_2-\omega_1$ , and depth d,  $\omega_{1/2}=\frac{\sqrt{b^2+4\omega_{\mathrm{notch}}^2\pm b}}{2}$ :

Butterworth: 
$$\frac{s^2 + \omega_2 \omega_1}{s^2 + (\omega_2 - \omega_1)s + \omega_2 \omega_1}$$
 adjusted notch filter: 
$$\frac{s^2 + bds + \omega_{\text{notch}}^2}{s^2 + b \ s + \omega_{\text{notch}}^2}$$

- Used to filter out certain frequencies to avoid resonances.
- Usually adjusted notch filter used due to better numerical and dynamic properties.


### Dynamic notch filter design

se filtran señales en el entorno de 3p pero estas cambia según la velocidad de rotación



- ➤ 3P frequency changes with mean rotor speed.
- ➤ 3P in generator speed causes unnecessary pitch and torque controller action.
- Low pass is used to get mean rotor speed (usually 4-5 times slower than closed-loop frequency).
- ➤ Adjusted notch filter with relative bandwidth (usually 30 to 40% of notch frequency) used to obtain "natural" spectra.

### High pass filter design




With 
$$\omega_{\mathrm{cut-in}}=1\,\mathrm{rad/s}$$
:

1st order: 
$$\frac{s}{s+\omega_{\mathrm{cut-in}}}$$

2nd order Butterworth: 
$$\frac{s}{s^2 + \sqrt{2}\omega_{\text{cut-in}}s + \omega_{\text{cut-in}}^2}$$

- Used to filter out steady state.
- Usually first or second order Butterworth filter is used.

### Band pass filter design



With 
$$\omega_1=0.1\,\mathrm{rad/s}$$
 and  $\omega_2{=}10\,\mathrm{rad/s}$  or  $\omega_{\mathrm{band}}=\sqrt{\omega_2\omega_1}=1\,\mathrm{rad/s}$ , bandwidth  $b=\omega_2-\omega_1$ :

high+low pass: 
$$\frac{\omega_2 s}{s^2 + (\omega_2 + \omega_1)s + \omega_2 \omega_1}$$

Butterworth:  $\frac{bs}{s^2 + bs + \omega_{\mathsf{band}}^2}$ 

es utilizado para el filtrado de la frecuencia de resonancia del generador

- Used to let pass certain frequencies.
- Usually 2nd order Butterworth filter used.

#### **Conclusion**

#### Main questions

- ▶ How can we avoid resonance with important modes by filtering?
- ► How can we damp tower and drive train torsional vibrations? Next lecture

#### With low pass and notch filters

- ▶ A low pass is usually used for filtering out noise: Trade-off filter effect vs. time delay.
- A notch filter is used for specific frequencies.

### Quick check on learning objectives

#### After this lectures you should be able to...

- ...model the basic dynamics of the rotor and tower of a wind turbine.
- ...know when to use a low pass or a notch filter.
- ...design a low pass filter.
- ...design a notch filter.
- ...design a high pass filter.
- ...design a band pass filter.

#### Please let me know if you have further questions!

Prof. Dr.-Ing. David Schlipf David.Schlipf@HS-Flensburg.de www.hs-flensburg.de/go/WETI

#### Disclaimer

The lecture notes are inspired by the lectures of SWE, University of Stuttgart. They are for educational purposes only and are not allowed to be published, shared or re-used in any form without the express consent of the authors (David Schlipf and colleagues). Copyright belongs to the authors. If not stated otherwise, copyright of photos and figures belongs to the authors. The authors do not assume any responsibility for the content of the material and will not be liable for any losses or damages in connection with the use of the material.