SecureFort User Guide

Welcome to SecureFort! This guide provides step-by-step instructions for setting up your device to connect to the Internet and VPN services. Follow these steps carefully to ensure a smooth and secure experience.

1. Access the SecureFort Web Interface

- 1. Launch a web browser on your computer or mobile device.
- 2. Enter the following URL into the browser's address bar:
- 3. http://192.168.3.1
- 4. Press **Enter** to load the SecureFort login page.

2. Login to SecureFort

- 1. On the login page, enter the administrator password:
 - o **Username:** admin
 - o **Password:** [Your "admin" password]
- 2. Click the **Submit** button to access the SecureFort dashboard.

3. Navigation Menu Overview

The SecureFort web interface has the following navigation menu options:

- **Dashboard:** Displays network activity and connection statistics.
- Connect: Configure and establish an Internet connection.
- VPN: Manage VPN services.
- **System:** System settings and maintenance options.
- Logout: Log out of the SecureFort interface.

4. Establishing an Internet Connection

4.1 Access the Connection Settings

1. In the navigation menu, click **Connect**.

- 2. From the dropdown menu labeled **External Interface**, select your connection type:
 - Wired (Ethernet)
 - o Wireless (Wi-Fi)
- 3. Click **Submit** to proceed.

4.2 Connecting to a Wireless Network

- 1. From the list of available Wi-Fi networks in the dropdown box, select the desired Wi-Fi service.
 - o **Open Network:** If you choose an open Wi-Fi network:
 - Click the Captive Portal button to complete the connection.
 - Secured Network: If the network requires a password:
 - Enter the Wi-Fi credentials (SSID and password).
 - Click Select to connect.

5. Configuring VPN Services

- 1. Once your Internet connection is established, navigate to the **VPN** page.
- 2. From the dropdown box, select a VPN service option:
 - o Available VPN Services: Choose a service from the pre-configured list.
 - o **Terminate VPN:** Disconnect the current VPN connection.
 - Skip VPN: Proceed without enabling a VPN.
- 3. To provision a new VPN service:
 - o Upload your VPN profile file using the upload option on the page.
 - o Select the uploaded VPN service from the list.
- 4. Click the **Submit** button to apply the VPN configuration.

6. Dashboard Overview

- The **Dashboard** page displays real-time statistics of active connections in your Wireless Local Area Network (WLAN).
- The connection activity chart refreshes automatically every 5 seconds.

7. Logging Out

1. When finished, click **Logout** in the navigation menu to securely exit the SecureFort interface.

Thank you for using SecureFort! If you encounter any issues, please consult the support documentation or contact customer service for assistance.