

Doors and Windows

The parts, the types, and the one glazing rule that is a safety requirement rather than a preference.

Stile	The vertical member of a frame. Both doors and windows have stiles — if a question asks what the two have in common, this is it.
Casement	A glazed sash or frame hung on hinges so it opens like a door.
Fixed-pane window	A window that does not open. A picture window is the example.
Louver	An opening fitted with slanted fins to keep out rain and snow while letting air through.

Safety glazing

YOU HAVE MISSED THIS

Tempered safety glass is required:
In sliding patio doors.

Tempered glass breaks into blunt granules instead of blades. It is required wherever glass is large, low, and in a place a person might walk into or fall against — a sliding patio door being the clearest case. Look for glass that is near a walking surface, near a door, or in a wet room.

The numbers here

Maximum height of a deadbolt lock in a door

48 in

How the exam expects you to inspect them

Exterior doors have their condition checked during the interior inspection. That sounds like a trick, but it is how the work is actually done: you operate the door, check the latch, the weatherstrip and the threshold from inside, where you are standing when you walk the rooms.

Say it back

Cover the page. Answer each one out loud.

1. What do doors and windows both have?
2. Casement, fixed-pane, louver — describe each one.
3. Where is tempered safety glass required, and what makes tempered glass safer?
4. Maximum height for a deadbolt?
5. During which part of the inspection are exterior doors checked?