

Bathroom, Attic and Roof Ventilation Hardware

The fans and vents fitted to individual rooms and roof planes, including the two paddle fan clearances.

Bathroom and kitchen exhaust must terminate outside the building. Discharged into an attic it deposits moisture on the underside of the sheathing, which is one of the genuine causes of wet attic insulation.

Paddle fans over a shower

The numbers here

Ceiling paddle fan — minimum height above the floor of a shower	8 ft
Ceiling paddle fan — minimum distance to the side of a shower	36 in

YOU HAVE MISSED THIS

An interior ceiling paddle fan in a bathroom needs to be installed eight feet above the floor of a shower and ____ inches to the side of the shower.

36.

Eight feet up, three feet across. The zone is defined so that someone standing wet in the shower cannot reach the blades or the fixture.

Powered attic ventilators

Electrically powered roof and attic fans move air out of the attic, lower its temperature and reduce moisture build-up. What they do NOT do is bring fresh make-up air in — they only exhaust. That is the whole reason an attic fan without adequate intake venting pulls its make-up air from the conditioned house below, which is the negative pressure problem.

O'Hagin vents

Roof vents shaped like concrete roof tiles, so they ventilate a tile roof without breaking its appearance.

Ridge vent

A continuous vent along the ridge, the high outlet of a balanced system.

Soffit vent

The low inlet under the eave.

Say it back

Cover the page. Answer each one out loud.

1. Where must bathroom exhaust terminate, and what happens if it does not?
2. Give the two paddle fan clearances at a shower.
3. What do powered attic fans do, and what do they not do?
4. Why does an attic fan without intake venting cause a problem?
5. What is an O'Hagin vent?