

Floors, Cabinets and Finishes

What the floor is built on, what the coverings are called, and the cabinet dimensions.

Sleepers	What wood flooring installed over a concrete slab is supported on — strips laid on the slab to carry the boards and hold them clear of it.
Resilient flooring	Another name for vinyl flooring.
Engineered floor	An interior floor made up of various composites that may include wood, laminate or wood components.
Thin-set	The name for ceramic tile set in dry-set mortar or mastic.

The numbers here

Solid wood strip flooring — common thickness	3/4 in
Kitchen base cabinet — depth	24 in
Bathroom vanity cabinet — depth	21 in
Upper cabinet above the countertop	18 in
Kitchen modular cabinet width increments	3 in

The cabinet set is worth learning as one picture of a kitchen: base cabinets 24 deep, wall cabinets 18 above the counter, and the whole modular range built in 3-inch steps so a run can be made up to any length. The bathroom vanity is the shallow one at 21.

Plywood veneers	Come in odd numbers, so the grain directions balance around a centre ply and the sheet does not cup.
Friable asbestos	Asbestos becomes dangerous when it is friable — when it can be crumbled by hand and release fibers into the air. Intact, bound asbestos is not releasing anything.

Say it back

Cover the page. Answer each one out loud.

1. What supports wood flooring over a slab?
2. Another name for vinyl flooring, and what an engineered floor is?
3. What is thin-set?
4. Common thickness of solid wood strip flooring?
5. Base cabinet depth, vanity depth, and upper cabinet height above the counter?
6. What increments do modular kitchen cabinets come in?
7. Why do plywood veneers come in odd numbers?
8. When does asbestos become dangerous?