

# Roku App Test Install Guide

Only the steps needed to download, sideload, and log in to the Synology DS Video Roku app.


## You need

A Roku device and remote on the same network as your computer.

The latest app ZIP file from GitHub: roku-ds-video.zip.

A password you choose for the Roku developer installer.

## 1. Download the Latest App ZIP



GitHub latest release page: download the roku-ds-video.zip asset.

1. Open the latest release page: <https://github.com/sapman1208/DS-Video-for-Roku-TV/releases/latest>
2. Under Assets, download roku-ds-video.zip. Do not unzip it.
3. Remember where the ZIP file downloads; you will upload this file to the Roku installer.

## 2. Open Developer Mode on Your Roku TV


### Developer Mode remote sequence



Enter this sequence from the Roku home screen.


Remote sequence that opens the Developer Settings screen.

4. On the Roku home screen, enter this remote sequence: Home, Home, Home, Up, Up, Right, Left, Right, Left, Right.
5. When the Developer Settings screen appears, write down the Roku device URL shown on screen. It usually looks like `http://ROKU_IP_ADDRESS`.
6. Select the option to enable the Development Application Installer.
7. Read and accept the Developer Tools License Agreement.
8. Create the installer password. Passwords are case-sensitive.
9. Let the Roku reboot. After it restarts, it is ready for sideloading.



Developer Settings: note the URL, enable the installer, then set the password.


### 3. Sideload the App



Roku browser installer screen: upload the ZIP, then install with zip or squashfs.


10. On your computer, open a browser and go to the Roku URL you wrote down.
11. Log in with username `rokudev` and the password you created above.
12. On the Development Application Installer page, click Upload and choose `roku-ds-video.zip`.
13. Click Install with zip or Install with squashfs.

- Wait for the upload to finish. The sideloaded app appears on the Roku home screen as the development channel.



Roku home screen after install: open the Development channel tile.

## 4. Open the App and Log In



Roku app login screen. Fill in the blank fields with the NAS details provided to you.

- Open the Synology DS Video development channel on the Roku.
- Fill in NAS Address, Port, Username, and Password. Leave Protocol as HTTPS unless instructed otherwise.
- Use Transcode Port 8099 unless instructed otherwise.
- Select Login.

## Important Notes

- Only one development app can be sideloaded at a time. Installing another development app replaces the current one.
- If Roku reports that the same package is already installed, delete the development app from the installer page and install again.
- If the browser cannot reach the Roku URL, confirm the Roku and computer are on the same network and that the Roku is still in developer mode.

Source: Roku Developer Docs, Activating developer mode, <https://developer.roku.com/dev/docs/developer-setup>