# Riding in the Rainy Season: Plaewlom Rain Pause FAQ

Plaewlom Mobility Co., Ltd., Chiang Mai · Plaew Help Centre · Ref. PLM-HC-0218 · Version 3.0 · Updated 8 September 2026

This article explains what happens to your Plaew e-scooter ride when heavy rain, strong wind or flooding makes riding unsafe in Chiang Mai. It applies to all Plaew S4 and older Plaew S3 scooters in our Chiang Mai service area. It replaces Version 2.2 of June 2025.

## 1. What a Rain Pause is

### What is a Rain Pause?

A Rain Pause is a temporary stop to new rides in all or part of the service area. The map turns grey in the affected area, the Unlock button is disabled, and scooters already on the road show a warning on the handlebar display.

### When is a Rain Pause started?

We start a Rain Pause when any of our 14 roadside weather sensors records rainfall of 8 mm or more in one hour, or wind gusts of 50 km/h or more. Until 31 May 2026 the rainfall trigger was 15 mm per hour; we lowered it after a review of wet-weather falls during the 2025 season. A Rain Pause is also started for a single district when water stands on a road in that district, even if the rain has stopped.

### Who decides to start and end a Rain Pause?

The decision is made by the Duty Operations Controller in the Plaewlom Control Room on Huay Kaew Road, which is staffed from 05:30 to 01:00 every day. A person always confirms the pause and decides when it ends. Outside staffed hours the system starts a pause on its own when a trigger is reached, and it stays on until the first controller of the morning shift lifts it. Ride credits are handled by the Rider Care team (section 3).

### How long does a Rain Pause last?

A pause lasts at least 30 minutes. It ends when the rainfall has stayed below 4 mm per hour for 20 minutes in a row and no road in the area is reported as flooded.

## 2. If you are already riding

### Will my scooter stop suddenly?

No. Your scooter never switches off in motion. When a pause begins, the top speed of the scooter is reduced from 20 km/h to 12 km/h and the display shows a blue rain symbol. Please end the ride as soon as it is safe to do so.

### Do I keep paying per minute?

The normal fare is 10 baht to unlock plus 3 baht per minute. During a Rain Pause the per-minute charge stops automatically 15 minutes after the pause begins, so a ride that continues longer is not charged for

Fictional document created for testing a question-answering system. All names, figures and organisations are invented.

the extra time. The unlock fee is never refunded once the ride has started.

> **Note.** Plaew Pass holders (399 baht per 30 days) already ride without a per-minute charge for the first 45 minutes of each ride. If a single Rain Pause lasts more than 6 hours, your Pass is extended by one day automatically.

### Where can I end my ride during a pause?

During a Rain Pause the usual rule that rides must end inside a purple parking zone is relaxed. You may end your ride on any pavement at least 1.5 metres wide, as long as the scooter does not block a doorway, a bus stop or a ramp. The normal out-of-zone parking fee of 100 baht is waived for rides that end within 60 minutes of the start of the pause.

This relaxation does not apply in Red Flood Zones. They include the riverside roads along the Ping River between Nawarat Bridge and Iron Bridge, the underpass at Khuang Singh intersection and the low section of Wua Lai Road. Ending a ride inside a Red Flood Zone costs 300 baht at any time, because our team must recover the scooter before the water rises.

### What if my battery runs out during a pause?

If the battery level falls below 5 % during a Rain Pause, you may end the ride wherever you are, including inside a Red Flood Zone, and neither the 100-baht nor the 300-baht fee is charged. To qualify, report the low battery through the app within 30 minutes of ending the ride and attach a photo of the parked scooter. Without the report within 30 minutes, the normal fees apply.

## 3. Ride credits and refunds

### Can I get credit for a ride cut short by a Rain Pause?

Yes. If you had to end a ride early because of a pause, you can receive a ride credit equal to the time charges of that ride, up to 60 baht per ride. Credits are added to your Plaew wallet, cannot be paid out in cash and expire 90 days after they are issued.

### How do I claim the credit?

1. Open the Plaew app and go to Account > Ride history.
2. Choose the affected ride and tap Report a problem > Ride ended by Rain Pause.
3. Add a short description of where you stopped. A photo is optional unless you parked inside a Red Flood Zone.
4. Send the claim no later than 7 days after the ride. Claims sent after 7 days are not accepted.

The Rider Care team reviews claims within 2 working days and sends the result to your registered email address.

## 4. Safety and contact

Plaew scooters are rated IPX5 and can be ridden in light rain, but never through standing water deeper than 5 cm. If you see a Plaew scooter lying in floodwater or blocking a road, report it in the app under Report a scooter, or call Rider Care on 053 118 460 (06:00 to 24:00).

Fictional document created for testing a question-answering system. All names, figures and organisations are invented.