
8-BIT
JOYSTICK
UP
LEFT
RIGHT
DOWN
SELECT
START
FIRE
ARM


1
4
3
2
SELECT
START
6
5


7
9
0
8
SELECT
START
Rs
*