
## Module2

Arunsundar Kannan and Sarah Stephany

## Programming using mbed API:

Changing button1.fall to button1.rise doesn't affect the outcome, just changes the interrupt trigger.



## Analog input and output:

The slope of the wave will change by increasing/decreasing i.

```
potentiometer 2: 0.812698
potentiometer 1: 0.999512
potentiometer 1: 0.999512
potentiometer 1: 0.999512
potentiometer 1: 0.999512
potentiometer 2: 0.814652
potentiometer 2: 0.814652
potentiometer 1: 0.286935
potentiometer 2: 0.814652
potentiometer 1: 0.993040
potentiometer 2: 0.814652
potentiometer 2: 0.814652
potentiometer 1: 0.093733
potentiometer 2: 0.814164
potentiometer 1: 0.093773
potentiometer 1: 0.993040
potentiometer 2: 0.599756
potentiometer 2: 0.601709
potentiometer 1: 0.094017
potentiometer 1: 0.094017
potentiometer 2: 0.601709
potentiometer 1: 0.093773
potentiometer 2: 0.601709
potentiometer 2: 0.601709
potentiometer 2: 0.6017709
potentiometer 2: 0.6017709
potentiometer 2: 0.6993773
potentiometer 2: 0.599267
```

## Serial Communication:

```
File Edit Setup Control Window Help
Hello mbed
temperature: 25.187500 degree C
temperature: 25.250000 degree C
temperature: 25.562500 degree C
temperature: 25.362500 degree C
temperature: 26.312500 degree C
temperature: 26.875000 degree C
temperature: 26.875000 degree C
temperature: 26.875000 degree C
temperature: 26.500000 degree C
temperature: 26.500000 degree C
temperature: 26.500000 degree C
temperature: 26.500000 degree C
temperature: 26.250000 degree C
temperature: 26.375000 degree C
temperature: 26.250000 degree C
temperature: 26.375000 degree C
```

