

Patal - true-scale check

Print at 100%. Turn off 'fit to page', 'shrink oversized pages' and any scaling.

Set the printer driver's paper size to the same size as this PDF - a Letter tray printing an A4 document silently shrinks it by about 6%, and no scaling setting in the print dialog will say so.

Then measure the two rules below from the corner, and the square on every sheet.

down the page: 200 mm from the corner to this tick

page 210 x 297 mm, margin 10 mm, overlap 10 mm

1 piece(s), no nesting - one grid per piece

Golden Panel: 2 x 2 sheets, seam allowance 12 mm

across the page: 186 mm from this corner to the tick

x0y2

x1y2

x0y1

x1y1

50mm calibration square - DO NOT CUT

Measure it. If it is not 50mm, the print is scaled and the pattern is wrong.

Golden Panel - sheet 1 of 4 (column 1 of 2, row 1 of 2)

solid = cut line (seam allowance 12 mm). dashed grey = sewing line.

Assembly: overlap the crosses, do not trim. Matching labels (x1y0) must coincide.

x1y2

x2y2

x1y1

x2y1

50mm calibration square - DO NOT CUT

Measure it. If it is not 50mm, the print is scaled and the pattern is wrong.

Golden Panel - sheet 2 of 4 (column 2 of 2, row 1 of 2)

solid = cut line (seam allowance 12 mm). dashed grey = sewing line.

Assembly: overlap the crosses, do not trim. Matching labels (x1y0) must coincide.

x0y1

x1y1

x0y0

x1y0

50mm calibration square - DO NOT CUT

Measure it. If it is not 50mm, the print is scaled and the pattern is wrong.

Golden Panel - sheet 3 of 4 (column 1 of 2, row 2 of 2)

solid = cut line (seam allowance 12 mm). dashed grey = sewing line.

Assembly: overlap the crosses, do not trim. Matching labels (x1y0) must coincide.

x1y1

x2y1

x1y0

x2y0

50mm calibration square - DO NOT CUT

Measure it. If it is not 50mm, the print is scaled and the pattern is wrong.

Golden Panel - sheet 4 of 4 (column 2 of 2, row 2 of 2)

solid = cut line (seam allowance 12 mm). dashed grey = sewing line.

Assembly: overlap the crosses, do not trim. Matching labels (x1y0) must coincide.