MG-02 Landholder bore assessment and make good

Tarrabool Resources, Kelvale Mine

Revision	Effective	Owner	Approved	Next review
3	01/03/2026	Principal hydrogeologist	General manager, Kelvale Mine	March 2028

1 Purpose and scope

1.1 This procedure sets how Kelvale Mine assesses landholder bores around the mine and makes good a bore whose capacity has been impaired by the mine's take of associated water.

1.2 It applies to the landholder bores in the Kelvale Mine landholder bore register. The other bores in the monitoring network, the state reference bores and the mine's own monitoring bores, are outside its scope.

2 Water levels

2.1 A static level is a water level read with the bore's pump off for at least 12 hours. A reading taken with the pump running is a pumped level and is not used under this procedure.

2.2 A reduced level (m AHD) is the elevation of the measuring point in force on the reading date, less the depth to water below it.

2.3 A logged bore's daily level is the mean of the day's logger readings, each compensated for air pressure, over the day in Queensland time.

2.4 A bore's assessment level is the mean of its static levels in the assessment month: its daily levels where the bore has a logger, its manual dips otherwise.

3 Trigger thresholds

3.1 The trigger threshold for a bore is set by the class of the aquifer it draws from: 2 m for an unconsolidated aquifer and 5 m for a consolidated aquifer.

4 Impaired capacity

4.1 A bore has impaired capacity when the decline in its water level caused by the mine's take of associated water, at its assessment level, exceeds the trigger threshold for its aquifer. A decline with another cause is not the mine's.

4.2 The assessment month for a bore under a complaint is the last complete month before the assessment.

4.3 The principal hydrogeologist assesses each bore and recommends offers to the executive team, which approves them.

5 Baseline assessments

5.1 Before the take began, each bore in the register received a baseline assessment recording its construction, static level, yield and water quality.

6 Make good

6.1 Where a bore has impaired capacity, the mine offers its owner a make-good agreement. There is one agreement per owner, covering every bore of the owner's that has impaired capacity.

6.2 A make-good agreement may provide for deepening or replacing the bore, lowering the pump, or supplying water while the bore is restored.

7 Complaints

7.1 A landholder who believes a bore has been affected by the mine may complain by phone, email, letter or in person. The complaint is recorded in the register and the bore is assessed under section 4.

Revision history

Revision	Date	Change
3	01/03/2026	One agreement per owner (6.1); make-good measures (6.2)

2	14/03/2023	Logged bores' daily levels (2.3) and assessment levels (2.4)
1	07/03/2022	First issue, for the baseline assessments before the take of associated water

Distribution: environment; mining; general manager's office. The current revision is on the site document register.