

Clothes Drying Rack - Assembly Instructions

Welcome to your 3D-Printed Clothes Drying Rack! No glue or metal screws required –everything threads together by hand.

Part Checklist

- * **Leg Segments**: Long rectangular tubes with a threaded peg on one end.
- * **Drying Rods**: Long rounded tubes with a threaded peg on one end.
- * **X-Frame Hinges**: Top and bottom hinge arms, plus the threaded pivot pin.
- * **T-Brackets**: L-shaped blocks with three threaded holes.
- * **Adapter Pins**: Short pins with threads on both sides.
- * **Caps**: Rubber-style foot caps for the base, and domed caps for the rod ends.

Step 1: Build the X-Frame Hinges

1. Take one **Bottom Hinge Arm** and one **Top Hinge Arm**.
 2. Align their central circular holes so they form an X shape.
 3. Insert the **Pivot Pin** through both holes.
 4. Twist the pin tightly to lock the hinge together.
- *(Repeat to build the second X-Frame hinge).*

Step 2: Assemble the Legs

1. Take your **Leg Segments** and screw them end-to-end to build four long legs for each X-Frame.
2. Screw the top of each completed leg into the four threaded arms of the **X-Frame Hinges**.
3. **Important**: As you tighten, align the flat rectangular sides so the leg looks smooth and continuous.

Step 3: Attach Brackets and Feet

1. At the very bottom of each leg, slide on a **Foot Cap**.
2. Halfway down the leg, insert a **T-Bracket** inline between two leg segments. (This will hold the middle stability bar).
3. At the very top of each leg, screw on a **T-Bracket** facing inward.

Step 4: Build the Horizontal Rods

1. Take your **Drying Rods** and screw them end-to-end to create your 3 main spanning rods, plus 1 middle stability bar.
2. At the flat end of each finished rod, screw in an **Adapter Pin** so that both ends of the rod have a protruding male thread.

Step 5: Final Assembly

1. Stand both completed X-Frames upright, facing each other.
2. Screw the **Middle Stability Bar** into the midway T-Brackets to connect the two frames.
3. Screw the **Top Drying Rods** into the side holes of the top T-Brackets.
4. Finally, cap off any open upward-facing holes on the top T-brackets using the **Rod End Caps**.

****You're done! Your clothes drying rack is fully assembled and ready for laundry day.****