

Modular Clothes Drying Rack

Assembly Instructions

Welcome! This modular clothes drying rack requires no glue or external hardware. All parts easily screw together.

Step 1: Build the X-Frame Central Hinges

Files: `part_02_xframe_hinge_bottom.py`, `part_03_xframe_hinge_top.py`,
`part_04_xframe_hinge_pin.py`

Take the Hinge Bottom, Hinge Top, and Hinge Pin. Align the two hinge halves and screw the pin through the center to secure them. Make two of these (Left and Right).

Step 2: Construct the Leg Segments

File: `part_01_leg_segment.py`

Take two Leg Segments and screw them together to create a long leg. Attach the legs to the 4 arms of each X-Frame Hinge.

Step 3: Attach the Universal T-Brackets

File: `part_05_top_l_bracket.py`

Screw a Universal T-Bracket onto the top of each leg. Place an additional T-Bracket in the middle of the back legs for the stability bar.

Step 4: Connect the Drying Rods

File: `part_06_drying_rod.py`

Screw two Drying Rod segments together to form one full-width rod. Insert the full-width rods into the T-Brackets to connect the Left and Right X-frames. You will attach 3 drying rods at the top and 1 stability bar at the mid-height.

Step 5: Finish with End Caps and Foot Caps

Modular Clothes Drying Rack

Assembly Instructions

Files: `part_08_foot_cap.py`, `part_09_rod_end_cap.py`

Slide the Anti-Slip Foot Caps onto the bottom of the 4 legs. Use the Rod End Caps to plug any exposed sockets at the top corners.