

SmartHome Hub X500 User Manual

Model: X500-PRO | Serial Number Location: Bottom of device

Thank you for purchasing the SmartHome Hub X500. This manual will guide you through setup, features, and troubleshooting.

Package Contents

1x SmartHome Hub X500, 1x Power Adapter (12V/2A), 1x Ethernet Cable (6ft), 1x Quick Start Guide, 1x Warranty Card

Technical Specifications

Processor: Quad-core ARM Cortex-A53 @ 1.8GHz | Memory: 2GB DDR4 RAM | Storage: 16GB eMMC | Connectivity: WiFi 6 (802.11ax), Bluetooth 5.2, Zigbee 3.0, Z-Wave Plus, Thread | Ports: 2x USB 3.0, 1x Gigabit Ethernet, 1x HDMI 2.0

Power: 12V DC, 2A | Dimensions: 5.5" x 5.5" x 1.5" | Weight: 0.8 lbs | Operating Temperature: 32F to 104F (0C to 40C)

Initial Setup

Step 1: Connect the power adapter to the hub and plug into a wall outlet. The status LED will turn amber during boot.

Step 2: Wait 60 seconds for the hub to fully boot. The LED will turn solid blue when ready.

Step 3: Download the SmartHome app from the App Store or Google Play. Create an account or sign in.

Step 4: In the app, tap "Add Device" then "SmartHome Hub". Follow the on-screen instructions to connect to your WiFi network.

Step 5: The hub will automatically update its firmware. This may take 5-10 minutes. Do not unplug during updates.

Adding Smart Devices

Zigbee Devices: In the app, go to Settings > Add Device > Zigbee. Put your device in pairing mode and it will appear automatically.

Z-Wave Devices: Go to Settings > Add Device > Z-Wave. Tap "Include" and activate pairing on your device within 30 seconds.

Troubleshooting

Hub not powering on: Verify the power adapter is firmly connected. Try a different outlet. Check that the outlet has power.

Cannot connect to WiFi: Ensure your WiFi password is correct. The hub only supports 2.4GHz networks for initial setup. Move closer to your router.

Device not pairing: Reset the device and try again. Ensure the device is within 10 feet of the hub during pairing. Check device battery level.

Hub offline in app: Check your internet connection. Restart your router. Power cycle the hub by unplugging for 30 seconds.

LED Status Indicators

Solid Blue: Normal operation, connected to cloud | Blinking Blue: Firmware update in progress | Solid Amber: Booting up | Blinking Amber: Pairing mode | Solid Red: Error - contact support | Blinking Red: No internet connection

Warranty Information

The SmartHome Hub X500 is covered by a 2-year limited warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover: damage from accidents, misuse, or unauthorized modifications; cosmetic damage; damage from power surges; normal wear and tear.

To make a warranty claim, contact support@smarthomeinc.com with your proof of purchase and serial number.

Safety Information

Do not expose to water or moisture. Do not block ventilation openings. Use only the included power adapter. Keep away from heat sources. Not intended for outdoor use.

Support Contact

Technical Support: 1-800-SMART-HUB (1-800-762-7848) | Email: support@smarthomeinc.com | Website: www.smarthomeinc.com/support

Support Hours: Monday-Friday 8AM-8PM EST, Saturday 10AM-6PM EST

SmartHome Inc. | 1200 Innovation Way, Austin, TX 78701