



A decorative graphic on the left side of the page. It features a thick, dark blue vertical bar. A horizontal blue arrow points to the right, originating from the vertical bar. At the bottom, several thin, light blue curved lines sweep upwards and to the right.

Portfolio Management in Maximo Real Estate and Facilities

IBM Maximo Real Estate and Facilities

System Details

Build Number
402158

Platform Version
9.1.3

Application Version
11.6


Table of Contents

Overview.....	3
Managing and Creating People.....	4
Onboarding an user in Real Estate & Facilities	4
Managing and Setting a Hierarchy or Location	13
<i>Creating a Location in Real Estate & Facilities</i>	<i>13</i>
Asset Creation and tagging to the building	20
<i>Creating an Asset in Real Estate & Facilities</i>	<i>20</i>
End.....	22

Overview

Portfolio data forms the foundation for managing workplaces. It includes key information about the organizations, locations, people, and assets connected to the spaces you oversee. In MREF, portfolio data records help you maintain the details needed to perform tasks across other applications. For instance, when planning space allocations or relocating personnel, you rely on accurate and comprehensive data about the relevant spaces and individuals. These portfolio data records are structured hierarchically and can be linked to other records. Each record's lifecycle events can be tracked, providing a complete history and audit trail. Real Estate Environmental Sustainability extends portfolio management by adding sections and features related to business objects such as My Company, Building, Land, Structure, and Retail Location.

All records in the Portfolio Data Manager follow the same set of states and actions. States are the major steps in the lifecycle of the record and the actions trigger state changes.





Managing and Creating People

People are resources that are managed in relation to their space and asset allocations. People can include employees, consultants, and external contacts such as vendors and suppliers.

Using people records, you can track and monitor resources. You assign people to organizations and spaces, and you can associate assets with them. This information supports various processes, such as managing spaces and moves. For example, you might maintain a list of all employees in a particular building and track details such as their work location, project allocation, and assigned assets. You can also manage a person's work schedule and availability.

To grant someone access to MREF applications, that person must be a valid user in the system. You define the person as an MREF user in their Employee, Consultant, or External Contact record.

Every active user has a My Profile record, which can be accessed from their portal home page. The My Profile allows users to personalize settings such as: Date and time format, Default time zone and currency, Graph display colors, Notification and reservation preferences. Changes made in the My Profile that overlap with the Employee, Consultant, or External Contact record will be automatically synchronized.




Exercise 1. Onboarding an user in Real Estate & Facilities


In this exercise You create people records to track and manage employees, contractors, and external contacts such as vendors or suppliers. You specify information that helps you manage day-to-day tasks and processes related to those individuals.

The type of information you provide when creating people records can vary based on the type of person. For example, you might enter details about who an employee reports to, but this information would not be required for an external contact.

1. Open the Maximo Application Suite.
2. Log in with the shared credentials. You will land to MAS Core page.
 - Username- **facilitiesadmin**
 - Password- **xxxxxxxxxx**



3. Click the navigation (hamburger ) menu, then expand the Security module under Suite and select the **Users** application.



Note: In MREF, user accounts are initially provisioned in MAS Core and assigned to the appropriate security groups. The accounts are then synchronized with the Real Estate and Facilities application.

4. The Users application opens in list view, displaying the existing user records. Click **Create User +** to add a new user.

Users								
Manage your suite users, their entitlements, and access rights.								
View: Default view (shared) Search Create user +								
☐	User ID	Person	Primary email	Access type	Entitlement	Status	Sync status	
☐	ABBY	ABBY		Concurrent	Base	Active	Complete	
☐	ADAMS	ADAMS	hanky14@hotmail.com	Concurrent	Base	Active	Complete	
☐	ALVIN	ALVIN		Concurrent	Base	Active	Complete	
☐	AMAN	AMAN	aman.white@mro.com	Concurrent	Base	Active	Complete	
☐	ANDY	ANDY	andy@hotmail.com	Concurrent	Limited	Active	Complete	
☐	BETHUNE	BETHUNE	dave.bethune@mro.com	Concurrent	Base	Active	Complete	
☐	BOUDRE...	BOUDREAU	jboudreau@hotmail.com	Concurrent	Base	Active	Complete	
☐	BPILLA	BPILLA	bob.pilla@mro.com	Concurrent	Base	Active	Complete	
☐	CALCOTT	CALCOTT	steve.calcott@mro.com	Concurrent	Base	Active	Complete	
☐	CALDONE	CALDONE	bob.caldone@mro.com	Concurrent	Base	Active	Complete	

5. Complete the mandatory fields for creating a user profile, including User ID, Name, Email, and Type. Set Authentication to Same as User ID, enable Custom Password, and enter the desired password. After all required fields are populated, click **Create & Continue to access**.

- User ID- **xxsmith** where "xx" represents your initials, followed by your last name.
- Name- **Brain Smith**
- Email- **briansmith@ibm.com**
- Email Type- **work**
- Password- based on your choice (Remember it for further login)

Users /

1. Identity & authentication 2. Access & license

Identity

Provide the information that is required to identify the user. You can also enter optional user information such as email, phone number, and address.

User ID

bsmith

Name

Brain Smith

Person ID

☒ Generate using User ID
☐ Use existing person
☐ Create person

Primary email

briansmith@ibm.com

Primary email type

WORK

Account status

User details

Contact information

Preferences

Authentication

Select the authentication type and provide login details for the user.

Local

Username

☒ Same as User ID
☐ Same as primary email
☐ Custom

Password

☐ Autogenerated
☒ Custom

☐ Send password by email

New password

Minimum password length: 15

Maximum password length: 35

Confirm password

Cancel

Create & exit

Create & continue to access

6

- On the Authorize User page, set the Access Type to **Authorized**. Click the **Select groups** under Security groups to assign the required access to the user.

Users / Authorize user

1. Identity & authentication 2. Access & license

Access type

Specify whether the user is granted concurrent access or authorized access.

☐ Concurrent

☒ **Authorized**

Security groups

To grant the user access to applications, assign the user to security groups.

Results: 2

Name	Description	Default application	Independent	Module count	License impact	
DEFLTREG	New User		No	2	Self Service	☒
EVERYONE	All Maximo Users		No	2	Limited	☒

Items per page: 10 1-2 of 2 items 1 1 of 1 pages



Note: Two types of access can be assigned to users: Authorized and Concurrent.

- Authorized users consume and reserve a fixed number of AppPoints on a permanent basis.
- Concurrent users consume AppPoints only during their active session. The AppPoints are released automatically once the user logs out.

- Select all the security groups by clicking the checkbox and navigate to the next page. Once all security groups are selected click **OK**, and the group will be added to the user's Security Groups list.

Security Groups

80 items selected Results: 80 Search

☒	Name	Description	License impact	Modules Count
☒	SYSADMIN	System Admin	MAS-Base	9
☒	TECHNICIAN	Technician	MAS-Base	0
☒	TEXASITE	Texas Site	MAS-Limited	3
☒	TICKRESP	Ticket Response Group	MAS-Base	12
☒	TOOLMGR	Tool Manager	MAS-Limited	5
☒	USERMANAGEMENT	User Management	MAS-Base	0
☒	VIEQHQ	View Headquarters	MAS-Limited	4
☒	VPAPPROVAL	VP Approvals	MAS-Limited	3
☒	WCDESIGNER	Design Work Centers	MAS-Base	0
☒	WEATHERADMIN	Weather Configuration Administ	Self-Service	0

Items per page: 10 71-80 of 80 items 8 8 of 8 pages

Selected 80 Clear all

☒	ALLSITES	All Sites	MAS-Limited	3	☒
☒	ASSISTADMIN	Assist admin	Self-Service	0	☒
☒	ASSISTSTUDIOUSE...	Assist Studio Users	Self-Service	0	☒
☒	ASSISTTECHUSERS	Assist Technician U...	Self-Service	0	☒
☒	BEDFORDSITE	Bedford Site	MAS-Limited	3	☒
☒	BIZANALYST	Business Analyst	MAS-Base	0	☒
☒	COGNOSUSERS	Cognos Users	MAS-Limited	0	☒
☒	CONTRACTMGR	Contract Manager	MAS-Base	7	☒

Cancel OK

- Check on all the Additional access checkbox, Select **User** in IoT Role and **Premium** in Application Entitlement.

Additional access

For users that need administration access, you can set their administration privileges

- ☒ System configuration
- ☒ API key management
- ☒ IDP management

IoT role

Administrator ▼

Real Estate and Facilities access

Application entitlement

Premium ▼

9. Click on **Re-calculate license summary** to get the user account summary.

License summary

Summary may be out of date ×

Recent selections may have changed the license summary. Re-calculate for up-to-date information.

Re-calculate license summary ↻

This user	Explanation
Admin-Premium 15AppPoints are reserved	82 Security groups 21 Unique modules with edit 3 Solutions - Administrator access type - Premium access to real estate and facilities - Administrator access to IOT - Suite administrative access

10. Click on **Save & exit**. You will see the summary of user account. Click on **Users**.

[Users](#) / [Authorize user](#) /

View user BSSMITH

Last modified October 2025 by FACILITIESADMIN

1. Identity & authentication 2. Access & license

Identity

Created on 10/26/25 10:20:38 am	Created by FACILITIESADMIN	Status Active	Status Complete
User ID BSSMITH	Name Brain Smith		
User Name bssmith	Primary email briansmith@ibm.com	Primary email type WORK	
Person BSSMITH	Owner local		

Account status ▼

User details ▼


Contact information ▼

Preferences ▼

Authentication


Local ▼

11. To verify the user's synchronization status, click on **Actions** and select **View User Synchronization Status**.



	User ID	Person	Primary email	Access type	Entitlement	Status	Sync status
☐	ABBY	ABBY		Concurrent	Base	Active	Complete
☐	ADAMS	ADAMS	hankys4@hotmail.com	Concurrent	Base	Active	Complete
☐	ALVIN	ALVIN		Concurrent	Base	Active	Complete
☐	AMAN	AMAN	aman.white@mno.com	Concurrent	Base	Active	Complete
☐	ANDY	ANDY	andy@hotmail.com	Concurrent	Limited	Active	Complete
☐	BETHUNE	BETHUNE	dave.bethune@mno.com	Concurrent	Base	Active	Complete
☐	BOUDREAU	BOUDREAU	jboudreau@hotmail.com	Concurrent	Base	Active	Complete
☐	BPILLA	BPILLA	bob.pilla@mno.com	Concurrent	Base	Active	Complete
☐	CALCOTT	CALCOTT	steve.calcott@mno.com	Concurrent	Base	Active	Complete
☐	CALDONE	CALDONE	bob.caldone@mno.com	Concurrent	Base	Active	Complete

12. The User Management page opens. Search for the user **bssmith** and review the synchronization status. If the user is successfully activated and synchronized, a **green** check mark will be displayed.



Brain Smith
Last modified 26 October 2025 by FACILITIESADMIN
Active Synchronized

Identity

User ID	Username	Primary email	Owner
bssmith	bssmith	briansmith@ibm.com	Local
Authentication type	Created by	Created on	
Local	FACILITIESADMIN	26 October 2025 10:20	

Account status

User details

Contact information

Locale and time zone

Entitlement

Access Type	Application entitlement	Administration entitlement	Cost
Authorized	Premium	Premium	15 Reserved AppPoints


Access

System administration access
API key management, IDP management, System configuration

Application user synchronization

Application	Sync state	Last synced	Reason
Real Estate and Facilities	Success	26 October 2025 10:46	
Manage	Success	26 October 2025 10:46	
IoT	Success	26 October 2025 10:46	

13. Log out of Maximo, then log back in using the newly created user account **bssmith** to verify that the login is successful.



Log in to IBM Maximo Application Suite

Continue with local account

Username

bssmith


Password

Log in


☐ Remember username

[Forgot password?](#)

14. From the Navigation menu, launch the **Real Estate and Facilities** application.




15. Once the application opens, observe the home page indicating that the user has restricted access and has not been configured.



16. Logout of the application OR launch Real Estate and Facilities in new tab and login with admin user.

- Username- **facilitiesadmin**
- Password- **xxxxxxxxxx**

17. On the Facilities Admin home page, navigate to the Select Users section and open the user account **bssmith**.



18. In the Brain user profile, assign the required details and add the user to the below user groups by clicking **Find** and accepting the listed groups for Administrator level access.


- Menu: **TRIRIGA Global Menu**
- User Type: **Employee**
- Home Page: **Home - Application Administrator Portal**

19. Click on **Save & Close**.



Note: Steps 20-23 are optional. You can skip these steps if you don't want to edit or add any employee related information or access.

20. To revise user details or add more employee-related information, click the hamburger icon and navigate to **Portfolio → People → Employees**.



21. Open the user **bssmith**.

22. To enter additional user-related details, use the fields available on the **Employees** page to input the necessary information.

Employee: bssmith, bssmith - 1002552

General Contact Details Locations & Assets Move Locations Credentials **Profile** History Notifications Notes & Documents

(Optional): Use Maximo Application Suite to manage user account details. During the Maximo Application Suite user synchronization process, a workflow automatically creates a My Profile and Timesheet.

Maximo Real Estate and Facilities Account

User ID **BSSMITH**

Default Portal

Home Page **Home - Application Administrator Portal** Menu **TRIRIGA Global Menu**

Project Home Page **Project Menu**

Sitemap? ☐

Disable Company Level? ☐

Preferences

User Language **US English** Currency **US Dollars**

Share Reservations? ☐

23. After providing and validating all user details, ensure the user status is set to **Active**.

Employee: bssmith, bssmith - 1002552

General Contact Details Locations & Assets Move Locations Credentials Profile History Notifications Notes & Documents

(Required): Manage general information about the employee.

General

ID **1002552** Status **Active User** Image


Last Name **bssmith** First Name **bssmith**

Full Name **bssmith bssmith**

Prefix **X** Nick Name

24. Logout from admin credentials and Log in as the **bssmith** user and launch the **Real Estate and Facilities** application from the Navigation menu.

25. The user **bssmith** now sees the home page configured according to the Lease Manager role.





Managing and Setting a Hierarchy or Location

Locations represent the business sites that are owned or managed by your organization or by your customers' organizations. They can include properties, land, buildings, structures, floors, spaces, retail centres, or any other facilities that your organization occupies or oversees.

Location information is used throughout various processes in MREF such as space allocation, move management, and lease or contract management. Any location can be made reservable by selecting the Reservable option on the General tab of the location record. The **Reserve** tab allows you to define the reservation calendar, along with cost and usage unit details.

The **location structure** follows a hierarchical model. You can configure locations based on how they relate to one another, creating as many levels as needed to represent your organization's structure accurately. For instance, your organization may own several properties, each containing multiple buildings, which in turn include several floors and spaces within them.




Exercise 2. Creating a Location in Real Estate & Facilities


In this exercise, you'll create locations to represent places of business that you or your customers own or operate. You'll enter key information to help manage daily tasks and processes related to those locations. If you're using IBM TRIRIGA Connector for BIM or CAD Integrator/Publisher, locations can also be created automatically from drawings or models.

The details you enter will vary based on the type of location. For example, a building might include cost and environmental information, while a floor might include area measurements.

1. Login to Real Estate and Facilities application with your id:
 - Username- **bssmith**
 - Password- **xxxxxxxxxx**
 -
2. Click on the hamburger menu and open **Locations** under Portfolio module.




3. This interface serves as a location management dashboard designed to categorize and manage various types of real estate assets and facilities within an organization's portfolio.



Note: The hierarchical structure enables efficient organization, navigation, and access to location data across categories such as Offices, Campuses, Healthcare, and other key asset types.

4. Select **Locations** from the Hierarchy and then click on **New**. Select **Location Category** from the List.



5. Fill the General details for the location category and then **Create Draft -> Save -> Activate**.

- ID: **XX-DEMO-OFC** (Replace XX with your initials)
- Name: **Demo Offices**

Location Category: Create Draft

General Notifications System Workflow Instance Includes Reports Associations

(Required): Provide general information for this Location.

General

ID BS-DEMO-OFC Status

Name Demo Offices

Hierarchy Path

Location Category: Demo Offices Activate Save Save & Close More

General Notifications System Workflow Instance Includes Reports Associations

(Required): Provide general information for this Location.

General

ID BS-DEMO-OFC ID Status Draft

Name Demo Offices

Hierarchy Path \Locations\Demo Offices

6. Similarly Click on **Demo Offices** and then Click on **New** and Select **Location Category** from the list.

Portfolio / **Locations**

Hierarchy

Open New Delete Cut

- Locations
 - Airports (Location Category)
 - Alternate Locations (Location Category)
 - City Centers (Location Category)
 - Demo Offices (Location Category)**
 - Generation/Distribution Facilities (Location Category)
 - Government Locations (Location Category)
 - Healthcare (Location Category)
 - Land Parcels (Location Category)

Locations

Hierarchy

Open New Delete Cut

- Building
- External Retail Location
- Installation
- Land
- Location Category**
- Property
- Proposed Retail Location
- Proposed Site
- Retail Center
- Retail Location
- Structure

7. Fill the General details for the location category and then **Create Draft -> Save -> Activate**.

- ID: **XX- NA-OFC**
- Name: **North America**

Location Category: North America Activate Save Save & Close More

General Notifications System Workflow Instance Includes Reports Associations

(Required): Provide general information for this Location.

General

ID NA-OFC Status Draft

Name North America

Hierarchy Path \Locations\Demo Offices\North America

8. Click on **North America** and then Click on **New** and Select **Building** from the list.

Portfolio / **Locations**

Hierarchy

Open New Delete Cut

- Locations
 - Airports (Location Category)
 - Alternate Locations (Location Category)
 - City Centers (Location Category)
 - Demo Offices (Location Category)
 - North America (Location Category)**

Locations

Hierarchy

Open New Delete Cut

- Building**
- External Retail Location
- Installation
- Land
- Location Category
- Property
- Proposed Retail Location
- Proposed Site
- Retail Center
- Retail Location
- Structure

9. Fill all the building related general details as provided in the screenshot and then click on **Create Draft -> Save -> Activate.**

- ID: **XX-NA004**
- Name: **Charlotte Watson Center**

(Required): General Information for this Building.

General

ID

BS-NA004

Status

Name

Charlotte Watson Center

Description

Charlotte NC - Watson Center - 3800 W. Royal Lane

Hierarchy Path

Image

Details

Legal Name

Charlotte Watson Center

Common Name

Charlotte Watson Center

Parking Spaces (Open)

81

Parking Spaces (Covered)

0

Tenure

Leased

Building Class

Corporate Office

Headcount

0

Zoning

Commercial

Headcount (manual)

1116

Time Zone

(GMT -5) Eastern Time (US, Canada) [US/Eastern]

Total Area Occupied

0 square-feet

Primary Use

Headquarter

Total Area Occupied (manual)

125406.7721 square-feet

Jurisdiction

Local/Other

Environmental Details

Carbon Calculation Method

Actual Energy Use

Carbon Calculation Region

SERC Virginia/Carolina

Total CO2e (Carbon Footprint)

408,888,281.19 US Tons CO2

Certification Level

Total CO2e (Carbon Footprint) Equity Share

408,888,281.19 US Tons CO2

Equity Share (Percent)

100

Occupancy Rate (Percent)

100

Electric Metering Type

Company Pays Utilities

Yes

Weather Station

CHARLOTTE/DOUGLAS INTERNATIONAL, NC, US

Energy Reporting Exempt Status

Yes

Climate Zone

Moderate

Total Annual Utility Bills

\$130,006.82 US Dollars

Climate Division

Humid Subtropical

Annual Energy Use

5161649.386 kilowatt-hours

Carbon Calculation Needed

☒

Last Update

Cost Summary

Annual Cost of Operations

\$39,875.00 US Dollars

Annual Lease Costs

\$99,398.00 US Dollars

Annual Fixed Assets Costs

\$13,987.00 US Dollars

Restrictions

Find Remove

Building Class Data Attributes

Accounting Cost Code Details

Accounting Cost Center

1052

Service Code Group

US Chart of Accounts

Accounting Organizations

Find Remove

Organizations

☐	!	Name	ID	Status
☐		GreenPoint	GP	Revision In Progress

Items per page: 10 1 - 1 of 1 items 1 of 1 pages

Location Status

In Service

07/01/2007

Actual Retirement

Primary Address

Geocode Address

Address

555 South College Street

Zip/Postal Code

28078

Geography Lookup

/Geography/North America/United States/North Carolina/Charlotte

City

Charlotte

State/Province

North Carolina

Country

United States

GIS Latitude

35.3395

GIS Longitude

-80.7668

Country Code

Primary Phone Numbers

Main Phone

704-555-5555

Main Fax

704-555-6666

Reporting

Parent Property



Hint: Download and attach the image for the IBM Software Labs

10. Click on **Charlotte Watson Center** and then Click on **New** and Select **Floor** from the list.

Portfolio / Locations

Hierarchy

Locations Open New Delete Cut

- Locations
 - Airports (Location Category)
 - Alternate Locations (Location Category)
 - City Centers (Location Category)
 - Demo Offices (Location Category)
 - North America (Location Category)
 - Charlotte Watson Center (Building)

Portfolio / Locations

Hierarchy

Open New Delete Cut

Floor

Vertical Shaft

11. Fill all general details for the First Floor of the building as provided in the screenshot and then click on **Create Draft -> Save -> Activate**.

- ID: **XX-NA004-01**
- Name: **01-First Floor**

Floor

General Contact Details Graphic Dynamic Space Planning Allocation Area Measurements Contracts Regulatory Maintenance History Notifications Notes & Documents Sy

(Required: General information for this floor)

General

ID BS-NA004-01 Status Image

Name 01 - First Floor

Description First Floor

Hierarchy Path

Details

Bar Code Entry Control Number

Floor Level 1 Floor Maintained

Ground Level Exit Capacity 178

Cost per Sq Unit \$35.00 US Dollars Headcount 0

Tenure Leased

Floor Class Office

Primary Use Office

Accounting Cost Center BS-NA004-01

Units

Currency US Dollars Area Units square-feet Length Units feet

Floor Measurements

Gross Area 31,192.68 square-feet Gross Measured Area 30,610.17 square-feet



Location Graphic

Reporting

Parent Property Parent Building Charlotte Watson Center

Location Status

12. Click on **01 – First Floor** and then Click on **New** and Select **Space** from the list.



13. Complete all the space details in the General tab as shown in the screenshot. Once finished, click on **Create Draft**.

- ID: **XX-01-A020**
- Name: **01-A020**

Hint: Download and attach the image for the space

14. You will be redirected to the **Reserve** tab of the space. Enter the reservation details as shown in the screenshot.

Space: 01-A020

General Contact Details Graphic Details Allocation Finishes Regulatory **Reserve** Maintenance History

(Required): Reserve.

General Information

Building [Charlotte Watson Center](#) Image

Floor [01 - First Floor](#)

Reserve Display Room Name [Run DMC](#)

Area [184.02 square-foot](#)

Default Capacity [1](#)

Time Zone [\(GMT -5\) Eastern Time \(US, Canada\) \[US/Eastern\]](#)

Layout Details

Default Layout [Workspace](#)

Reservation Class

Name [Reservable](#)

Description [No Approval Required](#)

Reserve Administration

Room Type [Meeting Space](#) [Workspace](#) Work Space Entitlement

Reserve Calendar [Reservation Calendar - 24 Hour Day \(Sunday-Saturday\)](#)

Reservation Group [Watson Buildings - Hoteling Spaces](#)

Advance Booking Period [0](#) Reserve Cut-Off Duration

Send Confirmation ☐

Check In Required ☐ Do Not Allow Series Reservations

Welcome Message

15. After filling in all the details, click on **Create Draft**. An attention message will then appear on the screen.

Attention!

Since you have designated this space as Reservable for reservation, you must set up at least one contact with the role of Reservation Coordinator. Please update the Contacts section to include a Reservation Coordinator.

16. Open Contact Details Tab and add a Reservation Coordinator. Then click on **Create Draft -> Save -> Activate**.

Space: 01-A020

General **Contact Details** Graphic Details Allocation Finishes Regulatory Reserve Maintenance History


(Optional): Contact Details for this Space.

Contacts

!	Role	Person	Work Phone	Fax	Email	Primary Organization
	Reservation Coordinator	Anita Meeting	(702) 833-1234	(702) 833-1234	ameeting@IBMSmarterBuil...	Conference Services

Items per page: 35 1 - 1 of 1 items

17. The hierarchy for the demo office has been successfully created.





Asset Creation and tagging to the building

Assets are owned or leased items, such as equipment, technology, tools, or furniture, that people use at a location within an organization.

Assets are unique instances of items and are associated with specifications. Specifications are used to categorize the assets. You use information about assets when you complete many business processes within MREF. For example, managing inventory, managing spaces and moves, and managing contracts all involve assets. Therefore, you set up your assets first before you complete other processes.

When you create an asset, you can associate it with an organization, with a primary location within the organization, and with the people who use it.

Any asset can be made available to be reserved if the Reservable field is selected on the General tab for the asset. Use the Reserve tab to set the reservation availability calendar and the cost and usage units details.




Exercise 3. Creating an Asset in Real Estate & Facilities

In this exercise, you'll create an asset to represent a real leased or owned property. You'll enter details that help manage daily tasks and activities related to that asset.

The kind of information you enter depends on the type of asset. For example, you might include environmental details for office equipment, but not for something simple like keys.

1. Login to Real Estate and Facilities application with your id:
 - Username- **bssmith**
 - Password- **xxxxxxxxxx**
2. Click on the hamburger menu and open **Building Equipment** under Portfolio module.



3. Click on **Add** to create a new asset.



4. Fill all the general details as per the screenshot for the **Asset: Mechanical Equipment Hydronic Fin-Tube Radiator** installed on the first floor of Charlotte Watson center and click on **Create Draft -> Save -> Activate**.

- ID- **XX-RAD-01**(Replace XX with your initials)
- Name- **XX Mechanical Equipment Hydronic Fin-Tube Radiator**

 A screenshot of a detailed form for 'Building Equipment: BS-RAD-01-BS Mechanical Equipment Hydronic Fin-Tube Radiator'. The form has tabs for General, Details, Graphics, Contracts, Assessment, Environmental, Operating Schedule, Maintenance, History, Notifications, Notes & Documents, System, 3D Model, Calendar, and Workflow. The 'General' tab is active, showing fields for ID (BS-RAD-01), Name (BS Mechanical Equipment Hydronic Fin-Tube Radiator), Status (Draft), and Image. The 'Details' tab is also visible, showing fields for Serial Number, Bar Code Entry, Condition (Excellent), Reservable, Maintenance Priority, Organization, and Primary Location. The 'Spec Information' section shows Specification Name (Mechanical Equipment), Spec ID (EQ-1000143), Spec Class (HVAC Equipment), and Model Number. The 'Spec Class Data Attributes' section is empty. The 'Asset Status' section shows In Service Date (01/01/2022) and Asset Status (Available).


Hint: Download and attach the image for the asset





Note: Specifications are detailed attributes or characteristics that describe an asset. They provide important information such as size, capacity, material, or performance details, depending on the type of asset. These details help in managing maintenance, compliance, and overall asset performance.

Its mandatory to have a Specification Name created before Asset Creation in MREF.

5. Once Asset gets activated it will start reflecting in the List View assigned to the building -> Floor -> Space.

Portfolio / Assets / Building Equipment						
Building Equipment						
Asset Name: BS x Clear Filters						
☐	Image	Asset Name	Spec Class	Brand	Building	Space
		BS	Contains	Contains	Contains	Contains
☐		BS Mechanical Equipm...	HVAC Equipment		Charlotte Watson Center	01 - First Floor 01-A020

-----END-----

References:

https://www.ibm.com/docs/en/SSFCZ3_11.6/pdf/pdf_tri_portfolio_mng.pdf