

FlexTrack Heart Rate Chest Strap - User Manual

Document date: 2024-08-23

Box Contents

Your FlexTrack Heart Rate Chest Strap order includes:

- Main device or item
- Charging cable (for electronic items) or assembly hardware (for equipment)
- Quick start guide
- Warranty information

Initial Setup

For the FlexTrack Heart Rate Chest Strap:

Electronic devices: Charge fully before first use. Download the MarketSphere FlexTrack app from your device's app store. Pair the device through the app following on-screen instructions.

Equipment: Assemble per the included instructions. Verify all hardware is fully tightened before use.

Using the Device

Follow the in-app onboarding flow for electronic items.

For smart watches and bands:

- Sync data daily with the app
- Adjust strap to be snug but comfortable (you should be able to fit one finger between the band and your wrist)
- Wear the device 1-2 finger widths above your wrist bone for accurate heart rate readings

For equipment:

- Start with lower resistance or weight than you think you need
- Use proper form; consult included exercise guide
- Allow rest days between intense sessions

App Features

The FlexTrack app provides:

- Daily activity summary (steps, calories, sleep)
- Workout logging with auto-detection of common exercises
- Heart rate zones during workouts
- Goal setting and tracking
- Social features (challenges with friends)
- Sleep tracking with stages
- Stress monitoring (premium feature)
- Recovery scoring (premium feature)

Battery Life and Charging

Battery life varies by usage:

- Smart watch series 5: up to 7 days normal use, 24 hours with continuous GPS
- Fitness band: up to 14 days
- Heart rate chest strap: up to 12 months on replaceable coin cell battery

Charge using only the included cable or a USB-A port providing 5V/0.5A or compliant USB-C port.

Water Resistance

Water resistance ratings:

- Smart watch series 5: 5 ATM (suitable for swimming in shallow water)
- Fitness band: IP68 (splash and rain resistant)
- Heart rate chest strap: IPX7 (splash resistant only)

Not rated for:

- Hot tubs, saunas (heat affects seals)
- Diving, water sports involving high water pressure
- Soap, shampoo, or chemical exposure (may degrade seals over time)

Care and Maintenance

Wipe device after sweaty workouts. Rinse with fresh water after pool or ocean use.

For equipment:

- Inspect hardware periodically; tighten if needed
- Clean grip surfaces with mild soap and damp cloth
- Store equipment dry and away from extreme temperatures

Replace bands and worn components as needed. Replacement parts available at marketsphere.example/parts.

Troubleshooting

****Device won't pair**:** Ensure Bluetooth is enabled on your phone. Verify the device is charged. Force-close and reopen the FlexTrack app. Restart the device by holding the button for 15 seconds.

****Heart rate readings seem incorrect**:** Check fit (snug but not tight). Ensure the sensor is in direct skin contact. Clean the sensor and your skin. For chest straps, slightly moisten the contact pads.

****Step count seems too high or low**:** Calibrate via the app under Settings > Calibrate. Wear on your non-dominant wrist for best results.

Warranty

Electronic FlexTrack devices include a 1-year limited warranty. Equipment carries a 2-year warranty against defects.

Not covered: damage from impact (dropping), chemical exposure, unauthorized modifications, or use beyond the device's rated capacity (e.g., diving with a swim-rated watch).

File warranty claims at marketsphere.example/warranty.

Specifications

(Specific to each model - consult the spec sheet at [marketsphere.example/\[model SKU\]](https://marketsphere.example/[model SKU]))