Preventive Maintenance Schedule

Do the preventive maintenance once in a quarter.

Check the following points -

1 Guide greasing

2 Worm gear greasing

3 Bearing greasing

4 Gear box greasing

5 Check Slats

6 Check Bottom rubber gasket

7 Check Guide are OK

8 Check Worm gear drive

9 Check Hood cover

10 Check Bracket welding / fasteners

11 Check Guide welding / fasteners

12 Check Bottom profile

13 Check Gear box welding / fasteners

14 Check Spring tension

15 Check Lock is working properly