
IDLER ASSEMBLY FOR B0



SR NO	PART NAME	QUANTITY
1	SHAFT	2
2	ROLLER	2
3	ROLLER BEARING	4