❑ INDEX


NIHVA
NIHVA Technologies Pvt. Ltd.

- ✓ **SLIDE 2 & 3 : Pallet Construction**
- ✓ **SLIDE 4 : Pallet Lifter System Breakdown Provision**
- ✓ **SLIDE 5 : Pallet Lifter System Maintenance Provision**
- ✓ **SLIDE 6: Manual Sliding Provision for Pallets (Breakdown Condition)**


NIHVA Technologies Pvt. Ltd.

❑ Pallet Detail Construction -

NIHVA Technologies Pvt. Ltd.




PALLET TOP VIEW




PALLET BOTTOM VIEW

❑ Pallet Updated Detail Construction -


NIHVA Technologies Pvt. Ltd.




PALLET BOLTING ARRENGMENT




SIDE GUIDE ROLLER CONCEPT




BOTTOM SLIDING ROLLER CONCEPT



MALE LOCKING ARRENGMENT



FEMALE LOCKING ARRENGMENT




PALLET SLIDING NYLONE PLATE

❑ Manual Lifting System for Pallet Lifter Unit -

NIHVA Technologies Pvt. Ltd.

- ✓ **Unit Location –** To be Mount on the Pool Top
- ✓ **Purpose To Developed –** While Breakdown Happens in Lifter System
- ✓ **How To Used –** When breakdown occurred in Pallet system switch off the Main control panel . Then Take the handle and stick it in Manual Lifter Unit. Then manual Rotates as per the requirements.
- ✓ **Unit Specifications –** This Unit Made with the Bevel Right Angle Type Gear Box. It uses bevel gears and worm wheels .

  It is used to lift the lift system up and down smoothly .



NIHVA Technologies Pvt. Ltd.


❑ Maintenance Provision for Lifter System -

NIHVA Technologies Pvt. Ltd.

➢ **How it works ? _**

✓ If any problem occurred in lifter System then we can do dismantle all middle of pallets sections till get access bottom Drive Unit .

✓ If any problem occurred in Power Roller System then we can do dismantle of pallets sections as per our feasibility (only Top pallet sections) to get access of motor & Rollers




❑ Breakdown Provision to Slide the Pallets on Pool


NIHVA Technologies Pvt. Ltd.


- ✓ **Unit Location –** To be Mount on the Pool Top
- ✓ **Purpose To Developed –** While Breakdown Happens in Lifter System

  (Pool open & Close Side to Pull & Push The Pallet)
- ✓ **How To Used –** When breakdown occurred in Pallet system then switch off the Main control panel . Take the Manual Jacking system & Mount on Pallet Pool Close condition.Then Take two hooks of the system and stick them in the locks of the pallets . Then Operate as per requirement. same method on the Pool Open Condition.
- ✓ **Unit Specifications –** This Unit Made with the Bevel Straight Type Gear Box & Pulleys with easy change Over Mounting Provision .



Locking Hook System for Rope





Thank You !

NIHVA
NIHVA Technologies Pvt. Ltd.