OPERATION & MAINTENANCE MANUAL FOR GEAR OPERATED ROLLING SHUTTER

DESIGNED, DEVELOPED & MARKETED

BY

NIHVA

NIHVA Technologies Pvt. Ltd.

G-BLOCK, 1ST FLOOR, THERMAX CHOWK
MIDC, ABOVE RENAULT SHOWROOM
CHINCHWAD, PUNE-411019

TEL.NO: - +912066304033
EMAIL: -sales@nihva.com
www.nihva.com

INTRODUCTION

The Gear operated Rolling Shutter is the result of many years' experience in Door Automation Technologies. "NIHVA" offers the best possible factor of safety with simple, easy to use controls. The high quality of manufacture gives a robust construction and many years of useful life. Each operation opens and closed movement controlled by handle.

We take pride that our product & service range is offered with a high level of working safety, comfort, functionality and supported by services and added value solutions.

NIHVA
We Make Possible

INDEX

1. DISPATCH & UNLOADING
2. ORDERING OF SPARES
3. EMERGENCY CONTACT DETAILS
4. DETAILS OF GEAR OPERATED ROLLING SHUTTER
5. PRE-OPERATING INSTRUCTIONS
6. ROUTINE MAINTENANCE
7. PARTS LIST
8. GA DRAWING OF GEAR OPERATED ROLLING SHUTTERS

- **DESPATCH & UNLOADING**

1. Loading, for dispatch, will be our responsibility. On receipt of the Rolling Shutter at site, please check and ensure that there is no physical damage to the equipment.

2. While unloading the equipment from the transporting vehicle, please ensure to use slings with rated capacity higher than the gross weight of the Stationary lift in packed condition.

- **ORDERING OF SPARES**

1. When ordering for spare, please specify the following in your Purchase Order.

    - Shutter Size
    - Part name / Description
    - Quantity required
    - Delivery period / time
    - Mode of dispatch

    This would avoid ambiguity and help us serve you better.

- **EMERGENCY CONTACT DETAILS: -**

    1) Service - 9168938333
    2) Projects- 8551008333

- **DETAILS OF GEAR OPERATED ROLLING SHUTTER:**

1. **SHUTTER OPERATION MODE-** GEAR OPERATED
2. **OPERATION CONTROL –** BY HANDLE
3. **MATERIAL –** M.S. / G.I. AS PER GA DRAWING
4. **CLEAR OPENING HEIGHT –** AS PER GA DRAWING
5. **CLEAR OPENING WIDTH –** AS PER GA DRAWING
6. **MOUNTING SURFACE-** ON CONCRETE/M.S. STRUCTURE REFER GA DRAWING
7. **MOUNTING LOCATION –** INSIDE/OUTSIDE REFER GA DRAWING
8. **RAL SHADE-** AS PER CUSTOMER REQUIREMENT, REFER GA DRAWING.

- **PRE – OPERATING INSTRUCTIONS: -**

1. There should be no obstacles within the operating path of the rolling shutter.
2. No objects should pass through the rolling shutter while in operation.
3. The operator / owner shall read and be familiar with the Owner's manual, especially the Operating and Maintenance Instruction.
4. In the event of a malfunction, the operator shall consult the Owner's Manual and contact NIHVA.
5. Any repair or modifications by an unqualified technician will void the warranty.

- **ROUTINE MAINTENANCE**

These recommendations are applicable to the Gear operated rolling shutter considering average daily usage of 15 to 20 times. If it is used more frequently, the same time intervals for the maintenance should be adjusted accordingly.

DAILY:

1. Check shutter lock is open before operation.
2. Visual inspection for damages.


MONTHLY:

1. Greasing between Guide and slats.
2. Check all Parts for wear out or damage. Check all fixing are secure.
3. Check correct operations of handle.
4. Greasing to gear & bearing.

NIHVA
We Make Possible

PARTS LIST:

SR NO	ITEM DESCRIPTION
1	MS BRACKET LH
2	MS BRACKET RH
3	GEAR BOX
4	HANDLE
5	GUIDE
6	SLAT
7	SHAFT
8	M.S. BOTTOM
9	HOOD COVER



GEAR OPERATED ROLLING SHUTTER