



SR NO	PART NAME	PART NO	QUANTITY
1	BOOM 0		1
2	REAR TOP GUIDE ROLLER ASSEMBLY B O		8
	END BELT ROLLER ASSEMBLY B 0		1
4	LAMP CASING		1
5	PENDENT		1
6	PENDENT COVER		1
7	PENDENT PUSH BUTTON		3
8	EMERGENCY STOP		1
9	BELT STOP PUSH BUTTON		1
10	IDLER ROLLER ASSEMBLY B 0		1
11	GRAVITY ROLLER		2

BOOM 0 ASSEMBLY